

- Manuals.plus /
- > CCEOO TOY /
- > CCEOO TOY Automatic Self-Cleaning Litter Box User Manual

CCEOO TOY Box-cceoo-01

CCEOO TOY Automatic Self-Cleaning Litter Box User Manual

Model: Box-cceoo-01

1. INTRODUCTION

Thank you for choosing the CCEOO TOY Automatic Self-Cleaning Litter Box. This innovative product is designed to simplify your cat care routine by providing an automated and hygienic solution for waste management. Please read this manual thoroughly before operating the device to ensure proper setup, safe operation, and effective maintenance.

2. PRODUCT OVERVIEW

The CCEOO TOY Automatic Self-Cleaning Litter Box is an advanced pet appliance featuring automatic waste scooping, odor control, and smart app connectivity. It is designed for cats weighing between 2.2 pounds and 33 pounds.



Figure 1: Overall view of the CCEOO TOY Automatic Self-Cleaning Litter Box.

3. SETUP GUIDE

3.1 Unboxing and Initial Assembly

1. Carefully remove all components from the packaging. Verify that all parts listed in the packing list are present.
2. Place the main unit on a flat, stable surface.
3. Attach the four support legs to the designated slots on the base of the unit. Ensure they are securely fastened.
4. Insert the waste collection bin into the lower compartment of the unit.
5. Add your preferred cat litter into the main drum. This unit is compatible with all types of litter.
6. Connect the power adapter to the unit and plug it into a standard electrical outlet.

Stop scooping, let's travel!

15days/1 cat, No more bending over every day to scoop



Figure 2: The litter box in operation, demonstrating its smart control capabilities via a mobile application.

3.2 Capacity and Safety Features

The litter box features a maximum roller capacity of 75 liters and a 15-liter waste bin, capable of holding waste for up to 12 days for a single cat. For your cat's safety, the unit is equipped with 6 sensors that detect presence and a delay mechanism to prevent operation while a cat is inside.



Figure 3: Visual representation of the 75L roller capacity and 15L waste bin capacity, highlighting extended use.




Figure 4: Detailed diagram illustrating the placement and function of safety sensors for comprehensive protection.

4. OPERATING INSTRUCTIONS


4.1 Automatic Cleaning Cycle

Once powered on and a cat uses the litter box, the unit will automatically initiate a cleaning cycle after a set delay (typically a few minutes after the cat exits). The internal mechanism sifts the litter, separating solid waste and depositing it into the sealed waste bin below.

Free up your hands



Cleaning cat poop only



Cleaning all cat litter

Figure 5: Illustration of the automatic cleaning process, showing how waste is separated and collected.

4.2 Smart App Control

The CCEO TOY Automatic Litter Box can be controlled via a dedicated smartphone application. This app allows you to:

- Monitor your cat's usage data.
- Initiate cleaning cycles manually.
- Receive notifications regarding waste bin status or system alerts.
- Adjust settings and preferences.

4.3 Odor Control

The unit incorporates advanced odor control capabilities to maintain a fresh environment. The sealed waste bin minimizes odor escape, contributing to an odor-free home.

Advanced Odor Control



Figure 6: The litter box actively managing odors, ensuring a fresh living space.

4.4 Compatible Litter Types

This automatic litter box is designed to be compatible with all types of clumping cat litter, offering flexibility in your choice of litter.

Works with almost



Figure 7: A display of various cat litter types that are compatible with the automatic litter box.

5. MAINTENANCE

5.1 Emptying the Waste Bin

- The waste bin should be emptied when indicated by the app or the unit's indicator light.
- Carefully pull out the waste bin from the bottom of the unit.
- Dispose of the waste in accordance with local regulations.
- Clean the waste bin with mild soap and water, then dry thoroughly before reinserting.

5.2 Cleaning the Unit

- Unplug the unit from the power outlet before cleaning.
- Wipe down the exterior surfaces with a damp cloth. Avoid using abrasive cleaners.
- For deeper cleaning, the internal drum can be removed and washed. Refer to the detailed cleaning instructions in the app or a

separate cleaning guide for specific steps.

- Ensure all components are completely dry before reassembling and plugging the unit back in.

6. TROUBLESHOOTING

Issue	Possible Cause	Solution
Unit not cleaning automatically	Cat still inside; sensors obstructed; waste bin full.	Ensure cat has exited; check and clean sensors; empty waste bin.
Unpleasant odor persists	Waste bin not emptied regularly; unit needs cleaning; poor quality litter.	Empty waste bin more frequently; perform thorough cleaning; try a different clumping litter.
App connectivity issues	Wi-Fi signal weak; incorrect setup; app outdated.	Ensure strong Wi-Fi signal; re-pair device in app; update app to latest version.
Cat not using the litter box	New environment; noise; type of litter.	Allow time for adjustment; ensure quiet operation; use familiar litter initially.

7. SPECIFICATIONS

Feature	Detail
Model Name	Box-cceoo-01
Brand	CCEOO TOY
Dimensions (L x W x H)	19.6" x 21.6" x 26"
Item Weight	29.5 Pounds
Material	Plastic
Weight Limit (Cat)	2.2 lbs to 33 lbs
Waste Bin Capacity	15 Liters (up to 12 days for 1 cat)
Roller Capacity	75 Liters
Safety Features	6-sensor detection, delay mechanism
Control	Manual buttons, Smart App
Compatible Litter	All types of clumping litter

8. WARRANTY AND SUPPORT

CCEOO TOY offers a lifelong service commitment for this product. In the event of any issues or concerns, our dedicated after-sales team is available to provide support and answer your questions promptly, ensuring your complete satisfaction.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DK13HTTD>

More documents and user manuals: <https://manuals.plus/>