WINGBO SYCF8404

WINGBO 84-inch Windmill Ceiling Fan with Lights

Model: SYCF8404

Safety Contents Setup Operation Maintenance Troubleshooting Specifications Warranty

Important Safety Information

Please read and understand this entire manual before attempting to assemble, operate, or install the product. Failure to do so could lead to electric shock, fire, or serious injury.

- Always turn off the power at the main circuit breaker before beginning installation.
- All electrical connections must be in accordance with local codes, ordinances, and the National Electric Code. If you are unfamiliar with proper electrical wiring, consult a qualified electrician.
- Ensure the installation site can support the fan's weight.
- Do not connect the fan to a dimmer switch or a fan's gear switch. Use only the provided remote control for operation.
- Keep children away from the fan during installation and operation.
- Ensure blades are installed at least 7 feet (2.1 meters) from the floor.

Package Contents

Carefully unpack your fan and check the contents. You should have the following items:

- Fan Motor Assembly
- 10 Fan Blades (Engineered Wood)
- Downrods (4.5", 12", and 24" included)
- Mounting Bracket
- Canopy
- Remote Control with Wall Mount
- LED Light Kit
- Hardware Pack (screws, washers, wire nuts, etc.)

- Instruction Manual



Figure 1: Product dimensions and included downrods (4.5", 12", 24"). The fan is suitable for great rooms larger than 400 sq ft.

Setup and Installation

This section provides general guidance for installing your WINGBO ceiling fan. For detailed, step-by-step instructions, please refer to the included installation video and diagrams.

Pre-Installation Considerations

- **Ceiling Height:** Recommended for ceilings 9 ft and above.
- **Room Size:** Ideal for great rooms larger than 400 sq ft.
- **Location:** Approved for indoor and covered outdoor (damp) locations.

Mounting Options

The fan supports both flat ceiling mount and sloped ceiling mount up to 15 degrees.

Installation Steps Overview

1. Secure the mounting bracket to the ceiling junction box.
2. Assemble the downrod and canopy to the motor.
3. Hang the fan assembly onto the mounting bracket.
4. Make electrical connections according to the wiring diagram.
5. Attach the fan blades to the motor housing.
6. Install the LED light kit and light cover.

Your browser does not support the video tag.

Video 1: WINGBO 10-Blade Ceiling Fan Installation Guide. This video provides a visual walkthrough of the installation process for the ceiling fan.

Your browser does not support the video tag.

Video 2: WINGBO 10-Blade Ceiling Fan Overview. This video showcases the fan's features and appearance.

Operating Instructions

Your WINGBO ceiling fan is controlled by a multi-function remote control.

Remote Control Functions



Figure 2: Remote control for the WINGBO ceiling fan, offering various settings for fan speed, light, and direction.

- **Fan ON/OFF:** Press the power button to turn the fan on or off.
- **Fan Speed:** Select from 6 different fan speeds to adjust airflow.
- **Light ON/OFF:** Control the integrated LED light. Note: The light is not dimmable.
- **Color Temperature (CCT) Adjustment:** Cycle through Warm (3000K), Natural (4500K), and Daylight (6000K) light temperatures. The light has a memory function, retaining the last setting if turned off for more than 10 seconds.
- **Reversible Motor:** Switch between summer (forward) and winter (reverse) modes to optimize air circulation.
- **Timer Settings:** Set the fan to turn off automatically after 1, 2, 4, or 8 hours.
- **Natural Breeze Mode:** Activates a varying fan speed to simulate a natural breeze.




Figure 3: The fan's integrated LED light offers three color temperature options to suit different preferences and scenarios.



Figure 4: The reversible motor allows for year-round comfort, providing cooling in summer and aiding warm air circulation in winter.

Quiet Operation

The DC motor operates at a low noise level of 25 dB, ensuring quiet enjoyment, especially suitable for bedrooms or quiet living spaces.



Figure 5: The fan's quiet operation at 35dB is comparable to a library setting, ensuring minimal disturbance.

Maintenance

Regular maintenance helps ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Use a soft brush or lint-free cloth to clean the fan blades and motor housing periodically. Do not use abrasive cleaners or solvents.
- **Blade Fasteners:** Check all blade attachment screws and other fasteners at least twice a year. Ensure they are securely tightened.
- **Light Kit:** The LED light board is replaceable. If damaged or lost, contact customer support for replacement.
- **Electrical Connections:** Periodically inspect electrical connections for any signs of wear or damage.

Troubleshooting

Before attempting any repairs, ensure the power supply to the fan is disconnected at the main circuit breaker.

Problem	Possible Cause	Solution
Fan does not start	1. No power to the fan. 2. Loose wire connections. 3. Remote control battery low or not paired.	1. Check circuit breaker and wall switch. 2. Verify all wire connections are secure. 3. Replace remote battery or re-pair remote according to instructions.
Light does not work	1. Loose wire connection to light kit. 2. LED light board failure.	1. Check light kit wiring. 2. Contact customer support for a replacement LED light board.
Fan wobbles	1. Loose blade screws. 2. Blades are unbalanced. 3. Fan not securely mounted.	1. Tighten all blade screws. 2. Use a balancing kit (not included) to balance blades. 3. Ensure mounting bracket and downrod are securely installed.
Remote control not responding	1. Battery low or dead. 2. Remote not paired with fan. 3. Interference.	1. Replace battery. 2. Follow pairing instructions in the full manual. 3. Ensure no other devices are interfering with the signal.

Specifications

Feature	Detail
Brand	WINGBO
Model Number	SYCF8404
Product Dimensions	84"D x 84"W x 33"H
Color	Black and Grey
Power Source	DC
Style	Farmhouse
Room Type	Bedroom, Kitchen, Living Room, Patio
Special Feature	LED Light
Mounting Type	Downrod Mount
Controller Type	Remote Control
Number of Speeds	6
Noise Level	25 db
Wattage (Light)	24 watts

Feature	Detail
Number of Blades	10
Air Flow Capacity	9697 cfm
Speed (Max)	80 rpm
Voltage	110 volts
Indoor/Outdoor Usage	Indoor, Covered Outdoor (Damp Rated)
Motor Type	DC
Installation Type	Flat Ceiling and Sloped Ceiling (up to 15°)
Light Type	Integrated LED (3CCT: 3000K, 4500K, 6000K)
Blade Material	Engineered Wood
Included Components	Light Kit, Remote Control

Warranty and Support

WINGBO stands behind the quality of its products. Please refer to the following warranty information:

- **Whole Fan Warranty:** 2 years from the date of purchase.
- **Motor Warranty:** 10 years from the date of purchase.
- **LED Light Board & Remote Control:** If these components are damaged or lost, please contact WINGBO customer service for assistance.

Customer Support

For any questions, technical assistance, or warranty claims, please contact WINGBO customer support through the retailer where the product was purchased or visit the official WINGBO website for contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question