

[Manuals.plus](#) /

> [iWALK](#) /

> iWALK 20000mAh 65W Portable Charger User Manual

iWALK LPR002

iWALK 20000mAh 65W Portable Charger User Manual

Model: LPR002

INTRODUCTION

This manual provides instructions for the safe and efficient use of your iWALK 20000mAh 65W Portable Charger (Model LPR002). Please read this manual thoroughly before using the product and retain it for future reference.





Image: The iWALK 20000mAh 65W Portable Charger, showcasing its compact design and integrated retractable USB-C cable.

PRODUCT OVERVIEW

Key Features:

- **High Capacity:** 20,000mAh battery for extended power.
- **Fast Charging:** Up to 65W output for rapid charging of compatible devices.
- **Integrated Retractable USB-C Cable:** A 2.3 ft (approximately 27.56 inches) built-in USB-C cable for convenience and portability.
- **Multiple Outputs:** Features a USB-C cable (PD 65W), a USB-C port (PD 65W), and a USB-A port (QC 22.5W) for charging multiple devices simultaneously.

- **LED Display:** Digital display to show the precise charge level.
- **Compact Design:** Ergonomic and portable, designed to be smaller than other power banks of similar capacity.

3 Outputs for Fast Charging



USB-C Cable
PD 65W



USB-C Port
PD 65W



USB-A Port
QC 22.5W



Single device charging is recommended

Image: The iWALK portable charger highlighting its three distinct charging outputs.

SETUP

Initial Charging of the Power Bank:

1. **Using the Built-in Cable:** Extend the integrated USB-C cable from the power bank. Connect the USB-C end to a compatible wall charger (65W or higher recommended for fastest charging, not included).

2. **Using an External Cable:** Alternatively, connect a USB-C to USB-C cable (not included) to the power bank's USB-C input port and then to a compatible wall charger.
3. The LED display will show the charging progress. A full charge typically takes approximately 1.38 hours with a 65W charger.




Image: Illustration of the two methods for recharging the power bank.

OPERATING INSTRUCTIONS

Charging Your Devices:

1. Using the Built-in Retractable USB-C Cable:

- Gently pull the retractable USB-C cable to extend it to the desired length (up to 2.3 ft).
- Connect the USB-C connector to your compatible device (e.g., laptop, smartphone, tablet).
- The power bank will automatically begin charging your device.
- To retract the cable, give it a gentle pull, and it will automatically retract into the unit.

Effortless PD High-Speed Charging



Image: Charging a laptop using the integrated USB-C cable.

2. Using the USB-C Output Port:

- Connect a USB-C to USB-C cable (not included) from the power bank's USB-C output port to your device.
- The power bank will initiate charging.

3. Using the USB-A Output Port:

- Connect a USB-A to compatible cable (not included) from the power bank's USB-A output port to your device.
- Charging will commence automatically.

4. **Simultaneous Charging:** The power bank supports charging up to three devices concurrently using all available outputs. For optimal performance, charging a single device is recommended when high-speed charging is critical.

Checking Battery Level:

The integrated LED display on the power bank shows the remaining battery percentage, allowing you to monitor the charge status accurately.



Image: The smart LED display indicating battery percentage.

MAINTENANCE

- Keep the power bank away from water, moisture, and extreme temperatures.
- Avoid dropping or subjecting the power bank to strong impacts.
- Clean the device with a dry, soft cloth. Do not use harsh chemicals or abrasive materials.
- Store the power bank in a cool, dry place when not in use. For long-term storage, it is recommended to charge the power bank to about 50-70% every three months to prolong battery life.
- Do not attempt to disassemble or repair the power bank yourself. This will void the warranty and may cause damage or injury.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging	Low battery; faulty charging cable/adaptor; loose connection.	Ensure the power bank is connected to a working power source with a functional cable and adaptor. Check connections.
Device not charging from power bank	Power bank battery depleted; incompatible cable; device not properly connected; device requires more power than available.	Recharge the power bank. Use a compatible cable. Ensure secure connection. Verify device power requirements.
Slow charging	Using a low-wattage charger/adaptor for the power bank; using a non-fast charging cable; multiple devices charging simultaneously.	Use a 65W or higher power adaptor for recharging the power bank. Use fast-charging compatible cables. Charge one device at a time for maximum speed.
Retractable cable not retracting smoothly	Mechanism obstruction or damage.	Ensure no debris is obstructing the cable path. Gently pull and release the cable. If the issue persists, contact customer support.

SPECIFICATIONS

Model Number	LPR002
Battery Capacity	20000 Milliamp Hours (mAh)
Max Output Power	65W
Input/Output Ports	Built-in USB-C Cable (PD 65W), USB-C Port (PD 65W), USB-A Port (QC 22.5W)
Product Dimensions	6.2 x 1.7 x 2 inches
Item Weight	14.9 ounces
Battery Type	Lithium Polymer
Color	Black
Manufacturer	U2O GLOBAL CO.,LTD

Applicable to Various Models

Laptops:



MacBook Pro / MacBook Air



DELL XPS



Microsoft Surface Book 2



ThinkPad T14

And
More...

Phones:



iPhone 16 / iPhone 15 / iPhone 14 / iPhone 13 / iPhone 12 / iPhone 11 / iPhone 8,SE Series




Samsung Galaxy S23 Ultra / S23 + / S23 / S21 / S20 / S9
Note 22 / Z Flip Series



Google Pixel 3 and Later
Sony XZ3 / Xpeia 1

And
More...

Tablets:



iPad Pro / iPad Air / iPad / iPad mini and Later



Galaxy Tab S7



Galaxy Tab A8

And
More...

Other Devices:



Switch



ROG Ally



AirPods



Galaxy Buds Pro

And
More...

Image: Compatibility chart for various devices.

SAFETY INFORMATION

- Do not expose the power bank to fire or high temperatures.
- Do not immerse the power bank in water or other liquids.
- Keep out of reach of children.
- Do not use the power bank if it is damaged or appears to be swelling.
- Dispose of the power bank according to local regulations for electronic waste.

WARRANTY AND SUPPORT

iWALK products come with a standard manufacturer's warranty. For detailed warranty information, product support, or to register your product, please visit the official iWALK website or contact their customer service directly.

Manufacturer: U2O GLOBAL CO.,LTD

For further assistance, please refer to the [iWALK Store on Amazon](#).