

bmani S13

bmani Wireless Bluetooth Earbuds - User Manual

Model: S13
Brand: bmani

INTRODUCTION

Thank you for choosing the bmani Wireless Bluetooth Earbuds. These earbuds are designed to provide an immersive music experience with enhanced bass and effective noise cancellation. This manual will guide you through the setup, operation, and maintenance of your new earbuds.





Image: The bmani Wireless Bluetooth Earbuds in their charcoal charging case, displaying a digital battery percentage.

Your browser does not support the video tag.

Video: An official overview of the bmani S13 Wireless Bluetooth Earbuds, highlighting key features, design, and compatibility. This video provides a visual introduction to the product.

WHAT'S IN THE BOX

Upon opening your package, you should find the following items:

- bmani Wireless Bluetooth Earbuds (in-the-ear-headphones)
- Charging Case
- User Manual (this document)
- USB-C Charging Cable
- Multiple sizes of ear tips

KEY FEATURES

The bmani S13 Earbuds are equipped with advanced features for a superior audio experience:

- **Enhanced Bass & Hi-Fi Stereo Sound:** Features 13mm dynamic drivers for deep bass and crystal-clear treble.
- **Active Noise Cancellation:** Provides an isolated listening environment by reducing ambient noise.
- **Bluetooth 5.3 Connectivity:** Ensures faster and more stable wireless connection.
- **Long Battery Life:** Up to 8 hours of playback on a single charge for earbuds, and 48 hours total with the charging case.
- **Dual Charging Options:** Supports both USB-C wired charging and wireless Qi charging.
- **Lightweight & Ergonomic Design:** Designed for comfortable and secure fit during extended use.
- **IPX7 Waterproof:** Resistant to sweat, rain, and splashing, making them suitable for various activities.

- **LED Digital Battery Display:** Clear indication of charging case and earbud battery status.
- **Smart Button Control:** Intuitive touch controls for music playback, calls, and voice assistant.
- **Monaural/Binaural Mode:** Use one or both earbuds as needed.

HiFi Stereo Sound

13mm dynamic driver produce deep bass & crystal treble



Image: Illustration of the earbuds' internal components, emphasizing the 13mm dynamic driver for deep bass and crystal treble, delivering HiFi Stereo Sound.

Deep Bass Hi-Fi Stereo Sound



Image: An exploded diagram showcasing the intricate components of the earbud's audio driver, designed for deep bass and high-fidelity stereo sound.

DESIGN AND COMFORT

The bmani S13 earbuds are engineered for maximum comfort and a secure fit, making them ideal for prolonged use.

- **Lightweight:** Each earbud is designed to be extremely light, minimizing ear fatigue.
- **Ergonomic Fit:** The rounded tips and in-ear design conform naturally to the ear canal, ensuring stability during movement.
- **Compact Dimensions:** The earbuds and case are designed for portability.



Image: A woman wearing a bmani earbud, highlighting its lightweight nature and ergonomic design for comfortable wear.

SETUP AND PAIRING

Follow these steps to pair your bmani S13 Earbuds with your device:

1. **Initial Charge:** Before first time use, please ensure both the earbuds and the charging case are fully charged.
2. **Power On & Pairing Mode:** Open the lid of the charging case. The earbuds will automatically power on and enter pairing mode.
3. **Connect via Bluetooth:** On your device (smartphone, tablet, etc.), go to Bluetooth settings and select "S13" from the list of available devices.
4. **Confirmation:** Once connected, you will hear an audio prompt, and the earbuds will be ready for use.

Bluetooth 5.3 with One-Step Pairing

Faster & more stable connect when open the case lid




Image: A smartphone screen displaying a successful Bluetooth connection to the "S13" earbuds, demonstrating the one-step pairing process.

OPERATING INSTRUCTIONS

The bmani S13 Earbuds feature intuitive touch controls for easy management of your audio and calls.

Touch Controls:

Play/Pause: Tap L/R earbud 1 time.

Volume +/-: Tap L/R earbud 2 times.

Previous/Next Track: Tap L/R earbud for 2 seconds.

Answer/Hang Up Call: Tap L/R earbud 1 time.

Reject Call: Tap L/R earbud for 2 seconds.

Voice Assistant: Tap L/R earbud 3 times.



Image: A visual guide detailing the smart button controls on the earbuds for various functions like play/pause, volume adjustment, track skipping, call management, and voice assistant activation.

Monoaural/Binaural Mode:

You can use either a single earbud (Monoaural Mode) or both earbuds together (Binaural Mode) depending on your preference and situation. Simply take one or both earbuds out of the case to activate the desired mode.



Image: A couple enjoying music, illustrating the flexibility of using the earbuds in either monoaural (single earbud) or binaural (both earbuds) mode.

CHARGING

Keep your bmani S13 Earbuds powered up with convenient charging options:

- **USB-C Charging:** Connect the provided USB-C cable to the charging case and a power source.
- **Wireless Charging:** Place the charging case on a Qi-compatible wireless charging pad.
- **Battery Display:** The LED digital display on the charging case shows the battery percentage of the case and the charging status of each earbud.



Image: The bmani earbud charging case being charged via a USB-C cable and simultaneously on a wireless charging pad, demonstrating both charging methods.

Digital Battery Display



Capacity of Charging Case



Charging Status of Earbuds

48H
with Charging Case



8H
Single Earbuds



Image: A close-up of the charging case's LED digital display, indicating the charging case capacity and the individual charging status of the earbuds.

WATER RESISTANCE (IPX7)

Your bmani S13 Earbuds are rated IPX7 waterproof, meaning they can withstand:

- Raining conditions
- Sweat during workouts
- Splashing from water

Note: IPX7 rating means the earbuds can be submerged in up to 1 meter of water for 30 minutes. However, it is not recommended for swimming or showering. The charging case is NOT waterproof.



Image: A man wearing the earbuds while engaging in an activity, demonstrating their IPX7 waterproof capability against rain, sweat, and splashing.

COMPATIBILITY

The bmani S13 Earbuds are designed for wide compatibility with various Bluetooth-enabled devices, including:

- Smartphones (iOS and Android)
- Tablets
- Laptops and PCs
- Other Bluetooth audio devices

They also support voice assistant integration for convenient hands-free control.

Monaural/Binaural Mode

Enjoy lively music with your partner



Image: An illustration showcasing the wide compatibility of the earbuds with various Bluetooth-enabled devices, including smartphones and tablets, along with features like voice assistant support and portability.

SPECIFICATIONS

Feature	Detail
Model Name	S13
Connectivity Technology	Wireless (Bluetooth 5.3)
Ear Placement	In Ear
Form Factor	In Ear
Noise Control	Active Noise Cancellation
Audio Driver Type	Dynamic Driver
Frequency Range	20 Hz - 20,000 Hz
Item Weight	3.2 ounces
Package Dimensions	3.7 x 3.27 x 1.54 inches
Batteries	1 Lithium Polymer battery (included)
Waterproof Rating	IPX7

MAINTENANCE

To ensure the longevity and optimal performance of your bmani S13 Earbuds, follow these maintenance tips:

- **Cleaning:** Regularly wipe the earbuds and charging case with a soft, dry, lint-free cloth. For ear tips, remove them and clean with mild soap and water, then dry thoroughly before reattaching.
- **Storage:** Store the earbuds in their charging case when not in use to protect them from dust and damage.
- **Avoid Extreme Conditions:** Do not expose the earbuds or case to extreme temperatures, humidity, or corrosive liquids.
- **Charging Practices:** Avoid overcharging. Disconnect the charger once the battery is full.

TROUBLESHOOTING

If you encounter any issues with your bmani S13 Earbuds, try the following solutions:

- **No Sound/Poor Sound Quality:**
 - Ensure earbuds are fully charged.
 - Check if the earbuds are properly connected to your device via Bluetooth. Try re-pairing.
 - Clean any debris from the earbud speakers and ear tips.
 - Adjust the volume on both your device and the earbuds.
- **Earbuds Not Pairing:**
 - Make sure Bluetooth is enabled on your device.
 - Ensure the earbuds are in pairing mode (open the case lid).
 - Forget "S13" from your device's Bluetooth list and try pairing again.
 - Ensure the earbuds and device are within the effective Bluetooth range.
- **Charging Issues:**
 - Check the USB-C cable and power adapter for damage.
 - Ensure the charging contacts on the earbuds and inside the case are clean and dry.
 - If using wireless charging, ensure the case is correctly placed on the charging pad.
- **Earbuds Not Fitting Comfortably:**
 - Try different sizes of ear tips (if included) to find the best fit for your ears.
 - Adjust the angle of the earbuds in your ear until they feel secure and comfortable.

WARRANTY AND SUPPORT

For information regarding warranty coverage, technical support, or replacement parts, please refer to the product's official listing page on Amazon or contact bmani customer service directly. Keep your purchase receipt as proof of purchase.

You can visit the bmani Store for more information:[bmani Store on Amazon](#)

© 2024 bmani. All rights reserved.

Documents - bmani – S13

no relevant documents