Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hello Kitty HKTWSMD-KU-MFN

Hello Kitty Bluetooth Wireless Earbuds Instruction Manual

Model: HKTWSMD-KU-MFN

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your Hello Kitty Bluetooth Wireless Earbuds. Please read this manual thoroughly before using the product to ensure proper function and longevity.

Package Contents

Verify that all items are present in your package:

- Hello Kitty Bluetooth Wireless Earbuds (Left and Right)
- Hello Kitty Charging Case
- USB Charging Cable
- Instruction Manual

Product Overview

The Hello Kitty Bluetooth Wireless Earbuds offer a convenient and stylish audio experience. The charging case features a unique Kuromi design, providing both protection and extended battery life for your earbuds.






Image: Hello Kitty Bluetooth Wireless Earbuds shown with the Kuromi-themed charging case. The earbuds are black, and the case is purple and black with Kuromi and My Melody characters.

The earbuds are designed for an in-ear fit and feature a built-in microphone for hands-free communication. The charging case not only stores the earbuds but also recharges them, ensuring they are ready for use.



Image: The black Hello Kitty Bluetooth Wireless Earbuds are placed inside the open Kuromi-themed charging case, illustrating how they are stored and charged.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case.
2. Connect the USB charging cable to the charging port on the case and plug the other end into a USB power source

(e.g., computer, wall adapter).
3. The indicator light on the case will show charging status. Once fully charged, the light will change or turn off.
4. A full charge provides approximately 3 hours of earbud playback and the case holds multiple charges for up to 30 hours total playback.

2. Pairing with a Bluetooth Device

Follow these steps to connect your earbuds to your smartphone, tablet, or other Bluetooth-enabled device:

1. Ensure the earbuds are charged and placed in the charging case.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing light on the earbuds.
3. On your device, go to Bluetooth settings and enable Bluetooth.
4. Search for available devices. You should see "Hello Kitty Earbuds" or a similar name appear in the list.
5. Select the earbuds from the list to connect. Once connected, a voice prompt will confirm successful pairing, and the earbud indicator lights will stop flashing.
6. If pairing fails, turn off the earbuds, close the case, and repeat the steps.

Operating Instructions

The earbuds feature push-button controls for various functions:

- **Power On/Off:** Earbuds power on automatically when removed from the case and power off when returned to the case.
- **Play/Pause Music:** Press the button on either earbud once.
- **Next Track:** Double-press the button on the right earbud.
- **Previous Track:** Double-press the button on the left earbud.
- **Answer/End Call:** Press the button on either earbud once during an incoming call or during a call.
- **Reject Call:** Press and hold the button on either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple-press the button on either earbud (if supported by your device).

The built-in microphone allows for clear hands-free calls.

Maintenance

To ensure the longevity and optimal performance of your earbuds:

- **Cleaning:** Use a soft, dry cloth to clean the earbuds and charging case. Do not use liquids or abrasive cleaners.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Temperature:** Avoid exposing the earbuds to extreme temperatures (hot or cold) or high humidity.
- **Water Exposure:** These earbuds are not waterproof. Avoid contact with water or other liquids.

Troubleshooting

If you encounter issues with your earbuds, refer to the following common solutions:

Problem	Solution

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off Bluetooth on your device and turn it back on. Forget the device in your Bluetooth settings and try pairing again. Place earbuds back in the case, close, wait a few seconds, then open to re-enter pairing mode.
No sound from earbuds	Check device volume and earbud volume. Ensure earbuds are properly connected to your device. Try playing audio from a different application or source. Re-pair the earbuds with your device.
One earbud not working	Ensure both earbuds are charged. Place both earbuds back in the charging case, close the lid, then open it again. Try resetting the earbuds (refer to manufacturer's website if specific reset instructions are available).
Charging case not charging	Check the USB cable and power adapter for damage. Try a different USB cable or power source. Ensure the charging port on the case is clean and free of debris.

Specifications

- **Model:** HKTWSMD-KU-MFN
- **Brand:** Hello Kitty
- **Connectivity:** Bluetooth Wireless
- **Bluetooth Range:** Up to 33 feet (10 meters)
- **Ear Placement:** In Ear
- **Form Factor:** In Ear
- **Control Method:** Push Button
- **Frequency Range:** 20Hz - 20,000Hz
- **Impedance:** 32 Ohm
- **Earbud Battery Capacity:** 30mAh (each)
- **Charging Case Battery Capacity:** 200mAh
- **Earbud Playback Time:** Approximately 3 hours
- **Total Playback Time (with case):** Up to 30 hours
- **Features:** Built-in Microphone, Lightweight, Rechargeable Battery
- **Material:** Plastic
- **Item Weight:** Approximately 0.08 Kilograms (earbuds and case)
- **UPC:** 680079035389
- **Manufacturer:** Southern Telecom

Safety Information

Please observe the following safety guidelines:

- Do not disassemble, repair, or modify the product.
- Keep away from water, moisture, and extreme temperatures.
- Avoid prolonged listening at high volumes to prevent hearing damage.
- Keep out of reach of small children due to small parts.
- Dispose of the product responsibly according to local regulations.

Warranty and Support

For warranty information or technical support, please contact the manufacturer, Southern Telecom, directly. Refer to the product packaging or their official website for contact details.
Manufacturer: Southern Telecom

© 2024 Southern Telecom. All rights reserved. Hello Kitty and related characters are trademarks of Sanrio Co., Ltd.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DK2B8G1X

More documents and user manuals: **https://manuals.plus/**