

[Manuals.plus](#) /

› [ML Lighting](#) /

› ML Lighting Dumont Collection Outdoor LED Wall Sconce User Manual

ML Lighting 89101-PBK

ML Lighting Dumont Collection Outdoor LED Wall Sconce User Manual

Model: 89101-PBK

1. INTRODUCTION

Thank you for choosing the ML Lighting Dumont Collection Outdoor LED Wall Sconce. This manual provides important information regarding the installation, operation, and maintenance of your new lighting fixture. Please read this manual thoroughly before installation and retain it for future reference.





Front view of the ML Lighting Dumont Collection Outdoor LED Wall Sconce, showcasing its powder coated black finish and clear glass shade.

2. SAFETY INFORMATION

For your safety, always read and understand all instructions completely before beginning installation. If you are unsure about any part of these instructions, consult a qualified electrician. Always turn off power at the main circuit breaker before installation or maintenance.

- Ensure the electrical supply is disconnected before handling the fixture.
- This fixture is rated for wet locations, suitable for outdoor use.
- Professional installation is recommended to ensure proper and safe setup.


- Do not attempt to modify the fixture. Any modifications may void the warranty and create a safety hazard.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation.

- Dumont Collection Outdoor LED Wall Sconce (Integrated LED)
- Clear Glass Shade
- Mounting Hardware (screws, wire nuts, mounting plate)
- Instruction Manual

4. SPECIFICATIONS



Detailed dimensions of the ML Lighting Dumont Collection Outdoor LED Wall Sconce, including height, width, depth, and backplate measurements.

Feature	Detail
Model Number	89101-PBK
Dimensions (L x W x H)	6.8" x 4.81" x 13.64"
Weight	2.96 lbs (fixture) / 4.11 lbs (package)

Feature	Detail
Color	Powder Coated Black
Material	Metal frame, Glass shade
Light Source	Integrated LED
Color Temperature	3000K
Wattage	6W
Voltage	120 Volts
Location Rating	Wet (Outdoor Use Only)
Assembly Required	Yes

5. INSTALLATION (SETUP)

This section provides general guidance for installing your outdoor wall sconce. Due to the nature of electrical installations, professional installation is highly recommended.

5.1 Pre-Installation Steps

- Turn off Power:** Locate the main circuit breaker and turn off the power to the junction box where the fixture will be installed.
- Unpack Contents:** Carefully remove all components from the packaging and inspect for any damage.
- Prepare Wiring:** If replacing an existing fixture, disconnect and remove it. Ensure the existing wiring is in good condition.


5.2 Mounting the Fixture

- Attach Mounting Plate:** Secure the provided mounting plate to the junction box using the screws.
- Wire Connections:** Connect the fixture's wires to the house wires according to standard electrical codes (black to black, white to white, ground to ground). Use wire nuts to secure connections.
- Secure Fixture:** Carefully push the wired fixture onto the mounting plate and secure it with the provided screws.
- Install Glass Shade:** Gently slide the clear glass cylinder shade into place.

5.3 Sizing Guidelines for Outdoor Lighting

Consider these general guidelines for optimal placement of your outdoor wall sconce:

OUTDOOR LIGHTING SIZING GUIDELINES



Front Door: Single Side

Position the light fixture on the same side as the doorknob in order to see your visitors' faces when opening the door at night. Mount center of the fixture at eye level, or 60"-65" from the ground.




Front Door: Both Sides

When mounting exterior wall lights beside a door, position the fixtures at eye level, or 60"-65" from the ground. For the best spread of light, the fixture should measure at least $\frac{1}{4}$ the height of the door.


Diagram illustrating recommended sizing and placement for outdoor wall sconces near a front door, for both single and double-sided installations.

WALL SCONCE LIGHTING SIZING GUIDELINES



In a Hallway

When installing multiple wall sconces to accent a hallway, dining room or other living space, consider leaving a minimum of 8'-10' between each fixture for a balanced spread of light.



Beside the Bed

For best results, leave approximately 55"-60" of space from the floor to the top of the sconce. If your sconce has a switch, be sure to install it where it can be easily reached from a sitting position in the bed.

Diagram illustrating recommended sizing and placement for wall sconces in hallways and beside a bed. While this fixture is for outdoor use, the general principles of spacing and height can be adapted.

6. OPERATING INSTRUCTIONS

Once installed, operating your ML Lighting Dumont Collection Outdoor LED Wall Sconce is straightforward:

- **Power On:** After installation is complete and all connections are secure, turn the power back on at the main circuit breaker.
- **Activate:** The fixture will illuminate when power is supplied. If connected to a wall switch, use the switch to turn the light on or off.

7. MAINTENANCE

The ML Lighting Dumont Collection Outdoor LED Wall Sconce is designed for durability and minimal maintenance. The integrated LED light source does not require bulb replacement.

- **Cleaning:** To clean the fixture, ensure power is off. Wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or glass.

- **Inspection:** Periodically inspect the fixture for any signs of wear, damage, or loose connections. If any issues are found, consult a qualified electrician.

8. TROUBLESHOOTING

If your ML Lighting Dumont Collection Outdoor LED Wall Sconce is not functioning as expected, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check the circuit breaker and ensure it is in the "ON" position. Verify all wire connections are secure.
Light flickers or dims.	Loose wiring connection or incompatible dimmer switch.	Turn off power and check all wire connections. Ensure any dimmer switch used is compatible with LED fixtures.
Fixture is damaged.	Physical impact or manufacturing defect.	Contact ML Lighting customer support for assistance. Do not attempt to repair damaged components yourself.

9. WARRANTY & SUPPORT

ML Lighting stands behind the quality of its products.

- **Warranty:** This product is covered under a 5-year limited manufacturer warranty. This warranty covers defects in materials and workmanship.
- **Customer Support:** If you experience any problems with this product, require further support, or need to inquire about returns, replacements, or shipment tracking, please contact ML Lighting customer service. We are committed to solving your problem within 24 hours.

For the most up-to-date contact information, please refer to the ML Lighting official website or your purchase documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question