

[Manuals.plus](#) /

› [Chrangmay](#) /

› Chrangmay 9-Drawer Dresser Instruction Manual

## Chrangmay dougui

# Chrangmay 9-Drawer Dresser Instruction Manual

Model: dougui

## INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Chrangmay 9-Drawer Dresser. Please read all instructions carefully before beginning assembly and retain this manual for future reference. This dresser is designed for storage in various living spaces, including bedrooms, living rooms, and entryways.


## SAFETY INFORMATION

**Important:** To prevent serious injury, always follow these safety precautions.

- **Anti-Tipping Device:** This dresser includes an anti-tipping device. It is crucial to install this device securely to a wall to prevent the dresser from tipping over, especially in households with children or pets. Failure to install this device can result in severe injury or death.
- **Weight Distribution:** Distribute weight evenly across drawers. Place heavier items in lower drawers to enhance stability.
- **Drawer Usage:** Do not open multiple drawers simultaneously. This can destabilize the dresser and cause it to tip.
- **Surface Placement:** Place the dresser on a flat, level surface. Uneven surfaces can compromise stability.
- **Children:** Do not allow children to climb on or play with the dresser drawers.

# The anti-tip kit adds extra stability

Protect your family members



Two anti-tipping Devices

At the back of the drawer cabinet




Image: Illustration of the anti-tipping device installation and a warning against climbing on the dresser. The left panel shows a person securing the dresser to the wall, marked with a checkmark. The right panel shows a child climbing on an unsecured dresser, marked with an 'X', indicating danger.

## PRODUCT SPECIFICATIONS

Brand	Chrangmay
Model Name	dougui
Product Dimensions	15.75"D x 63"W x 31.5"H
Color	Walnuts
Item Weight	52 Pounds
Number of Drawers	9

<b>Drawer Type</b>	Ball Bearing Slide
<b>Assembly Required</b>	Yes

## Dimensions

✔ Overall : 63" W x15.75" D x31.50" H

Note: All dimensions are manually measured and may have a 0.4–1.2 in error  
Please refer to the actual product dimensions



Image: A diagram illustrating the overall dimensions of the dresser: 63 inches wide, 15.75 inches deep, and 31.50 inches high. It also shows the height of the legs at 6.10 inches and a small inset diagram of a drawer's internal dimensions.

## PARTS LIST

Before assembly, ensure all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Dresser Top Panel
- Side Panels (2)
- Bottom Panel
- Back Panel

- Drawer Fronts (9)
- Drawer Side Panels (18)
- Drawer Back Panels (9)
- Drawer Bottom Panels (9)
- Wooden Legs (6) with Brass Accents
- Drawer Knobs/Handles (9)
- Ball Bearing Drawer Slides (18 pairs)
- Anti-Tipping Device (1 set)
- Assembly Hardware (screws, dowels, cam locks, etc.)



Image: A close-up view highlighting key components: smooth drawer rails, exquisite golden handles, and wooden legs with brass caps. These are essential parts for the dresser's functionality and appearance.

## ASSEMBLY INSTRUCTIONS (SETUP)

---

Assembly requires two people and approximately 2-3 hours. Follow the numbered steps carefully. All necessary tools are typically included, but a screwdriver may be helpful.

- 1. Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Verify all parts against the provided parts list.
- 2. Assemble the Main Frame:**
  - Attach the side panels to the bottom panel using the provided hardware (e.g., dowels and cam locks).
  - Secure the top panel to the assembled sides and bottom.
  - Attach the back panel to the main frame using small nails or screws. Ensure the frame is square.
- 3. Install Drawer Slides:** Attach the drawer slides to the interior of the dresser frame according to the pre-drilled holes. Ensure they are level and aligned.
- 4. Assemble Drawers:** For each of the nine drawers:
  - Connect the drawer side panels to the drawer back panel and drawer front panel.
  - Slide the drawer bottom panel into the grooves.
  - Attach the corresponding drawer slides to the sides of the assembled drawer boxes.
  - Install the drawer knobs/handles onto the drawer fronts.

5. **Insert Drawers:** Carefully insert each assembled drawer into its respective slot in the dresser frame. Ensure smooth operation. Adjust drawer slides if necessary for proper alignment.
6. **Attach Legs:** Securely attach the six wooden legs to the bottom of the dresser using the provided hardware.
7. **Install Anti-Tipping Device:** Position the dresser in its final location. Securely attach the anti-tipping device to the back of the dresser and to a wall stud using the provided hardware. This step is critical for safety.

## Spacious storage space

9 drawers provide ample space for organizing clothes, small items, and more.

9 large drawers+Spacious tabletop



Image: The dresser with all nine drawers partially open, demonstrating the spacious storage capacity for various items like clothes, shoes, and accessories.

### OPERATING INSTRUCTIONS

Your Chrangmay 9-Drawer Dresser is designed for efficient storage and ease of use.

- **Opening/Closing Drawers:** Gently pull or push the drawer handles to open and close. The ball-bearing slides ensure smooth operation. Avoid forcing drawers.
- **Storage Capacity:** The nine drawers provide ample space for organizing clothes, linens, accessories, and other

household items. The spacious tabletop can hold decorative items, lamps, or other daily necessities.

- **Weight Limit:** Do not overload drawers. Exceeding weight limits can damage the drawer slides and compromise the dresser's stability.



Image: The Chrangmay dresser positioned in a bedroom, serving as both a storage unit and a surface for decorative items, highlighting its versatile use.

## MAINTENANCE

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe the dresser surface with a dry cloth. For light cleaning, a damp cloth followed by a dry cloth can be used. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood finish.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood.
- **Humidity:** Maintain a stable humidity level in the room to prevent wood warping or cracking.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten as needed.

## TROUBLESHOOTING

If you encounter issues with your dresser, refer to the following common problems and solutions:

- **Drawers Not Closing Smoothly or Uneven:**
  - Check if the drawer slides are properly aligned and securely fastened to both the drawer box and the dresser frame.
  - Ensure no items inside the drawer are obstructing its movement.
  - Verify that the dresser is on a level surface. Adjust feet if necessary.
- **Dresser Feels Wobbly:**
  - Confirm all assembly hardware is tightened.
  - Ensure the dresser is placed on a flat, level floor.
  - Verify the anti-tipping device is correctly installed and secured to the wall.
- **Missing or Damaged Parts:**

- Refer to the "Warranty and Support" section to contact customer service for replacement parts.

## WARRANTY AND SUPPORT

---

Chrangmay is committed to providing quality products and customer satisfaction. If you experience any product problems, require replacement parts, or have questions regarding assembly or use, please contact our customer support team. Our products require self-assembly, and clear instructions are provided. We also offer excellent after-sales service for any product issues.

For assistance, please visit the [Chrangmay Store on Amazon](#) or contact us directly through the platform where you purchased the product.