

[Manuals.plus](#) /

› [HAPPYGRILL](#) /

› HAPPYGRILL Tall Adirondack Chairs Set (Model HG3021) - Instruction Manual

## HAPPYGRILL HG3021

# HAPPYGRILL Tall Adirondack Chairs Set

Model: HG3021

## INTRODUCTION

---

Thank you for choosing the HAPPYGRILL Tall Adirondack Chairs Set. This manual provides essential information for the safe assembly, operation, and maintenance of your new HDPE patio bar stools. Please read these instructions carefully before assembly and retain them for future reference.



The HAPPYGRILL Tall Adirondack Chairs Set provides comfortable outdoor seating.

## SAFETY INFORMATION

---

- Always assemble the chair on a soft, clean surface to prevent damage.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight capacity of 330 lbs (150 kg) per chair.
- Keep children away from the assembly area. Small parts can be a choking hazard.
- Use the chair only on a flat, stable surface to prevent tipping.
- Avoid standing on the chair or using it as a step stool.

## PACKAGE CONTENTS

---

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact HAPPYGRILL customer support.

- Chair Components (Backrest, Seat, Armrests, Legs, Footrest)
- Hardware Pack (Screws, Bolts, Washers, Allen Wrench)
- Instruction Manual

## SETUP AND ASSEMBLY

---

Follow these steps carefully to assemble your HAPPYGRILL Tall Adirondack Chair. It is recommended to have two people for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratches.
2. **Attach Backrest to Seat:** Connect the backrest to the seat using the provided hardware. Do not fully tighten screws at this stage.
3. **Assemble Legs:** Attach the front and rear legs to the seat and backrest assembly. Ensure correct orientation.
4. **Install Armrests:** Secure the armrests to the side of the seat and backrest.
5. **Attach Footrest:** Connect the footrest between the front legs.
6. **Final Tightening:** Once all parts are loosely assembled and aligned, gradually tighten all screws and bolts using the included Allen wrench. **Important: Do not tighten screws until all holes are aligned. Otherwise, some screw holes may be misaligned, or result in different lengths of furniture legs.**




Refer to the product dimensions for proper assembly and placement.

# Product Dimensions



Weight Capacity



Ensure all screw connections are reinforced and secure.

## OPERATING INSTRUCTIONS

The HAPPYGRILL Tall Adirondack Chair is designed for outdoor leisure. Its ergonomic features provide comfort for extended periods.

- **Placement:** Position the chair on a stable, level surface in your backyard, lawn, poolside, or patio area.
- **Recommended Table Height:** This bar height chair is ideal for pairing with counter tables that are 35 to 39 inches high.
- **Comfort Features:** The 105° inclined backrest, curved seat, wide armrests, and 4.5-inch wide footrest are designed to relieve stress and fatigue.

# 24.5" Seat Height

Recommend 35"-39" counter height table



Ergonomic design ensures comfort and breathability.



## Reinforced Screw Connection

## Appealing Wood-Like Texture



The 24.5-inch seat height is suitable for 35-39 inch counter height tables.

## MAINTENANCE

The HDPE construction of your Adirondack chair makes maintenance simple and easy.

- **Cleaning:** Wipe the chair with a wet cloth to remove dirt and debris. For tougher stains, a mild soap solution can be used. Rinse thoroughly with water.
- **No Harsh Chemicals:** Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the HDPE material.
- **Weather Resistance:** The HDPE material is waterproof, sunproof, and anti-fading, designed for extended outdoor use without significant wear.

# Ergonomic & Breathable

Effectively relieve your stress and fatigue



Curved Seat



4.5" Wide Footrest

HDPE material ensures durability and easy maintenance in various weather conditions.

## TROUBLESHOOTING

If you encounter any issues with your chair, refer to the following common solutions:

- **Wobbling Chair:** Ensure all screws and bolts are fully tightened. Check that the chair is placed on a level surface. If the issue persists, disassemble and reassemble, ensuring all parts are correctly aligned before tightening.
- **Difficulty Aligning Holes:** Do not fully tighten any screws until all components are loosely connected. This allows for minor adjustments to align holes.
- **Damaged or Missing Parts:** If you received damaged or missing parts, please contact HAPPYGRILL customer support for assistance.

## SPECIFICATIONS

Feature	Specification
Brand	HAPPYGRILL
Model Number	HG3021
Material	High Density Polyethylene (HDPE)
Color (Current Variant)	Grey
Overall Dimensions (L x W x H)	27.5" x 33.5" x 47" (70 x 85 x 119 cm)
Seat Height from Ground	24.5" (62 cm)
Seat Dimensions (L x W)	19.5" x 18" (50 x 46 cm)
Footrest Dimensions (L x W)	21.5" x 4.5" (55 x 11 cm)
Net Weight (Each Chair)	41 lbs (18.5 kg)
Weight Capacity	330 lbs (150 kg)
Assembly Required	Yes

## WARRANTY AND SUPPORT

Specific warranty details for this product are not provided in the available information. For warranty claims, technical support, or to inquire about replacement parts, please contact HAPPYGRILL directly through their official website or the retailer where the product was purchased.

Please have your model number (HG3021) and purchase information ready when contacting support.

