

- Manuals.plus /
- › Drmpry /
 - › Drmpry L1 Open Ear Headphones User Manual

Drmpry L1

Drmpry L1 Open Ear Headphones User Manual

Model: L1 | Brand: Drmpry

1. INTRODUCTION

The Drmpry L1 Open Ear Headphones are designed to provide a comfortable and high-quality audio experience while allowing you to remain aware of your surroundings. Featuring Bluetooth 5.4 connectivity, these lightweight earbuds are suitable for various activities, from daily commutes to sports and calls.



Figure 1: Drmpy L1 Open Ear Headphones and Charging Case

2. WHAT'S IN THE BOX

- Drmpy L1 Open Ear Headphones (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual

3. PRODUCT OVERVIEW

The Drmpy L1 headphones feature an ergonomic open-ear design for extended comfort and situational awareness. They are equipped with advanced audio technology for clear sound and Environmental Noise Cancellation (ENC) for improved call quality.



Figure 2: Lightweight design for comfort.

HYBRID ACTIVE NOISE REDUCTION, HD CALLS



Figure 3: Environmental Noise Cancellation (ENC) for clear calls.

Figure 4: Flexible ear hooks for secure fit.

4. SETUP: BLUETOOTH PAIRING

1. **Charge the Headphones:** Ensure your Drmpty L1 headphones are fully charged before first use. Place them in the charging case and connect the case to a power source using the provided USB cable. The indicator

lights on the case will show the charging status.

2. **Activate Pairing Mode:** Open the charging case. The headphones will automatically enter pairing mode. The indicator lights on the earbuds will flash, indicating they are ready to connect.
3. **Enable Bluetooth on Your Device:** On your smartphone, tablet, or computer, go to the Bluetooth settings and ensure Bluetooth is turned on.
4. **Select 'L1-OPEN':** In the list of available Bluetooth devices, locate and select 'L1-OPEN'. Once connected, you will hear a voice prompt confirming the connection, and the indicator lights on the earbuds will stop flashing.

RAPID ONE-STEP PAIRING

Take out the headphones and connect automatically



Figure 5: Seamless one-step Bluetooth pairing.

5. OPERATING INSTRUCTIONS

Touch Controls

The Drmpy L1 headphones feature intuitive touch controls on each earbud. Refer to the user manual for specific tap sequences for functions such as:

- Play/Pause music
- Adjust Volume
- Skip tracks (Next/Previous)
- Answer/End calls
- Activate Voice Assistant




Figure 6: Touch control functionality.

Charging


To charge the headphones, place them back into their charging case. The case itself can be charged via the USB-C port located at the bottom. A full charge of the carrying case takes approximately 1.8 hours, providing up to 40 hours of total listening time for the earbuds.

Long Endurance

Just Chargeing 0.2h



Headphone work 2h



Full charge condition

50H

Figure 7: Charging case with battery level indicators.

6. MAINTENANCE

Cleaning and Storage

Regularly clean your Drmpty L1 headphones with a soft, dry cloth to remove any dust or debris. Avoid using abrasive materials or harsh chemicals. Store the headphones in their charging case when not in use to protect them

and ensure they remain charged.

Water Resistance

While designed for active use, these headphones are not rated as fully waterproof and should not be submerged in water. They are resistant to light splashes and sweat, making them suitable for workouts. However, prolonged exposure to moisture should be avoided.



Figure 8: Designed to withstand splashes and sweat.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones do not turn on/pair.	Low battery; Bluetooth off; not in pairing mode.	Ensure headphones are charged. Verify Bluetooth is enabled on your device. Open the charging case to activate pairing mode. Manually select 'L1-OPEN' from your device's Bluetooth settings.
Poor sound quality.	Out of range; interference; low battery.	Move closer to your device. Avoid strong electromagnetic interference. Charge the headphones.
Cannot hear during calls.	Microphone blocked; volume too low.	Ensure microphone is clear. Adjust call volume on your device.
Headphones fall out during activity.	Improper fit.	Adjust the ear hooks to ensure a secure and comfortable fit around your ear.

8. SPECIFICATIONS

Feature	Detail
Model Name	L1

Feature	Detail
Brand	Drmpy
Connectivity Technology	Wireless (Bluetooth 5.4)
Bluetooth Range	20 Meters
Ear Placement	Open Ear
Audio Driver Type	Bone Conduction Driver
Noise Control	Adaptive Noise Cancellation (ENC)
Battery Life (Earbuds)	Up to 40 Hours (with charging case)
Carrying Case Charging Time	1.8 Hours
Control Type	Touch Control
Material	Acrylonitrile Butadiene Styrene (ABS)
Water Resistance Level	Not Water Resistant (Splash/Sweat Resistant)
Item Weight	5 ounces

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided on the product packaging or the official Drmpy website. Keep your purchase receipt as proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DK3D1C4T>

More documents and user manuals: <https://manuals.plus/>