

BOUSNIC RS2

Bousnic Dog Shock Collar Instruction Manual

BOUSNIC

PRODUCT OVERVIEW

The Bousnic Dog Shock Collar is an advanced training tool designed to help manage and train dogs weighing between 5 and 120 lbs. It features three humane training modes: adjustable beep (1-8 levels), vibration (1-16 levels), and safe shock (1-99 levels). This collar is engineered to assist in correcting undesirable behaviors and reinforcing positive ones, making your dog a well-behaved member of your household.

The system boasts an extended remote control range of up to 3300 feet (approximately 3/4 mile), allowing for effective training over long distances. Its dual-channel capability enables simultaneous training of two dogs. The receiver collar is IP67 waterproof, ensuring durability in various weather conditions, though the remote control is not waterproof and should be kept away from water. Both the receiver and remote feature impressive battery life, with the receiver lasting up to 15 days in working mode and the remote over a month on a single charge.



Image: The Bousnic Dog Shock Collar system, showing the remote control and the receiver collar.

SETUP GUIDE

Charging the Devices

- Before first use, fully charge both the remote control and the receiver collar.
- Use the provided charging cable to connect the devices to a USB power source.
- The charging indicator lights will show charging status and turn solid when fully charged.

Turning On/Off

- **Remote Control:** Press and hold the power button until the screen illuminates. To turn off, press and hold the power button until the screen turns off.
- **Receiver Collar:** Press and hold the power button on the receiver until it vibrates and the green light illuminates. To turn off, press and hold the power button until it beeps and the light turns off.

Fitting the Collar

Proper fit of the receiver collar is crucial for effective and safe operation. The collar strap is adjustable from 0 to 24 inches and can be trimmed to fit your dog's neck size. Ensure the contact points are making direct contact with your dog's skin. The collar should be snug enough to allow only one finger to fit between the strap and your dog's neck.

For dogs
5-120lbs

0-24 inches adjustable strap




Image: Visual guide for fitting the collar on dogs of different sizes, from 5 lbs to 120 lbs.

Note: If trimming the collar strap, use a lighter to carefully singe the cut end to prevent fraying.

OPERATING INSTRUCTIONS

Remote Control Overview

The remote control features a clear LCD screen displaying the current mode and level. It has dedicated buttons for each training mode (Beep, Vibration, Shock) and a dial to adjust intensity levels. An on/off switch provides instant response security, preventing accidental activation.

Security **on/off switch**

Prevent any misoperation



Image: Detailed view of the remote control's security on/off switch and mode selection buttons.

Training Modes

The Bousnic collar offers three distinct training modes to suit various training needs:

- **Beep Mode:** Provides an audible tone. Adjustable from 1 to 8 levels of intensity. Often used as an initial warning or for positive reinforcement.
- **Vibration Mode:** Delivers a gentle vibration. Adjustable from 1 to 16 levels of intensity. Useful for getting your dog's attention without a physical sensation.
- **Safe Shock Mode:** Emits a static correction. Adjustable from 1 to 99 levels of intensity. Designed to be safe and humane, providing a deterrent for unwanted behaviors. Always start at the lowest level and increase gradually if necessary.

3 Effective Training Modes

Professional & Humane




Image: Illustration of the three training modes: Beep, Vibration (Shake), and Safe Shock, with their respective adjustable levels.

Remote Control Range

The Bousnic Dog Training Collar offers an impressive remote control range of up to 3300 feet (approximately 3/4 mile). This extended range allows for effective training in open outdoor environments, providing ample freedom for your pet while maintaining control.

Updated 3300Ft

Remote Control Range

Train Your Dog Far Away



Image: Depiction of the 3300ft remote control range, showing a dog and handler at a distance.

CARE AND MAINTENANCE

Waterproofing

The receiver collar is designed with an IP67 waterproof rating, meaning it can withstand submersion in water up to 1 meter for 30 minutes. This allows your dog to swim or play in the rain without damaging the collar. However, it is crucial to remember that the remote control is *not* waterproof and must be kept away from water to prevent damage.

IP67

Waterproof Receiver Collar

Enjoy Water Freely




Image: A dog swimming while wearing the Bousnic waterproof receiver collar.

Battery Life

The Bousnic e-collar system is equipped with long-lasting rechargeable batteries. The receiver's battery can operate for up to 15 days on a single charge in working modes, while the remote control can last for over one month. Regular charging ensures consistent performance for your training sessions.

Long-Lasting Battery Life

Say Good Bye to frequently charge



Image: The Bousnic remote and receiver, highlighting their extended battery life with indicators for 15 days working time and 2 months standby time.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Collar not responding to remote	Low battery; Not paired; Out of range; Incorrect mode/level	Charge both devices; Re-pair the devices; Move closer to the dog; Check mode and level settings.
No static correction (shock)	Poor contact with skin; Level too low; Contact points dirty/damaged	Adjust collar fit; Increase shock level gradually; Clean contact points; Replace contact points if damaged.
Remote screen is blank	Low battery; Remote is off	Charge the remote; Turn on the remote using the power button.
Collar light not on	Low battery; Collar is off	Charge the collar; Turn on the collar using the power button.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Name	RS2
Item Weight	10.6 ounces (0.3 Kilograms)
Item Dimensions (LxWxH)	6.61 x 5.51 x 0.1 inches
Batteries	2 Lithium Ion batteries (included)
Color	Black
Collar Strap Adjustment	0 to 24 inches
Waterproof Rating (Receiver)	IP67
Training Modes	Beep (1-8 levels), Vibration (1-16 levels), Safe Shock (1-99 levels)
Remote Control Range	Up to 3300 feet
Target Dog Weight	5-120 lbs

WARRANTY AND SUPPORT

The Bousnic Dog Shock Collar comes with a 1-Year Warranty. This warranty covers manufacturing defects and ensures the quality and reliability of your product.

For any questions, technical assistance, or warranty claims, please contact Bousnic customer support. Refer to the product packaging or the official Bousnic website for the most current contact information.

© 2024 BOUSNIC. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What type of charger cord do I need for the BOUSNIC RS2 shock collar if I didn't receive one?

The BOUSNIC RS2 Dog Shock Collar uses a provided charging cable to connect the devices (remote control and receiver collar) to a USB power source. The manual does not specify the exact type of...

[Read full answer](#)

I didn't receive a charging cable for the BOUSNIC RS2 collar; how can I purchase one?

The BOUSNIC RS2 Dog Shock Collar manual states, "Use the provided charging cable to connect the devices to a USB power source." Since you did not receive one, you should contact BOUSNIC customer support...

[Read full answer](#)