

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Deolme](#) /

› [Deolme Grey Rocker Recliner Chair User Manual](#)

Deolme 52939b22-553c-4a04-845f-6a051190c1e7

Deolme Grey Rocker Recliner Chair User Manual

Model: 52939b22-553c-4a04-845f-6a051190c1e7

1. INTRODUCTION

Thank you for choosing the Deolme Grey Rocker Recliner Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner. Please read it thoroughly before use and retain it for future reference.

This versatile chair combines the comfort of a recliner with the soothing motion of a rocker and glider, enhanced with massage and heat functions. Its ergonomic design and durable faux leather upholstery ensure a comfortable and long-lasting experience.

2. SAFETY INFORMATION

- Always ensure the chair is placed on a flat, stable surface.
- Do not allow children to play on or around the recliner unsupervised.
- Keep hands and feet clear of moving parts during reclining or rocking.
- Do not exceed the maximum weight capacity of 300 lbs.
- Unplug the chair from the power outlet when not in use or before cleaning.
- Avoid placing the chair near heat sources or in direct sunlight to prevent material degradation.
- This chair is not recommended for patients who have recently undergone or are about to undergo surgery.

3. PRODUCT FEATURES

- **3-in-1 Functionality:** Recline, 360-degree swivel, and rock/glide motion.
- **Massage and Heat:** Integrated massage with 8 vibrating points, 5 modes, 2 intensity options, and a lumbar heating function with a 10-minute auto-shutdown timer.
- **Durable Upholstery:** Soft, durable, waterproof, and oilproof faux leather for easy cleaning.
- **Ergonomic Design:** High-density foam padding and solid wood/metal frame for full-body support and longevity.
- **Independent Controls:** Footrest and backrest can be adjusted separately (manual recline from 110° to 150°).
- **Convenient Storage:** Armrests equipped with side pockets for small items.



Figure 3.1: The Deolme Grey Rocker Recliner Chair, highlighting its integrated massage and heat zones.

4. SETUP AND ASSEMBLY

The Deolme Recliner Chair requires assembly. Please ensure all components are present before beginning. Assembly typically involves attaching the backrest to the base and connecting any electrical components for massage and heat functions.

- Carefully unpack all parts and lay them out on a soft, clean surface to prevent scratches.
- Refer to the included assembly instructions for detailed, step-by-step guidance.
- Ensure all connections are secure before using the chair.

NURSERY APPROVED

Rigorously tested for safety



Figure 4.1: Product dimensions and weight capacity for assembly planning.

5. OPERATING INSTRUCTIONS

5.1 Reclining Function

The recliner features a manual reclining mechanism. To recline:

1. Locate the concealed lever on the side of the chair (typically on the right side when seated).
2. Pull the lever to activate the integrated footrest.
3. Apply gentle body pressure to the backrest to adjust it to your desired angle, from 110° to 150°. The footrest and backrest operate independently.
4. To return to the upright position, push the footrest down with your legs and lean forward.

ROCKING FUNCTION



Pull the handle to open the footrest



Reading



Watching TV



Napping time

Figure 5.1: Demonstrating the rocking function and the lever to open the footrest.

5.2 Swivel and Rocking/Gliding Function

The chair is equipped with a sturdy swivel metal base allowing for a smooth 360-degree rotation. It also provides a 30-degree gliding function for gentle back-and-forth motion.

- To swivel, simply rotate the chair in any direction.
- To rock or glide, gently push off the floor with your feet to initiate the motion.

BUILT FOR COMFORT



◆ *Glide back and forth*



◆ *Swivel a full 360 degrees*



◆ *Kick up your feet*



◆ *Lay back and relax*

Figure 5.2: Visual representation of the chair's glide, swivel, and recline capabilities.

5.3 Massage and Heat Functions

The integrated massage and heat system provides targeted comfort. Use the included remote control to operate these features.

- **Power Button:** Turns the massage and heat functions on/off.
- **Mode Selection:** Cycle through 5 adjustable massage modes.
- **Intensity Control:** Choose between 2 intensity options for vibration.
- **Heat Mode:** Activates the lumbar heating function. The heat will automatically shut off after 10 minutes.
- **Timer Options:** Select from 3 timer settings for massage duration.
- **Part Selection:** Target specific areas with 8 vibrating points.



Figure 5.3: Overview of the adjustable massage and heat features with the remote control.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your Deolme Recliner Chair.

- **Cleaning Faux Leather:** For general cleaning, wipe the surface with a soft, damp cloth. For tougher stains, use a mild soap solution and wipe dry immediately. Avoid abrasive cleaners or solvents.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub.
- **Dusting:** Regularly dust the chair with a soft, dry cloth.
- **Mechanism Care:** Periodically check all bolts and screws to ensure they are tight. Do not lubricate the reclining mechanism unless specifically instructed by the manufacturer.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading and cracking of the faux leather.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not recline smoothly.	Mechanism obstruction or loose connection.	Check for any objects obstructing the mechanism. Ensure all assembly bolts are tightened.
Massage/Heat function not working.	Power cord unplugged, remote battery low, or internal connection issue.	Ensure the power cord is securely plugged into a working outlet. Check remote control batteries. If issues persist, contact customer support.
Chair wobbles or feels unstable.	Loose assembly bolts or uneven floor.	Tighten all assembly bolts. Ensure the chair is on a level surface.
Squeaking noise during rocking/swiveling.	Friction in the base mechanism.	Ensure the base is clean and free of debris. Do not apply lubricants unless specified by the manufacturer.

8. SPECIFICATIONS

Attribute	Detail
Brand	Deolme
Model Number	52939b22-553c-4a04-845f-6a051190c1e7
Color	Grey
Product Dimensions (D x W x H)	29.3" x 36.2" x 40.5"
Maximum Weight Capacity	300 Pounds
Material	Faux Leather, High-Density Foam, Solid Wood, Metal Frame
Reclining Angle	110° to 150° (manual)
Swivel Angle	360°
Gliding Function	30° back and forth
Massage Points	8 vibrating points
Massage Modes	5 adjustable modes
Massage Intensity	2 options
Heat Function	Lumbar heating, 10-minute auto-shutdown
Item Weight	97 pounds
Recommended Uses	Relaxing, Gaming, Reading, Watching TV, Napping

9. WARRANTY AND SUPPORT

For information regarding warranty coverage, product support, or to purchase replacement parts, please refer to the documentation included with your purchase or contact Deolme customer service directly. Contact details are typically provided on the product packaging or the manufacturer's official website.

Please have your model number (52939b22-553c-4a04-845f-6a051190c1e7) and purchase date ready when contacting

support.

© 2024 Deolme. All rights reserved.