Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Treocho OD2402-PK

Treocho Kids Desk and Chair Set Instruction Manual

Model: OD2402-PK
Brand: Treocho

1. Important Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Adult Assembly Required:** This product contains small parts and requires adult assembly.
- **Choking Hazard:** Keep all small parts and packaging materials away from children during assembly.
- **Stability:** Ensure all fasteners are securely tightened before use. Periodically check and re-tighten fasteners as needed.
- **Weight Limit:** Do not allow children to stand on the desk or chair.
- **Safe Design:** The desk features arc-shaped table corners to help prevent collisions.
- **Material Safety:** Constructed from environmentally friendly engineered wood and safe paint.

2. Package Contents

Verify that all components and hardware are present before beginning assembly. Refer to the detailed step-by-step instructions included in the packaging for a complete list of numbered accessories.



Image 1: Overview of the Treocho Kids Desk and Chair Set.

3. Setup (Assembly Instructions)

Assembly of the Treocho Kids Desk and Chair Set is designed to be straightforward with detailed instructions provided in the product packaging. All accessories are numbered to facilitate quick and easy assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Match each component with its corresponding number as indicated in the assembly guide.
3. **Follow Step-by-Step Instructions:** Adhere strictly to the provided assembly manual. Do not skip steps.
4. **Secure Fasteners:** Ensure all screws, bolts, and connectors are tightened firmly. Avoid over-tightening to prevent damage.
5. **Final Check:** Once assembled, gently shake the desk and chair to confirm stability before allowing a child to use it.




Image 2: Product dimensions for reference during assembly.

4. Operating Instructions

The Treocho Kids Desk and Chair Set is designed for children's study and creative activities.

- **Desk Usage:** The desktop provides a stable surface for writing, drawing, and other activities.
- **Storage and Organization:** Utilize the desktop partition for holding books and the two cloth drawers for storing pencils, crayons, and other school supplies.
- **Chair Usage:** The accompanying chair is designed for comfortable seating during desk activities. Ensure the child sits properly with both feet on the floor if possible, or on a footrest if needed.



Image 3: Key features of the desk and chair set, highlighting storage and safety elements.

5. Maintenance and Care

Proper care will extend the life and appearance of your Treocho Kids Desk and Chair Set.

- **Cleaning the Desktop:** The smooth desktop can be cleaned with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals.
- **Cleaning Cloth Drawers:** The detachable cloth drawers can be spot cleaned or hand washed as needed. Allow to air dry completely before reinserting.
- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if any looseness is detected.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or damage to the wood finish.

6. Troubleshooting

If you encounter any issues with your desk and chair set, refer to the following common solutions:

- **Wobbling Desk/Chair:** Check all assembly points and ensure screws are fully tightened. Uneven flooring can also cause wobbling; try moving the set to a level surface.
- **Missing Parts:** If any parts are missing upon unboxing, please contact Treocho customer support immediately for assistance.
- **Difficulty with Drawers:** Ensure the cloth drawers are inserted correctly and are not overfilled.

7. Specifications

Feature	Detail
Brand	Treocho
Model Number	OD2402-PK
Material	Engineered Wood
Product Dimensions (L x W x H)	32.7 x 17.9 x 27.6 inches
Item Weight	42.3 pounds
Shape	Rectangular
Color	Pinky Beige

8. Warranty Information

Specific warranty details for the Treocho Kids Desk and Chair Set are not provided in this manual. Please refer to the product packaging or contact Treocho customer support for information regarding warranty coverage.

9. Support

For further assistance, missing parts, or any questions not covered in this manual, please contact Treocho customer service. Contact information can typically be found on the product packaging or the official Treocho website.

© 2025 Treocho. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DK4JWN3P

More documents and user manuals: **https://manuals.plus/**