

[Manuals.plus](#) /

› [ICEBOX](#) /

› ICEBOX 1.7 Cu. Ft. Compact Refrigerator User Manual (Model IBCR17BLS)

ICEBOX IBCR17BLS

ICEBOX 1.7 Cu. Ft. Compact Refrigerator

USER MANUAL (MODEL: IBCR17BLS)

Brand: ICEBOX

Introduction

This manual provides comprehensive instructions for the safe and efficient use of your new ICEBOX 1.7 Cu. Ft. Compact Refrigerator. Please read all instructions carefully before installation and operation. Retain this manual for future reference.

The ICEBOX compact refrigerator is designed for cooling and storing food and beverages. It features a single door, a small freezer compartment, and uses R600a refrigerant. This appliance is ENERGY STAR certified, indicating its energy efficiency.



Image: Front view of the ICEBOX 1.7 Cu. Ft. Compact Refrigerator in Blush Red.

Safety Information

WARNING: To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the refrigerator.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance must be properly installed and located in accordance with the Installation Instructions before it is used.
- Do not allow children to climb, stand, or hang on the shelves in the refrigerator. They could damage the refrigerator and seriously injure themselves.
- To protect against electric shock, do not place cord, plugs, or appliance in water or other liquid.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.

- The refrigerant R600a is flammable. Handle with care during transportation and installation to avoid damaging the refrigeration circuit.

Product Features

- **Compact Design:** Space-saving mini refrigerator suitable for dorm rooms, offices, garages, and apartments.
- **Energy Efficient:** Uses minimal energy (70 watts) and R600a refrigerant, which is eco-friendly. ENERGY STAR certified.
- **Interior Storage:** Features a full-width slide-out glass shelf for flexible organization.
- **Door Storage:** Includes one full-width and one half-width door shelf, accommodating 1-liter and tall bottles.
- **Freezer Compartment:** Equipped with a full-width freezer compartment and an ice cube tray.
- **Adjustable Thermostat:** Allows for precise temperature control.
- **Reversible Door:** Offers flexible placement options.
- **Adjustable Leveling Legs:** Ensures stability on uneven surfaces.
- **Manual Defrost:** Designed for ease of use and maintenance.

1 FULL-WIDTH
SLIDE-OUT GLASS SHELF

1 FULL-WIDTH & 1 HALF-WIDTH
DOOR STORAGE SHELF

Accommodates 1 Liter & Tall Bottles



Setup

1. Unpacking

- Remove all packaging materials, including the foam base and adhesive tape.
- Inspect the refrigerator for any shipping damage. If damage is found, do not plug in the unit and contact customer support.
- Clean the interior and exterior of the refrigerator with a damp cloth before use.

2. Placement

- Place the refrigerator on a flat, stable surface strong enough to support the unit when fully loaded.
- Allow at least 4 inches (10 cm) of space around the back and sides of the refrigerator for proper air circulation.
- Avoid placing the refrigerator in direct sunlight or near heat sources (e.g., oven, radiator).
- The reversible door design allows you to change the door swing direction to suit your space. Refer to the detailed instructions in the full PDF manual for this procedure.

3. Leveling

- Adjust the leveling legs at the bottom of the refrigerator to ensure the unit is stable and level. This helps reduce vibration and ensures proper door sealing.

4. Initial Power-On

- After placement, wait at least 2-4 hours before plugging the refrigerator into a grounded electrical outlet. This allows the refrigerant to settle.
- Set the thermostat to the desired cooling level.
- Allow the refrigerator to operate for several hours empty to reach its set temperature before storing food.

Operating Instructions

Temperature Control

Your refrigerator is equipped with an adjustable thermostat control located inside the unit. The dial typically ranges from 0 (Off) to 7 (Coldest).

- To increase cooling, turn the dial towards a higher number.
- To decrease cooling, turn the dial towards a lower number.
- Setting the dial to '0' will turn off the cooling function.
- The ideal setting depends on ambient temperature and how often the door is opened. Start with a medium setting (e.g., 4) and adjust as needed.

ADJUSTABLE THERMOSTAT CONTROL

Reversible Door

Space Saving Flat Back Design

Adjustable Leveling Legs



Image: Close-up of the adjustable thermostat dial, showing settings from 0 to 7.

Food Storage

- Utilize the full-width slide-out glass shelf for main storage.
- The door shelves are suitable for bottles, cans, and smaller items.
- The freezer compartment is designed for making ice and storing small frozen items. An ice cube tray is included.

INTERIOR STORAGE OPTIONS

Optimal Storage Capacity



Image: Interior view of the refrigerator with the freezer compartment visible, containing an ice cube tray and other items.

Maintenance

Cleaning Your Refrigerator

- Always unplug the refrigerator before cleaning.
- Wash the interior with a solution of mild detergent and warm water. Use a soft cloth or sponge.
- Clean the exterior with a mild detergent and warm water. Dry thoroughly with a soft cloth.
- Do not use harsh chemicals, abrasive cleaners, or scouring pads, as they can damage surfaces.
- Regularly wipe down the door gasket to ensure a tight seal.

Manual Defrosting

This refrigerator features a manual defrost system. Frost will accumulate on the freezer compartment walls. To maintain efficiency and prevent excessive frost buildup:

- Defrost the unit when frost accumulation reaches about 1/4 inch (6 mm) thick.
- Turn the thermostat to '0' (Off) and unplug the refrigerator.
- Remove all food items from the freezer and refrigerator compartments. Place frozen items in a cooler to keep them cold.
- Leave the refrigerator door open to allow frost to melt naturally. You can place towels at the bottom to absorb water.
- Do not use sharp objects or heating devices to remove frost, as this can damage the cooling system.
- Once all frost has melted, clean and dry the interior thoroughly.
- Plug the refrigerator back in and reset the thermostat to your desired setting. Allow it to cool for a few hours before returning food.

Troubleshooting

Before contacting customer service, review this section for common issues and solutions.

Problem	Possible Cause	Solution
Refrigerator does not operate.	Not plugged in; circuit breaker tripped; thermostat set to '0'.	Ensure plug is secure; reset circuit breaker; set thermostat to a number between 1 and 7.
Temperature is not cold enough.	Thermostat setting too low; door opened too frequently; warm food placed inside; poor air circulation.	Increase thermostat setting; minimize door openings; allow hot food to cool before storing; ensure adequate space around unit.
Excessive frost buildup in freezer.	Door not sealed properly; frequent door openings; high humidity.	Check door gasket for damage or obstructions; reduce door openings; perform manual defrost as needed.
Unusual noises.	Refrigerator not level; items rattling inside; normal compressor operation.	Adjust leveling legs; reposition items; gurgling/hissing sounds are normal for refrigerant.

Specifications

Feature	Detail
Model Number	IBCR17BLS
Product Dimensions (D x W x H)	18.5" x 17.5" x 19.7"
Capacity	1.7 Cubic Feet
Configuration	Compact Freezer-On-Bottom
Defrost System	Manual
Voltage	120 Volts
Refrigerant	R-600A
Item Weight	34.2 Pounds
Annual Energy Consumption	201 Kilowatt Hours Per Year
Shelf Type	Glass
Number of Doors	1
Power Source	Corded Electric
Certification	ENERGY STAR, UL



Image: Diagram showing the dimensions (18.5"D x 17.5"W x 19.7"H) of the ICEBOX compact refrigerator and its four available colors.

Official Product Video

Your browser does not support the video tag.

Video: An official overview of the ICEBOX 1.7 cu. ft. compact refrigerator, demonstrating its features and size. This video is provided by Equity Brands, the manufacturer.

Warranty and Support

Your ICEBOX 1.7 Cu. Ft. Compact Refrigerator is covered by a **4 Year Limited Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or replacement parts, please contact ICEBOX customer service. Refer to the contact information provided in your product packaging or visit the official ICEBOX website for assistance.

What's in the Box:

- 1 x ICEBOX 1.7 Cu. Ft. Compact Refrigerator

© 2026 ICEBOX. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question