

[Manuals.plus](#) /

› [KIWI design](#) /

› KIWI design G4 Max Extended Controller Grips User Manual for Meta Quest 3/3S (Model QG07)

KIWI design QG07

KIWI design G4 Max Extended Controller Grips User Manual

Model: QG07 | Compatible with Meta Quest 3/3S

INTRODUCTION

The KIWI design G4 Max Extended Controller Grips are engineered to enhance your virtual reality experience by providing superior protection, improved ergonomics, and convenient functionality for your Meta Quest 3/3S Touch Plus Controllers. These grips are designed to offer a secure and comfortable hold, especially for users with larger hands, ensuring stable signal transmission and quick battery access.



Image: KIWI design G4 Max Extended Controller Grips attached to Meta Quest 3 controllers, held by a user in VR.

WHAT'S IN THE BOX

Your KIWI design G4 Max Extended Controller Grips package includes the following components:

- 2 x G4 Max Extended Controller Grips
- 2 x Knuckle Straps (pre-installed)
- 2 x Wrist Straps (pre-installed)
- Replacement Battery Access Tabs (various sizes)

Image: Contents of the KIWI design G4 Max package, including two controller grips, replacement tabs, and a manual.

SETUP & INSTALLATION

Follow these steps to properly install your KIWI design G4 Max Extended Controller Grips:

1. **Prepare your Meta Quest 3/3S Controllers:** Remove the original battery cover and any existing wrist straps from your controllers.
2. **Insert the Controller:** Carefully slide your Meta Quest 3/3S controller into the G4 Max grip. Ensure the controller is fully seated and aligned with the grip's internal structure.
3. **Secure the Battery:** The G4 Max grips feature a convenient access door for battery replacement. Insert your AA battery (not included) and ensure the pull-tab is positioned correctly for easy removal. Close the battery access door securely.
4. **Adjust Knuckle and Wrist Straps:** The knuckle straps are integrated with padded foam for comfort. Adjust the straps to fit your hand size, ensuring a snug but comfortable fit. The wrist straps can also be adjusted for added security.

Your browser does not support the video tag.

Video: Installation guide for KIWI Design G4 Max Controller Grips, demonstrating how to attach the grips and access the battery compartment.

Comfortable Grip

Extended handle for larger hand sizes





The image shows a close-up of a black, textured controller grip. A blue double-headed vertical arrow indicates the length of the extended handle, which is labeled as 1.7 inch. The grip has a braided cable attached to it, and a small circular button is visible on the side. The background is white.

1.7inch

Image: KIWI design G4 Max Extended Controller Grip showing the 1.7-inch extended handle for larger hands.

Quick Battery Replacement

Instant Swap through the Access Door



*Supports AA batteries, but not official wireless rechargeable batteries or charging docks.

Image: Hands demonstrating quick battery replacement using the pull-tab and access door on the KIWI design G4 Max grip.

Your browser does not support the video tag.

Video: Overview of the G4 Max Extended Controller Grips for Quest 3/3S, highlighting key features and benefits.

OPERATING INSTRUCTIONS

The G4 Max grips are designed for optimal performance during VR gameplay:

- **Secure Hold:** The anti-slip and sweat-diversion texture ensures a firm grip even during intense gaming sessions. The padded knuckle straps provide exceptional comfort and prevent the controllers from slipping.
- **Precision Control:** The translucent silicone material of the grips ensures stable signal transmission, allowing for precise and responsive control in every movement.
- **Extended Comfort:** The 1.7-inch (4.3 cm) extended handle maximizes stability and comfort, especially beneficial for users with larger hands, reducing fatigue during long play sessions.

Better Grips and Secure Controllers



Image: User holding Meta Quest 3 controllers with KIWI design G4 Max grips, demonstrating a secure and comfortable hold.

Precision Control

Translucent frills keep signals steady



Image: Hand holding a Meta Quest 3 controller with KIWI design G4 Max grip, showing translucent frills for steady signal transmission.



Image: Close-up of the anti-slip and thickened surface texture on the KIWI design G4 Max grip.



Image: Hand wearing the KIWI design G4 Max grip, highlighting the silicone built-in sponge design for enhanced comfort.



Image: User adjusting the wrist strap on the KIWI design G4 Max grip for a comfortable and secure fit.

MAINTENANCE

To ensure the longevity and hygiene of your KIWI design G4 Max Extended Controller Grips, follow these maintenance guidelines:

- **Cleaning:** Wipe the silicone grips with a soft, damp cloth. Use mild soap if necessary, and ensure they are completely dry before reattaching to your controllers.
- **Storage:** Store the grips in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Inspection:** Periodically check the grips and straps for any signs of wear or damage. Replace if necessary to maintain optimal performance and safety.

TROUBLESHOOTING

If you encounter any issues with your KIWI design G4 Max Extended Controller Grips, consider the following:

- **Tracking Issues:** Ensure the translucent silicone is properly aligned and not obstructing any sensors on your Meta Quest 3/3S controllers. Slight adjustments may be needed.
- **Loose Fit:** Re-adjust the knuckle and wrist straps to achieve a tighter fit. The elastic band allows for quick and easy adjustments.
- **Battery Access:** If the battery access door feels stiff, ensure the pull-tab is correctly positioned underneath the battery for smooth operation.

SPECIFICATIONS

Product Dimensions	7.28 x 4.13 x 3.15 inches
Item Weight	9.5 ounces

ASIN	B0DK4LG7T4
Item Model Number	QG07
Brand	KIWI design
Compatible Devices	Meta Quest 3, Meta Quest 3S
Color	Black

WARRANTY & SUPPORT

KIWI design products are backed by a manufacturer's warranty. For detailed warranty information, product support, or assistance with any issues, please visit the official KIWI design website or contact their customer service directly. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question