Treocho KT2401-WH

Treocho Wooden Kids Table and Chair Set User Manual

Model: KT2401-WH

1. Introduction

Thank you for choosing the Treocho Wooden Kids Table and Chair Set. This versatile 2-in-1 activity table is designed to provide a dedicated space for children to engage in various activities such as building, reading, drawing, and playing. It features a reversible tabletop, integrated storage, and a paper roll dispenser to foster creativity and organization. This manual provides essential information for safe assembly, operation, and maintenance of your product.

2. Safety Information

- **Adult Assembly Required:** This product contains small parts and requires adult assembly. Keep small parts away from children before and during assembly.
- **Supervision:** Always supervise children when they are using the table and chairs.
- **Weight Limit:** Do not exceed the recommended weight limit for the chairs and table.
- **Stability:** Ensure the table and chairs are placed on a flat, stable surface to prevent tipping.
- **Choking Hazard:** Small parts, such as building blocks or crayons, can be choking hazards. Ensure children are old enough to use these items safely.
- **Maintenance:** Regularly check all fasteners and connections to ensure they are tight and secure.

3. Package Contents

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.



Image: All components of the Treocho Kids Table and Chair Set laid out for assembly.

- Tabletop (1)
- Table Legs (4)
- Chair Seats (2)
- Chair Backrests (2)
- Chair Legs (8)
- Fabric Storage Drawer (1)
- Paper Roll Dispenser Rod (1)
- Hardware Pack (screws, bolts, tools)

4. Assembly Instructions

Assembly of the Treocho Kids Table and Chair Set is designed to be straightforward. Please follow the step-by-step instructions provided in the included manual. All components are clearly numbered for your convenience. For a visual guide to the assembly process, please refer to the video below:

Video: Assembly and feature overview of the Treocho Kids Activity Table.

Once assembled, the table and chairs will appear as shown:



Image: Fully assembled Treocho Wooden Kids Table and Chair Set.

5. Operating Instructions

5.1 Reversible Tabletop

The tabletop is designed for versatility, offering two distinct surfaces for different activities:

- **Building Baseplate Side:** One side features a green building baseplate, compatible with most major building block brands, providing a stable surface for construction play.
- **Blackboard Side:** The reverse side is a smooth blackboard surface, ideal for drawing with chalk or using as a flat surface for reading and other activities.

To reverse the tabletop, carefully lift it from the table frame, flip it to the desired side, and gently place it back into the frame. Ensure it is securely seated before use.



Image: Reversible tabletop showing both the building baseplate and blackboard surfaces.



Image: Examples of the table's 4-in-1 activity modes.

5.2 Storage Drawers

The table includes a large fabric storage drawer located beneath the tabletop. This drawer is designed to hold toys, building blocks, art supplies, and other items, helping to keep the play area tidy. The drawer can be pulled out from either side of the table for easy access.



Image: Integrated fabric storage drawer.

5.3 Paper Roll Dispenser

A paper roll dispenser is integrated into the table frame, allowing for continuous drawing and painting activities. Simply load a standard paper roll onto the rod and pull the paper across the tabletop for an instant art canvas.




Image: Paper roll dispenser feature.

6. Maintenance

- **Cleaning:** Wipe the table and chairs with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish. For the blackboard surface, use a damp cloth to wipe away chalk residue.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Tighten as necessary to maintain stability.
- **Storage:** Store the table and chairs in a dry environment, away from extreme temperatures or humidity, to prevent warping or damage.

7. Troubleshooting

- **Table/Chair Wobbles:** Ensure all screws and bolts are securely tightened. Check that the table and chairs are on a level surface.
- **Tabletop Difficult to Flip:** Ensure no debris is lodged in the tabletop grooves. Lift evenly when flipping.
- **Drawer Sticks:** Check for obstructions in the drawer runners. Ensure the fabric drawer is not overfilled.

8. Specifications

Brand	Treocho
Model Number	KT2401-WH
Product Dimensions	25.59 x 25.59 x 23.22 inches
Item Weight	34.2 pounds
Material	Engineered Wood

Color	White
Features	Reversible Tabletop (Building Baseplate/Blackboard), Storage Drawer, Paper Roll Dispenser




Image: Product dimensions.

9. Warranty and Customer Support

For warranty information or any questions regarding your Treocho Wooden Kids Table and Chair Set, please refer to the product packaging or contact Treocho customer support directly. Our dedicated team is available to assist you with any inquiries or concerns you may have.