

Linkidea SHC36-01

Linkidea Wall Mounted Electric Shaver and Hair Clipper Holder SHC36-01 Instruction Manual

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Linkidea Wall Mounted Electric Shaver and Hair Clipper Holder, model SHC36-01. Please read this manual thoroughly before installation and retain it for future reference.

SAFETY INFORMATION

- Ensure the installation surface is clean, dry, and smooth for optimal adhesion.
- Do not overload the holder beyond its intended capacity.
- Keep out of reach of children to prevent accidental detachment or injury.
- Avoid installing near heat sources or in areas with extreme temperature fluctuations.

PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- 1 x Linkidea Electric Shaver and Hair Clipper Holder
- Self-adhesive backing (pre-applied or separate)
- Optional: Mounting screws and anchors (if applicable for alternative mounting)




Image: Package contents showing the holder, adhesive strip, and optional mounting screws.

SETUP AND INSTALLATION

1. Choose an Appropriate Location

Select a smooth, clean, and dry surface for installation. The holder is designed for optimal adhesion on surfaces such as:

- Metal
- Glass
- Marble
- Mirror
- Ceramic Tile
- Plywood

Avoid rough or uneven surfaces such as painted walls, cement walls, or brick walls, as adhesion may be compromised.

Applicable Wall Type

Applicable

Smooth, shiny surface



Metal



Glass



Marble



Mirror



Ceramic Tile



Plywood

Not applicable


Rough, uneven surfaces



Painting Wall



Cement Wall



Brick Wall

Image: Visual guide illustrating suitable and unsuitable wall types for installation.

2. Surface Preparation

1. Clean the chosen surface thoroughly with a mild cleaner and dry it completely.
2. Ensure there is no dust, grease, or moisture on the surface.

3. Installation Steps (Self-Adhesive)

1. Carefully peel off the protective film from the adhesive backing on the holder.
2. Align the holder to the desired position on the prepared surface.
3. Press firmly across the entire surface of the holder for at least 30 seconds to ensure strong adhesion.
4. For best results, wait 24 hours before placing any items in the holder to allow the adhesive to fully cure.

4. Dimensions

The holder dimensions are 12.2 inches (31 cm) in length, 8.27 inches (21 cm) in height, and 1.77 inches (4.5 cm) in depth. Ensure adequate space is available for installation.




Image: Dimensional drawing of the holder, indicating length, height, and depth.

OPERATING INSTRUCTIONS

Using the Holder

Once installed, the holder provides dedicated slots for organizing your electric shavers and hair clippers. Simply slide your device into an available slot. The design ensures devices are held securely while allowing for easy access.



Image: The holder with various electric shavers and clippers in place, demonstrating its organizational function.



Image: The holder integrated into a bathroom setting, demonstrating its practical application.

Compatibility

The Linkidea holder is designed to be compatible with a wide range of electric shaver and hair clipper models, including but not limited to:

- Philips Norelco Shaver 3600, Shaver 2400, Series 9, Series 7, Series 2, 5000x
- Braun Series 6, Series 7, Series 8, Series 9
- Panasonic Arc 6, Arc 5, Arc 4, Arc 3, Twin-X
- MANSCAPED Electric Shaver
- Wahl 7063, 7064, 7061-100
- MAX-T 7109 Adapter, RMS8101, RMS8101A-Black

Compatible Type



Shaver 2400



Norelco Series 7



Series 3



Series 5



Arc 6



Arc 5

Image: Examples of compatible electric shaver models.

MAINTENANCE

Cleaning the Holder

To maintain the appearance and hygiene of your holder, wipe it regularly with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these may damage the plastic material or the adhesive.

TROUBLESHOOTING

Holder Not Adhering Properly

- **Issue:** The holder is not sticking to the wall or is falling off.
- **Solution:** Ensure the installation surface was thoroughly cleaned and dried before application. The surface must be smooth and non-porous. Re-apply to a suitable, clean surface, pressing firmly for an extended period, and allow 24 hours for the adhesive to set before use.

Devices Do Not Fit

- **Issue:** An electric shaver or hair clipper does not fit into the holder slots.
- **Solution:** While the holder is designed for broad compatibility, some larger or unusually shaped devices may not fit. Refer to the compatibility list and product dimensions to ensure your device is suitable.

SPECIFICATIONS

Brand	Linkidea
Model Number	SHC36-01
Material	Plastic
Color	Black
Product Dimensions (L x W x H)	12.2 x 8.27 x 1.77 inches (31 x 21 x 4.5 cm)
Item Weight	8.8 ounces (249 grams)
Special Feature	Durability, Sturdy

WARRANTY AND SUPPORT

Warranty Information

This Linkidea product is covered by a **1-year manufacturer’s warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

Customer Support

For technical assistance, warranty claims, or any questions regarding your Linkidea product, please contact our customer support team through the retailer's platform where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question