Skil SFS0001

SKIL Table Saw Folding Stand (SFS0001) Instruction Manual

Model: SFS0001

1. Introduction

This manual provides detailed instructions for the safe and efficient setup, operation, and maintenance of your SKIL Table Saw Folding Stand. Please read this manual thoroughly before assembly and use to ensure proper functionality and safety.

The SKIL Folding Saw Stand is designed for use with the SKIL 8-1/4 In. Table Saw (TS6308-00) and SKIL 5-1/2 In. Flooring Saw. Its folding design allows for quick, tool-free setup and offers two height positions for various working conditions. A quick-install dust bag is also included to help maintain a clean workspace.

2. Setup and Assembly

2.1. Unboxing and Initial Inspection

Carefully open the packaging and remove all components. Inspect all parts for any damage that may have occurred during shipping. Ensure all listed components are present before proceeding with assembly.



Figure 1: The SKIL Table Saw Folding Stand in its compact, folded state, ready for transport or storage.

2.2. Component Identification

The packaging includes various components essential for the stand's operation and safety. These typically include:

- Blade Guards (if included with the saw, not the stand itself)
- Anti-Kickback Guard / Riving Knife (if included with the saw, not the stand itself)
- Push Stick (for safe material feeding)
- Dust Collection Elbow (for connecting to a dust collection system)
- Miter Adjustment Tool (if included with the saw, not the stand itself)
- Quick-Install Dust Bag (attaches to the stand for debris collection)

2.3. Unfolding the Stand Legs

To unfold the stand, locate the red buttons on the legs. Press these buttons and extend the legs outwards until they lock into place. Ensure all four legs are fully extended and stable before placing any equipment on the stand.



Figure 2: Proper technique for unfolding the stand legs by pressing the red release buttons.



Figure 3: The stand fully unfolded, showing its stable base and integrated dust bag.

2.4. Attaching the Table Saw

Align the mounting points on the table saw with the corresponding holes on the stand. Secure the table saw to the stand using the provided hardware. Ensure a tight and secure fit to prevent movement during operation.



Figure 4: The SKIL Table Saw securely attached to the folding stand, demonstrating a complete and stable workstation.

2.5. Dust Bag Installation

Attach the quick-install dust bag to the designated port on the stand. This helps to collect sawdust and maintain a cleaner working environment.



Figure 5: The quick-install dust bag attached to the side of the stand, ready to collect sawdust.

3. Operating the Stand

3.1. Height Adjustment

The stand features two height positions for user comfort and versatility. To adjust the height, locate the adjustment mechanisms on the legs and follow the instructions provided with your table saw for specific height settings.



Figure 6: Detail of the height adjustment knob, allowing users to set the stand to their preferred working height.

3.2. Fence Adjustment

The table saw's fence (not part of the stand, but supported by it) can be adjusted using a rack and pinion system for precise cuts. Refer to your table saw's manual for detailed instructions on fence calibration and use.

3.3. Using the Push Stick

Always use the provided push stick when feeding material into the saw, especially for narrow cuts. This ensures your hands remain safely away from the blade. The push stick can be stored on the stand when not in use.

4. Maintenance

Regular maintenance ensures the longevity and optimal performance of your folding stand. Keep the stand clean from sawdust and debris, especially around the folding mechanisms and leg adjustments. The quick-install dust bag should be emptied regularly to prevent buildup.

5. Troubleshooting

5.1. Missing or Loose Hardware

If you encounter any missing or loose hardware, such as a bolt for the push stick holder as observed during initial setup, check the packaging thoroughly. If a part is genuinely missing or damaged, contact SKIL customer support for replacement parts. Do not operate the stand with missing or damaged components.

6. Specifications

- **Brand:** Skil
- **Model Number:** SFS0001
- **Style:** 8-1/4" Table Saw Folding Stand
- **Item Weight:** 17.81 pounds
- **Package Dimensions:** 25.25 x 25 x 4.2 inches
- **Material:** Metal (Handle Material)
- **Special Feature:** Fast, tool-free installation and adjustable height positions
- **Included Components:** [1] SKIL Folding Stand, [1] dust bag

7. Warranty and Support

7.1. Warranty Information

This SKIL product comes with a**3-Year Limited Warranty**. Registration is required to activate the full warranty coverage. Please refer to the warranty card included in your packaging for detailed terms and conditions.

7.2. Customer Support

For technical assistance, replacement parts, or warranty claims, please contact SKIL customer support. Visit the official SKIL website or refer to the contact information provided in your product packaging for the most up-to-date support options.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question