BOBLOV M10

BOBLOV M10 3.2K Body Camera User Manual

Model: M10 | Brand: BOBLOV

Introduction

The BOBLOV M10 3.2K Body Camera is a high-performance wearable device designed for various applications, including law enforcement, delivery work, and outdoor activities. It features 3.2K Ultra HD video recording, a 170° wide-angle lens, and an upgraded 6000mAh battery for extended operation. This manual provides detailed instructions on setting up, operating, and maintaining your M10 body camera to ensure optimal performance and longevity.

What's in the Box



The BOBLOV M10 Body Camera package includes all necessary components to get started. Upon unboxing, verify

that all items listed below are present:

- M10 Body Camera
- Long Clip
- Short Clip
- Charging Dock
- USB Cable
- User Manual
- Durable Lanyard

Setup

Charging the Camera



Before first use, fully charge the BOBLOV M10 Body Camera. The camera is equipped with a 6000mAh battery, providing extended recording times. Charging is convenient with the included dock:

1. Connect the USB cable to the charging dock and a power source (e.g., wall adapter, computer USB port).
2. Place the M10 body camera onto the charging dock. Ensure the camera is properly seated.
3. The charging indicator light on the dock will show the charging status. A full charge typically takes approximately 6 hours.

Attaching Clips and Lanyard

The camera comes with a long clip and a short clip for versatile attachment options. Choose the clip that best suits your needs for secure wearing. The durable lanyard can also be attached for additional security or carrying convenience.


Operating the Camera

Power On/Off

- To power on: Press and hold the Power button until the camera starts.

- To power off: Press and hold the Power button until the camera shuts down.

Video Recording



The M10 records in 3.2K Ultra HD resolution with a 170° wide-angle lens, capturing clear and comprehensive footage. It supports up to 20 hours of continuous recording at 1080P or 18 hours at 3.2K.

- To start recording: Press the Record button.
- To stop recording: Press the Record button again.
- Adjust video resolution settings via the camera's menu.

GPS Functionality



The integrated GPS function allows the camera to record your location and movement during video capture. This data can be reviewed on your computer using compatible software for both Windows and Mac systems.

- Ensure GPS is enabled in the camera settings for location tracking.
- For optimal GPS signal, operate the camera in an open area.

Night Vision



Equipped with 8 built-in infrared (IR) lights, the M10 provides clear and detailed recording even in low-light or completely dark environments. This feature is crucial for night shifts or situations requiring visibility in darkness.

- Night vision can be activated manually or set to automatic mode in the camera's menu.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your BOBLOV M10 Body Camera.

- **Cleaning:** Use a soft, dry cloth to clean the camera body and lens. Avoid abrasive materials or harsh chemicals.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For long-term storage, charge the battery to about 50% to preserve its health. Avoid fully discharging the battery frequently.
- **Firmware Updates:** Periodically check the official BOBLOV website for any available firmware updates to ensure your camera has the latest features and bug fixes.

Troubleshooting

If you encounter issues with your BOBLOV M10 Body Camera, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Camera does not power on	Low battery; System crash	Charge the camera fully; Perform a hard reset (refer to manual for specific button combination if available, or hold power button for 10+ seconds).
Recording issues (e.g., blurry video, no recording)	Lens dirty; Insufficient storage; Incorrect settings	Clean the lens; Transfer files to computer to free up space; Check video resolution and recording settings.
GPS not tracking	GPS disabled; Poor signal	Ensure GPS is enabled in settings; Move to an open area with clear sky view.
Buttons are difficult to see/operate	Low light conditions; Design characteristic	Familiarize yourself with button layout in well-lit conditions; Use tactile feedback to identify buttons.
Cannot delete files on camera	Security setting; Feature limitation	Connect to a computer to manage and delete files.

If the problem persists, please contact BOBLOV customer support for further assistance.

Specifications

Key technical specifications for the BOBLOV M10 Body Camera:

Feature	Detail
Brand Name	BOBLOV
Model Number	M10

Feature	Detail
Video Capture Resolution	3.2K
Photo Sensor Technology	CMOS
Battery Capacity	6000mAh Lithium Polymer (included)
Continuous Recording Time	Up to 20 hours (1080P), 18 hours (3.2K)
Charging Time	Approx. 6 hours
Internal Storage	128GB
Special Features	Night Vision (8 IR Lights), GPS Function
Screen Size	2 Inches
Connectivity Technology	USB
Item Weight	Approx. 1.19 pounds (0.54 kg)
Package Dimensions	Approx. 5.16 x 4.02 x 4.02 inches

Warranty and Support

BOBLOV offers comprehensive support for its products. The M10 Body Camera comes with a 24-month product coverage period. For any inquiries or technical assistance, BOBLOV aims to provide a quick response within 24 hours and offers lifetime technical support.
For more information or to contact support, please visit the official BOBLOV store:BOBLOV Store on Amazon