SLOTHMORE FE-7204B

SLOTHMORE Leg Massager User Manual

Model: FE-7204B

Introduction

The SLOTHMORE Leg Massager is an advanced air compression device designed to provide circulation improvement and pain relief for your feet, calves, knees, and thighs. Utilizing 10x2 airbags, it simulates kneading leg muscles through inflation and deflation, offering a comprehensive massage experience. This manual provides essential information for the safe and effective operation of your new leg massager.



Image: The SLOTHMORE Leg Massager, showcasing the full set of leg wraps and the connected handheld controller.

Safety Information

Please read all safety instructions carefully before using the SLOTHMORE Leg Massager to prevent injury or damage to the device.

- Always ensure the device is unplugged before cleaning or when not in use.
- Do not use the massager in wet environments or near water.
- Keep out of reach of children and pets.
- Consult a physician before use if you have pre-existing medical conditions, are pregnant, or have pacemakers/implants.
- Do not use the massager on swollen, inflamed, or injured areas of the skin.
- If you experience any discomfort or pain during use, discontinue immediately.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Use only the provided power adapter.

Setup

Follow these steps to set up your SLOTHMORE Leg Massager for the first time:

1. Unpack all components from the box: the leg wraps (foot, calf, and thigh sections) and the handheld controller.
2. Connect the air hoses from the leg wraps to the corresponding ports on the handheld controller. Ensure a secure connection.
3. Plug the power adapter into the handheld controller, then into a standard electrical outlet.
4. Adjust the leg wraps to fit your legs comfortably using the Velcro fasteners. The wraps are designed to fit various sizes, with calves up to 22.7 inches, thighs up to 31.4 inches, and feet up to US Men Size 14.



Image: Adjustable sizing of the leg massager wraps for a comfortable fit.

For a visual guide on how to wear the massager, you can scan the QR code provided in the user manual or on the hand controller with your mobile phone. This video guide simplifies the wearing process into 4 easy steps.



Image: Scan the QR code for a quick video wearing guide.

Operating Instructions

The SLOTHMORE Leg Massager features a user-friendly handheld controller to customize your massage experience.



Image: The Smart Controller for the SLOTHMORE Leg Massager.

Controller Functions:

- **Power Button:** Press to turn the device ON/OFF.
- **Mode (M) Button:** Cycle through 4 massage modes:
  - Auto (Full Leg)
  - Foot Only
  - Calf Only
  - Thigh Only
- **Intensity (III) Button:** Select from 3 intensity levels (Low/Mid/High) for air compression.
- **Heat (SSS) Button:** Choose from 3 heat levels (Low/Mid/High) for the knee area, or turn heat off.
- **Timer Button:** Set the massage duration to 20, 25, or 30 minutes.
- **Play/Pause Button:** Start or pause the inflation and deflation function.

Massage Modes and Benefits:

The massager uses 10x2 airbags to simulate kneading leg muscles, promoting circulation and relieving pain.



Image: Air Compression Technology provides deep relief.



Image: Knee Heating Therapy with adjustable levels and timer.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your SLOTHMORE Leg Massager.

- **Cleaning:** Disconnect the power adapter. Wipe the surface of the leg wraps and controller with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the massager in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the wraps are neatly folded to prevent damage to the air hoses.
- **Care:** Avoid sharp objects that could puncture the airbags or fabric. Do not twist or bend the air hoses excessively.

Troubleshooting

If you encounter any issues with your SLOTHMORE Leg Massager, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Power adapter not properly connected or no power from outlet.	Ensure the power adapter is securely plugged into both the controller and a working electrical outlet. Try a different outlet.
No air compression or weak compression.	Air hoses are loose or disconnected; wraps are not properly secured.	Check all air hose connections to the controller and ensure they are firmly attached. Make sure the leg wraps are tightly secured around your legs.
Heat function not working.	Heat setting is off or too low.	Press the Heat (SSS) button on the controller to cycle through heat levels (H1, H2, H3) and ensure it's not set to off.
Unusual noise during operation.	Normal operation sound of the air pump; loose connection.	A low humming sound from the air pump is normal. If the noise is excessive or unusual, check for loose connections. If it persists, contact support.

If the problem persists after trying these solutions, please contact SLOTHMORE customer support.

Specifications

Feature	Detail
Product Dimensions	8 x 6.69 x 5 inches
Item Weight	4.19 Pounds
Model Number	FE-7204B
Manufacturer	Xiamen Healthpal Electronic Co., Ltd
Power Source	Corded Electric
Special Features	Auto Shut-Off, Heat
Massage Modes	4 (Auto, Foot, Calf, Thigh)
Intensity Levels	3 (Low, Mid, High)
Heat Levels (Knee)	3 (Low, Mid, High)
Timer Settings	20, 25, 30 minutes

Warranty and Support

SLOTHMORE is committed to providing high-quality products and excellent customer service.

Warranty Information:

Your SLOTHMORE Leg Massager comes with a**12-Month Warranty** from the date of purchase, covering manufacturing defects. Additionally, we offer a **30-Day Return Policy** for your peace of mind.
Please retain your proof of purchase for warranty claims.

Customer Support:

For any questions, technical assistance, or warranty inquiries, please do not hesitate to contact our dedicated support team:
Email: Support@slothmoreteam.com
Our team is available to assist you with any concerns regarding your SLOTHMORE Leg Massager.

© 2025 SLOTHMORE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question