MOVE SPEED YSPBS10

MOVE SPEED 10,000mAh Magnetic Power Bank Instruction Manual

Model: YSPBS10

Introduction

Thank you for choosing the MOVE SPEED 10,000mAh Magnetic Power Bank. This ultra-slim, alloy-designed portable charger is engineered to provide efficient and reliable power for your devices on the go. Featuring strong magnetic attachment, intelligent temperature control, and versatile charging options, it ensures your devices stay powered in various scenarios. This manual provides essential information for setup, operation, maintenance, and troubleshooting to help you get the most out of your new power bank.

What's in the Box

- 1 x 10000mAh Magnetic Powerbank S10
- 1 x USB C Fast Charging Cable
- 1 x Magnetic Ring
- 1 x User Manual

Key Features

- **Metal Design & Portable:** Our portable power bank is only 0.5 inch thick, with a metal design, like a carried power source. It takes almost no space in a pocket, backpack, or handbag, providing charging support for devices anytime and anywhere, enabling easy travel without heavy burdens.



Image: The MOVE SPEED power bank's slim profile, easily held in one hand.

- **NTC Intelligent Temperature Control:** Equipped with advanced polymer lithium batteries and NTC main control temperature chips, it has 3 layers of cooling protection. When the temperature rises abnormally, the system automatically adjusts the charging power to prevent overheating and protect devices and personal safety.



Image: Internal view of the power bank emphasizing NTC intelligent temperature control.

- **N52 Super Strong Suction:** With 4 times stronger N52 neodymium magnets, gently place the device and it will attach and start charging, achieving drop and charge. This saves time and reduces interface wear. You can enjoy a fast and convenient charging experience at home, in the office, or in a car.




Image: Illustration of the power bank's strong magnetic attachment to a phone.

- **Efficient Charging Options:** Supports 7.5W charging and 15W USB-C wired output, allowing two devices to be charged simultaneously. It offers faster charging compared to standard options, ensuring your devices regain power quickly to meet urgent needs.



Image: Visual representation of wireless and wired charging speeds.

- **Multi-scenario Application:** Our product is designed to meet charging needs in various scenarios, such as at home, bedroom, living room, in the office, desk, meeting room, during a trip, hotel, airport, or in a car while driving, providing reliable charging services for devices.



Image: Examples of the power bank's use in different daily and travel situations.

Setup Guide

Initial Charging of the Power Bank

Before first use, fully charge your MOVE SPEED Magnetic Power Bank. Use the provided USB-C cable and connect it to a compatible USB power adapter (not included). The LED indicator lights on the side of the power bank will illuminate to show the charging progress. All lights will be solid when fully charged.

Attaching the Magnetic Ring (for non-MagSafe compatible devices)

If your device is not MagSafe compatible, you can use the included magnetic ring to enable magnetic attachment. Carefully peel off the adhesive backing from the magnetic ring and center it on the back of your phone or phone case. Ensure it is aligned correctly for optimal magnetic connection and wireless charging.

Operating Instructions

Wireless Charging (MagSafe Compatible Devices)

1. Ensure your power bank is sufficiently charged.
2. Align the MOVE SPEED Magnetic Power Bank with the back of your MagSafe-compatible iPhone (iPhone 12 series and later) or a device with the magnetic ring attached.
3. The power bank will magnetically snap into place and automatically begin wireless charging. The charging status will be indicated on your phone's screen.

Wired Charging (USB-C Output)

1. Ensure your power bank is sufficiently charged.
2. Connect one end of the provided USB-C cable to the USB-C port on the power bank.
3. Connect the other end of the USB-C cable to your device's charging port.
4. The power bank will begin wired charging your device.

Care and Maintenance

- **Cleaning:** Wipe the power bank with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- **Temperature Control:** The power bank features NTC Intelligent Temperature Control. If it becomes unusually warm during charging, it will automatically adjust power output to prevent overheating. Do not cover the power bank during use.
- **Avoid Drops:** While durable, avoid dropping the power bank or subjecting it to strong impacts, which could damage internal components.

Troubleshooting

Issue	Possible Cause	Solution
Power bank not charging device wirelessly.	Incorrect alignment; phone case too thick; power bank battery low.	Ensure proper magnetic alignment. Use a MagSafe-compatible case or the included magnetic ring. Recharge the power bank.
Power bank not charging device via USB-C.	Cable is faulty; power bank battery low; device port issue.	Try a different USB-C cable. Recharge the power bank. Test with another device.
Power bank or device getting hot during charging.	Normal heat generation; poor ventilation; excessive load.	Minor heat is normal. Ensure adequate ventilation. The NTC system will regulate temperature. Discontinue use if excessively hot.
LED indicators not lighting up.	Power bank is fully discharged or faulty.	Connect the power bank to a power source to charge. If still unresponsive, contact customer support.

Product Specifications

Feature	Detail
Product Dimensions	3.98 x 2.61 x 0.59 inches
Item Weight	7.8 ounces
ASIN	B0DK6JPWLT
Item Model Number	YSPBS10
Batteries	1 A batteries required
Color	Glacier Gray
Connector Type	USB Type C
Brand	MOVE SPEED
Battery Capacity	10000 Milliamp Hours

Feature	Detail
Special Feature	Lightweight
Manufacturer	Shenzhen Speedmobile Technology Co., Ltd
Country of Origin	China
Date First Available	October 17, 2024

Warranty and Support

MOVE SPEED is committed to providing high-quality products and customer satisfaction. Your MOVE SPEED Magnetic Power Bank comes with a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures reliable performance.

For any questions, technical support, or warranty claims, please refer to the contact information provided in the user manual included in your product packaging or visit the official MOVE SPEED website. We offer lifetime support to assist you with any inquiries.



Image: MOVE SPEED's commitment to lifetime support and warranty assurance.

© 2025 MOVE SPEED. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question