Benkut 27804942-3b9b-4be4-abf4-868041c41eba

Benkut Modern LED Wall Sconce Instruction Manual

Model: 27804942-3b9b-4be4-abf4-868041c41eba
Brand: Benkut

1. Important Safety Information

Please read these instructions carefully before installation and use. Keep this manual for future reference.

- **Electrical Safety:** Always disconnect power at the circuit breaker before installation, servicing, or cleaning. If you are unsure about electrical wiring, consult a qualified electrician.
- **Installation:** Ensure the mounting surface can support the weight of the fixture. Install in accordance with local electrical codes.
- **Indoor Use Only:** This fixture is designed for indoor use. Do not expose to moisture or extreme temperatures.
- **Handling:** Handle the fixture with care to avoid damage to the LED components or acrylic parts.
- **Cleaning:** Use a soft, dry cloth for cleaning. Do not use abrasive cleaners or solvents.

2. Package Contents

Verify that all components are present before beginning installation:

- LED Wall Sconce (1 unit)
- Remote Control (1 unit)
- Mounting Hardware (screws, wire nuts, etc.)
- Instruction Manual (this document)

3. Product Overview

The Benkut Modern LED Wall Sconce features a contemporary design with integrated LED lighting. It offers adjustable color temperature (3000K-6500K) and dimmable brightness, controlled via an included remote. The fixture is constructed from durable aluminum and acrylic materials.



Image 3.1: Benkut Modern LED Wall Sconce with remote control and various light settings.



Image 3.2: Product dimensions and key specifications.



Image 3.3: Adjustable color temperature and dimming capabilities.

4. Installation Instructions

This wall light fixture is designed for direct connection to a standard wall junction box. All necessary mounting hardware is included.

Tools Required (Not Included):

- Screwdriver (Phillips head)
- Wire strippers
- Electrical tape
- Voltage tester

Installation Steps:

1. **Safety First:** Turn off the power to the junction box at the main circuit breaker. Verify power is off using a voltage

tester.

2. **Prepare Mounting Plate:** Attach the mounting plate (usually pre-attached to the fixture) to the wall junction box using the provided screws. Ensure it is securely fastened.
3. **Wire Connections:** Carefully connect the electrical wires:
    - Connect the **black** wire from the fixture to the **black** (live) wire from the junction box using a wire nut.
    - Connect the **white** wire from the fixture to the **white** (neutral) wire from the junction box using a wire nut.
    - Connect the **green** or bare copper (ground) wire from the fixture to the **green** or bare copper (ground) wire from the junction box, and to the ground screw on the mounting plate.

    Ensure all connections are secure and insulated with electrical tape if necessary.
4. **Mount the Fixture:** Carefully tuck the wires into the junction box. Align the fixture with the mounting plate and secure it using the provided screws.
5. **Restore Power:** Turn the power back on at the circuit breaker.




Image 4.1: Hard wiring installation diagram.

Note: *This fixture is designed to work with a regular on/off wall switch and is not compatible with external dimmable switches.*

5. Operating Instructions

The Benkut LED Wall Sconce is operated using the included remote control. The remote allows for adjustment of both brightness and color temperature.

Remote Control Functions:

- **Power On/Off:** Press the **ON** or **OFF** button to turn the light on or off.
- **Brightness Adjustment:** Use the **brightness up/down** buttons to increase or decrease the light intensity (10% to 100%).
- **Color Temperature Adjustment:** Use the **color temperature up/down** buttons to cycle through color temperatures from warm white (3000K) to daylight (6500K).
- **Preset Modes:** The remote may include preset buttons for specific brightness or color temperature settings. Refer to the remote's markings for details.



Image 5.1: Visual guide to adjustable color temperature and dimming.

Demonstration Video:

Your browser does not support the video tag.

Video 5.1: This video demonstrates the Benkut Gold Wall Sconce in various room settings and showcases the 3-color dimming functionality controlled by the remote. It illustrates how to switch between bright white, warm white, and daylight settings.

6. Maintenance

Regular maintenance will help preserve the appearance and functionality of your LED wall sconce.

- **Cleaning:** To clean the fixture, ensure the power is off. Use a soft, dry, or slightly damp cloth. Avoid using harsh chemicals, abrasive cleaners, or sprays directly on the fixture, as these can damage the finish or electrical components.
- **LED Longevity:** The integrated LED light source is designed for long-term use and does not require bulb replacement.

7. Troubleshooting

If you encounter issues with your Benkut LED Wall Sconce, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on	No power to the fixture	Check circuit breaker. Ensure wall switch is on. Verify wire connections.
Remote control not working	Remote battery is dead or improperly inserted	Replace remote battery. Ensure battery is inserted with correct polarity.
Light flickers or dims unexpectedly	Loose wire connection or incompatible dimmer switch	Turn off power and check wire connections. Ensure a standard on/off switch is used, not an external dimmer.
Incorrect color temperature or brightness	Remote settings are not adjusted correctly	Use the remote control to adjust color temperature and brightness to desired levels.

If the problem persists after attempting these solutions, please contact customer support.

8. Specifications

Attribute	Detail
Brand	Benkut
Model Number	27804942-3b9b-4be4-abf4-868041c41eba
Color	Gold
Material	Acrylic, Aluminum, Iron
Style	Modern
Light Fixture Form	Sconce
Product Dimensions	4"L x 2.4"W x 35.5"H
Indoor/Outdoor Usage	Indoor
Power Source	AC/DC
Installation Type	Wall Mount
Special Feature	Adjustable Color Temperature, Dimmable
Control Method	Remote
Light Source Type	LED
Voltage	110-220 Volts
Light Color	3000K-6500K (Adjustable)
Brightness	1650 Lumens (Max)

Attribute	Detail
Wattage	18 Watts
Item Weight	3.1 Pounds

9. Warranty and Support

Information regarding product warranty and customer support was not provided in the available product data. For warranty details or technical assistance, please refer to the product packaging or contact the manufacturer directly through their official channels.

© 2025 Benkut. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question