

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [FEPP0](#) /

› [FEPP0 XXL 36"x16" Electric Food Warming Mat Instruction Manual](#)

FEPP0 ORK.61.241-2

FEPP0 XXL 36"x16" Electric Food Warming Mat

Model: ORK.61.241-2

1. IMPORTANT SAFETY INSTRUCTIONS


Please read and understand all safety instructions before using the FEPP0 Electric Food Warming Mat. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Voltage:** Use only with standard U.S. voltage (110-120V AC).
- **Placement:** Always place the warming mat on a stable, flat, and heat-resistant surface.
- **Surface Compatibility:**
 - For Quartz Tabletops: Maximum temperature $\leq 194^{\circ}\text{F}$ (90°C).
 - For Wooden Tabletops: Maximum temperature $\leq 194^{\circ}\text{F}$ (90°C).
 - **Do Not Use on Glass Tabletops.**
- **Unplug When Not in Use:** Disconnect the power cord from the outlet when the mat is not in use or before cleaning.
- **Avoid Overheating:** Do not cover the control panel or block ventilation.
- **Liquid Contact:** Do not immerse the mat or power cord in water or other liquids. Avoid spilling liquids directly onto the control panel.
- **Children and Pets:** Keep out of reach of children and pets.
- **Damage:** Do not operate if the mat or power cord is damaged. Contact customer support for assistance.
- **Intended Use:** This appliance is designed for warming food and beverages only. Do not use for other purposes.

Safety Instructions

For safe use, please read the following instructions carefully

Quartz Tabletop
≤194°F



Wooden Tabletop
≤194°F



Glass Tabletop



Notice

-  Use with standard U.S. voltage: **110-120V**
-  Place on a stable, heat-resistant surface
-  Disconnect when not in use.

Image: Safety guidelines for tabletop use and general precautions.

2. PRODUCT OVERVIEW

The FEPP0 XXL Electric Food Warming Mat is designed to keep your food warm for extended periods, ideal for family meals, parties, and buffets. It features advanced graphene heating technology for rapid and uniform heat distribution across its large surface.

- **Extended Size:** Measuring 36" x 16", this mat provides ample space for multiple dishes.
- **Rapid Heating:** Equipped with a 580W PI heating film, it achieves full-surface uniform heating in approximately 10 seconds.
- **Temperature Control:** Offers six temperature levels ranging from 122°F (50°C) to 212°F (100°C).
- **Integrated Timer:** Features a built-in timer for up to 6 hours of continuous warming.
- **Durable Material:** Made from top-quality flexible silicone nano-materials, ensuring durability, easy cleaning, and space-saving storage.
- **Versatile Compatibility:** Compatible with various tableware materials including glass, stainless steel, iron pot, ceramic, casserole, and plastic.

36"x 16" Extra space

Designed for family gatherings/parties/buffets.




Image: The FEPPO warming mat displaying its large surface area with various food containers.



Image: Visual representation of the 36" x 16" dimensions of the warming mat.

Your browser does not support the video tag.

Video: An overview of the FEPPO Electric Food Warming Mat, demonstrating its features and use in a kitchen setting.

3. SETUP

1. **Unpack:** Carefully remove the warming mat and all accessories from the packaging. Ensure all components listed in the "Included Components" section are present.
2. **Placement:** Choose a stable, flat, and heat-resistant surface for the warming mat. Ensure there is adequate space around the mat for proper ventilation. Refer to the "Important Safety Instructions" for surface compatibility.
3. **Power Connection:** Insert the power cord into the designated port on the control panel of the warming mat. Then, plug the power cord into a standard 110-120V AC electrical outlet.
4. **Initial Cleaning:** Before first use, wipe the surface of the warming mat with a damp cloth. Do not immerse the mat in water.



Stable, safe and suitable for any surface.
Effective heat dissipation to protect your countertop.

Image: The non-slip silicone bottom of the warming mat, designed for stability and countertop protection.

4. OPERATING INSTRUCTIONS

The FEPP0 warming mat features a digital touch control panel for easy operation.

- 1. Power On/Off:** Press the power button () on the control panel to turn the mat on or off. The display will illuminate when powered on.
- 2. Setting Temperature:**
 - Press the "TEMP" button () to cycle through the six available temperature settings:
 - 122°F (50°C)
 - 140°F (60°C)
 - 158°F (70°C)
 - 176°F (80°C)
 - 194°F (90°C)
 - 212°F (100°C)
 - Select the desired temperature for your food. The mat will begin heating to the selected temperature.
- 3. Setting Timer:**
 - Press the "TIME" button () to set the operating duration. You can choose from 1 to 6 hours.
 - Once the set time expires, the mat will automatically turn off.
- 4. Monitoring:** The digital display shows the current temperature setting.




Image: Close-up of the digital touch control panel with temperature and timer options.

5. USAGE GUIDELINES

The FEPP0 warming mat is versatile and can be used for various applications beyond just keeping food warm.

- **Food Warming:** Maintain optimal serving temperature for cooked dishes during meals, parties, or buffets.
- **Thawing Frozen Foods:** Use a lower temperature setting to gently thaw frozen items.
- **Dough Fermentation:** Provides a consistent warm environment for proofing dough.
- **Melting Chocolate:** Achieve a controlled low heat for melting chocolate without scorching.

- **Warming Beverages:** Keep coffee, tea, or milk warm in appropriate containers.
- **Compatible Cookware:** The mat is designed to work with various materials including glass, stainless steel, iron pots, ceramic, casseroles, and plastic containers.

Image: Examples of different types of tableware and containers compatible with the warming mat.



Image: Illustrations of the diverse applications for the FEPPO warming mat.

6. MAINTENANCE AND CLEANING

Proper care and maintenance will extend the life of your FEPPO Electric Food Warming Mat.

- **Cleaning:**
 - Always unplug the mat and allow it to cool completely before cleaning.
 - Wipe the silicone surface with a damp cloth and mild detergent if necessary.
 - Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the surface.
 - Do not immerse the mat or its control panel in water.
- **Storage:**
 - Once clean and dry, the flexible silicone material allows the mat to be rolled up for compact storage.
 - Use the provided storage strap to secure the rolled mat.
 - Store in a cool, dry place away from direct sunlight.

Graphene Directional Heating Technology




Image: Demonstrating the easy cleaning process for the water-resistant, stain-resistant, and oil drop-resistant surface.



Image: The flexible design allows the mat to be rolled for convenient storage without wrinkles.

7. TROUBLESHOOTING

If you encounter any issues with your FEPP0 Electric Food Warming Mat, please refer to the following common troubleshooting steps:

- **Mat Not Heating:**

- Ensure the power cord is securely plugged into both the mat and a working electrical outlet.
- Verify that the power button on the control panel has been pressed and the display is active.
- Check if the circuit breaker has tripped.

- **Uneven Heating:**

- Ensure the mat is placed on a flat, even surface.
- Confirm that the cookware used has a flat bottom for maximum contact with the mat.

- **Temperature Not Reaching Desired Level:**

- Allow sufficient time for the mat to reach the set temperature, especially when starting from cold.
- Ensure the ambient room temperature is not excessively cold, which can affect heating efficiency.

- **Control Panel Unresponsive:**

- Unplug the mat from the power outlet, wait for a few minutes, and then plug it back in to reset the system.
- Ensure the control panel is clean and dry.

If the issue persists after attempting these steps, please contact FEPPPO customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	FEPPPO
Model Number	ORK.61.241-2
Product Dimensions	16"D x 36"W x 0.71"H
Material	Silicone
Wattage	580 watts
Voltage	120 Volts (AC)
Controls Type	Digital Touch
Heating Elements	1 (PI Heating Layer)
Temperature Levels	6 (122°F to 212°F)
Timer Settings	0-6 Hours
Included Components	1* Electric Warming Mat, 1*Storage Bag, 1*Storage Strap, Power Cord, User Manual
UPC	717331877200

9. WARRANTY AND SUPPORT

FEPPPO products are manufactured with quality and durability in mind. For specific warranty information regarding your Electric Food Warming Mat, please refer to the warranty card included with your product or visit the official FEPPPO website.

If you have any questions, require technical assistance, or need to report an issue, please contact FEPPPO customer support. Contact details can typically be found in the product packaging or on the official FEPPPO website.

Online Support: [Visit the FEPPPO Store on Amazon](#)

