Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

sonecesiya 60ml

sonecesiya Reusable 60ml Coffee Capsules for Tassimo/BOSCH Machines

Instruction Manual

1. Introduction

Thank you for choosing sonecesiya Reusable Coffee Capsules. This product is designed to provide a sustainable and cost-effective alternative to single-use coffee pods for your Tassimo or BOSCH coffee machine. Made from high-quality 304 stainless steel and food-grade silicone, these capsules allow you to enjoy your favorite ground coffee while reducing waste.

Please read this manual carefully before first use to ensure proper operation and maintenance of your reusable coffee capsules.

2. Product Components

Your sonecesiya Reusable Coffee Capsule set includes the following items:

- 1 x Reusable Coffee Capsule (60ml)
- 1 x Silicone Lid with Integrated Filter
- 1 x Coffee Spoon
- 1 x Cleaning Brush



Image: All components of the reusable coffee capsule set.

3. Compatibility

These 60ml reusable coffee capsules are compatible with various Tassimo and BOSCH coffee machine models, including but not limited to:

- TAS1003/01
- TAS1403/02
- TAS5552UC/05
- Tassimo T20
- Tassimo Vivy2
- Tassimo T55+ CTPM05UC
- CTPM12

- CTPM07
- CTPM02
- CTPM08
- Tassimo Tas4013 / 09



Image: Examples of compatible Tassimo coffee machines.

4. Setup and Operating Instructions

Follow these steps to prepare and use your reusable coffee capsule:

1. **Fill the Capsule:** Open the reusable capsule. Use the included spoon to fill the empty pod with your desired ground coffee. Ensure the coffee grounds do not exceed the maximum fill line indicated inside the capsule. Overfilling can affect brewing performance and machine operation.
2. **Close the Lid:** Place the silicone lid onto the capsule. Ensure the filter is properly seated inside the silicone cover. Press gently around the entire circumference of the lid to secure it, avoiding pressure directly in the center to prevent the filter from dislodging.
3. **Insert into Machine:** Open the capsule compartment of your Tassimo or BOSCH coffee machine. Insert the filled reusable capsule into its designated location. The capsule's bottom groove is designed to hold the machine needle and protect it during insertion and brewing.
4. **Brew Coffee:** Close the machine's lid firmly. Select your desired brew setting (if applicable) and start the brewing process.
5. **Enjoy:** Once brewing is complete, carefully remove your cup and enjoy your freshly brewed coffee.



Image: Reusable coffee capsule set ready for use.

03/

NOTE:

Filling coffee grinds do not exceed the maximum mark





04/

CAPSULE BOTTOM GROOVE CAN HOLD THE MACHINE NEEDLE AND PROTECT IT.

Used BPA free plastic material and 304 stainless steel filter is no harm to healthy.

Image: Do not exceed the maximum fill line for coffee grounds.




Image: Capsule bottom groove for machine needle protection.

Video: How to Use the Reusable Coffee Capsule

Your browser does not support the video tag. Please update your browser to view this content.

Video: This video demonstrates the process of filling the reusable capsule with coffee grounds, securing the lid, inserting it into a Tassimo machine, and brewing coffee.

5. Cleaning and Maintenance

Regular cleaning ensures optimal performance and longevity of your reusable coffee capsule:

1. **Disassemble:** After each use, allow the capsule to cool. Carefully remove the silicone lid from the capsule.
2. **Rinse:** Rinse both the capsule and the lid under running water to remove all coffee grounds.
3. **Brush Cleaning:** Use the included cleaning brush to thoroughly clean any remaining coffee residue from the filter mesh and inside the capsule.
4. **Dry:** Ensure all components are completely dry before reassembling or storing to prevent mold or odor buildup.

The capsule is made from 304 stainless steel and food-grade silicone, which are durable and easy to clean materials.




Image: The removable filter design facilitates easy cleaning.

6. Troubleshooting

If you encounter issues while using your reusable coffee capsule, consider the following:

- **Weak Coffee:** Ensure you are using a fine grind coffee. For a creamier espresso, an 'extreme fine' grind is recommended. Also, check that the capsule is filled adequately but not overfilled.
- **No Coffee Dispensed or Slow Flow:** This often indicates overfilling or coffee grounds that are too fine and compacted. Try reducing the amount of coffee or using a slightly coarser grind. Ensure the lid is properly sealed.
- **Capsule Not Fitting:** Double-check that the capsule is correctly aligned and inserted into the machine's compartment. Ensure no coffee grounds are obstructing the fit.
- **Coffee Splashing:** Ensure your cup is appropriately sized and positioned directly under the dispenser. Note that the 60ml capsule is designed for smaller servings, similar to an espresso.



Image: Guide to achieving creamy espresso by adjusting coffee grind size.



Image: Detail of the filter and pressurized cover for optimal extraction.

7. Specifications

Feature	Detail

Brand	sonecesiya
Model	60ml
Material	Food-grade Silicone, 304 Stainless Steel
Dimensions (Approx.)	7.4 cm (Width) x 6.8 cm (Base Diameter) x 3 cm (Height)
Included Components	1 x coffee filter, 1 x spoon, 1 x brush




Image: Detailed dimensions of the 60ml reusable coffee capsule.

8. Warranty and Support

For any questions, concerns, or support regarding your sonecesiya Reusable Coffee Capsules, please contact the seller directly through the platform where the purchase was made. Please retain your proof of purchase for warranty claims, if applicable.

© 2026 sonecesiya. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DK717YGQ

More documents and user manuals: **https://manuals.plus/**