Schleich 42706

Schleich Horse Club Lakeside Country House and Stable Playset (Model 42706) Instruction Manual

1. Safety Information

WARNING! CHOKING HAZARD - Small Parts. This product contains small parts that can be swallowed. It is not suitable for children under 3 years of age due to potential choking risks.

Always supervise young children during play to ensure safe use of all components.

2. Product Overview

The Schleich Horse Club Lakeside Country House and Stable Playset (Model 42706) offers a detailed and interactive environment for horse enthusiasts. This 179-piece set includes a multi-story farmhouse, a stable, horse figurines, poseable characters, riding tack, furniture, and various grooming tools, designed for imaginative play.



Image 2.1: The complete Schleich Horse Club Lakeside Country House and Stable Playset, showing the packaging and the fully assembled house and stable with figures and horses.

2.1. Components Included

The playset includes:

- 1x Lakeside Country House
- 1x Stable
- Horse figurines
- Poseable human figures
- Various furniture pieces
- Riding tack and grooming tools
- Additional accessories for detailed play



Image 2.2: The back of the product box, illustrating all 179 individual components and the overall dimensions of the assembled playset.

3. Setup and Assembly

Assembly of the Lakeside Country House and Stable Playset is required. Please follow the detailed instructions provided in the physical manual included with your product. Ensure all 179 pieces are accounted for before beginning assembly.

3.1. General Assembly Steps

1. **Unpack Components:** Carefully remove all pieces from the packaging. Organize them by type to facilitate easier assembly.
2. **Review Instructions:** Consult the included assembly manual for step-by-step diagrams and instructions.
3. **Assemble Main Structures:** Begin by constructing the main house and stable frames.
4. **Add Details:** Attach smaller elements such as windows, doors, railings, and roof sections.
5. **Place Furniture and Accessories:** Arrange the interior furniture and place accessories as desired.



Image 3.1: The Lakeside Country House and Stable shown as two distinct, assembled structures before being connected or arranged for play.



Image 3.2: The Lakeside Country House and Stable connected, demonstrating how the two main structures can be arranged to form a larger playset.

4. Operating the Playset

The playset is designed for open-ended imaginative play. The poseable figures allow for dynamic interaction with the horses and the environment.

4.1. Poseable Figures

The human figures included in the set feature articulated joints, allowing them to sit on horses, stand, and interact with various accessories. Gently move the limbs to position the figures as desired.



Image 4.1: Examples of poseable figures, demonstrating their articulated legs for various stances and riding positions.

4.2. Interactive Play Areas

- **Stable:** Use the stable for housing horses, grooming, and feeding.
- **Country House:** Explore multiple rooms, including bedrooms, a dining area, and a balcony for various scenarios.
- **Accessories:** Utilize the included accessories like riding tack, feed, and furniture to enhance storytelling.



Image 4.2: A child engaging in play with the stable section of the playset, demonstrating interaction with the horse figurines.



Image 4.3: Two figures enjoying a meal on the balcony of the country house, showcasing the playset's detailed living spaces.

5. Maintenance and Care

To ensure the longevity of your Schleich playset, follow these simple care instructions:

- **Cleaning:** Wipe surfaces with a damp cloth and mild soap if necessary. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the playset in a dry, cool place away from direct sunlight to prevent material degradation or color fading.
- **Handling:** Handle all pieces with care, especially smaller accessories and articulated figures, to prevent breakage.

6. Troubleshooting

If you encounter any issues with your playset, consider the following:

- **Missing Parts:** Refer to the parts list in your physical instruction manual. If a part is missing upon initial unboxing, contact Schleich customer support.
- **Assembly Difficulties:** Double-check the assembly steps and diagrams in the manual. Ensure all pieces are oriented correctly and snapped into place firmly. Do not force pieces together.
- **Damaged Parts:** If any part is damaged, do not attempt to repair it if it compromises safety. Contact customer support for assistance.

7. Specifications

Feature	Detail
Product Dimensions	25.39 x 6.3 x 16.73 inches
Item Weight	0.035 ounces
Model Number	42706
Manufacturer Recommended Age	5 - 12 years
Number of Pieces	179
Language (Manual)	Dutch, English, French, German, Italian
Manufacturer	Schleich

8. Warranty and Support

For warranty information, missing parts, or any product-related inquiries, please contact Schleich customer support directly. Details can typically be found on the product packaging or on the official Schleich website.

You can visit the official Schleich store for more information and products:Schleich Official Store

For additional product details and digital resources, you may scan the QR code found on the product packaging or visit: Schleich Product Information

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question