

[Manuals.plus](#) /

> [WLIVE](#) /

> WLIVE ABL001BL Fireplace Suit Instruction Manual

WLIVE ABL001BL

WLIVE ABL001BL Fireplace Suit Instruction Manual

Model: ABL001BL | Brand: WLIVE

INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your WLIVE ABL001BL Fireplace Suit. Please read all instructions carefully before use and retain this manual for future reference.

IMPORTANT SAFETY INFORMATION

- Read all instructions before installing or using this fireplace.
- Do not operate any fireplace with a damaged cord or plug, or if the heater has malfunctioned or been dropped.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the fireplace is left operating and unattended.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This fireplace is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Always unplug the fireplace when not in use.

PACKAGE CONTENTS

Please verify that all components are present and undamaged. If any parts are missing or damaged, contact WLIVE customer service.

- ABL001BL Fireplace Unit
- Remote Control
- Instruction Manual
- Mounting Hardware (if applicable, based on TV stand model)

SETUP AND INSTALLATION

The WLIVE ABL001BL Fireplace Suit is designed to be integrated into specific WLIVE TV Stands (models 027, 028, 031). Ensure you have the correct TV stand model for proper installation.

Step 1: Unpacking

Carefully remove all components from the packaging. Retain packaging for future transport or storage.

Step 2: Placement

Position the TV stand in its desired location, ensuring it is on a stable, level surface and away from combustible materials.

Step 3: Integrating the Fireplace Unit

Follow the specific instructions provided with your WLIVE TV Stand (models 027, 028, 031) for integrating the ABL001BL fireplace unit. This typically involves sliding the fireplace into a designated opening and securing it with provided hardware.



Image: Front view of the WLIVE ABL001BL electric fireplace unit, showing the realistic flame effect and control panel.

Step 4: Electrical Connection

Plug the fireplace power cord into a standard 120V AC grounded outlet. Do not use extension cords or power strips.

OPERATING INSTRUCTIONS

The ABL001BL fireplace can be operated using the control panel on the unit or the included remote control.



Image: The WLIVE ABL001BL fireplace unit highlighting key features: 1200W heating power, 0.5-7.5 hour timer, remote control functionality, and CSA Listed certification.

Control Panel Functions

- **Power Button:** Turns the fireplace ON/OFF.
- **Flame Button:** Adjusts flame brightness or style.
- **Heater Button:** Activates/deactivates the 1200W heating function.
- **Temperature Control:** Adjusts the heat output.
- **Timer Button:** Sets the operating timer (0.5 to 7.5 hours).

Remote Control Functions

The remote control duplicates the functions of the control panel for convenient operation. Ensure batteries are correctly installed.

MAINTENANCE

Cleaning

- Always disconnect power before cleaning.
- Use a soft, damp cloth to clean the exterior surfaces. Do not use abrasive cleaners or sprays.
- Gently wipe the glass panel with a soft cloth.

Storage

When not in use for extended periods, unplug the unit and store it in a dry, dust-free location.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fireplace does not turn on	No power	Check power cord connection and wall outlet.

Problem	Possible Cause	Solution
No heat output	Heater function off or thermostat set too low	Activate heater function; increase temperature setting.
Remote control not working	Dead batteries or obstruction	Replace batteries; ensure clear line of sight to unit.
Flames not visible	Flame effect off or brightness too low	Activate flame effect; increase brightness setting.

If problems persist, contact WLIVE customer support.

SPECIFICATIONS

- **Model:** ABL001BL
- **Brand:** WLIVE
- **Material:** Glass
- **Color:** Black
- **Power Output:** 1200W
- **Timer Range:** 0.5 - 7.5 hours
- **Applicability:** Designed for WLIVE TV Stand models 027, 028, 031
- **Certifications:** CSA Listed

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official WLIVE website.

WLIVE Customer Service: Please refer to the contact information provided on your product packaging or the official WLIVE website for support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DK7B28DY>

More documents and user manuals: <https://manuals.plus/>