Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aolion AK10DOC

Aolion K10 Wireless Bluetooth Gamepad with Dock User Manual

Model: AK10DOC

1. Introduction

Thank you for choosing the Aolion K10 Wireless Bluetooth Gamepad. This high-performance controller is designed to enhance your gaming experience across multiple platforms, including Nintendo Switch, PC, iOS, and Android devices. Featuring Hall effect joysticks and triggers, extra customizable pads, RGB lighting, and a mini display, the K10 offers precise control and versatile functionality. Please read this manual carefully before using the product to ensure proper operation and maintenance.

2. Package Contents

Please check the package contents upon unboxing. If any items are missing or damaged, please contact your retailer.

- Aolion K10 Wireless Bluetooth Gamepad
- Charging Dock
- USB-C Charging Cable
- User Manual (this document)
- Additional Customizable Pads (if included)

3. Product Features

The Aolion K10 Gamepad is equipped with advanced features for superior gaming performance:

- **Hall Effect Joysticks:** Provides precise, drift-free control and extended lifespan.
- **Hall Effect Triggers:** Offers accurate and responsive acceleration/braking control.
- **Multi-Platform Compatibility:** Seamlessly connects with Nintendo Switch, PC, iOS, and Android devices.
- **Wireless Bluetooth Connectivity:** Enjoy gaming without the clutter of cables.
- **Intelligent Charging Dock:** Convenient and stable charging solution.
- **Customizable Extra Pads:** Enhance gameplay with additional programmable buttons.
- **RGB Lighting:** Personalize your controller with dynamic lighting effects.
- **Mini Display:** Provides quick access to controller status and settings.



Image 1: Key features of the Aolion K10 Gamepad, highlighting the Hall effect joysticks, Hall effect triggers, and the intelligent charging base.

4. Setup

4.1 Charging the Gamepad

1. Connect the USB-C charging cable to the charging dock and a power source (e.g., USB wall adapter, PC USB port).
2. Place the Aolion K10 Gamepad onto the charging dock. Ensure the charging contacts on the gamepad align with those on the dock.
3. The controller's indicator lights or mini display will show the charging status. A full charge typically takes 2-3 hours.
4. Alternatively, you can connect the USB-C cable directly to the gamepad for charging.

4.2 Pairing with Devices

Ensure the gamepad is sufficiently charged before attempting to pair.

4.2.1 Nintendo Switch

1. On your Nintendo Switch, go to the HOME Menu.
2. Select "Controllers" > "Change Grip/Order".
3. On the Aolion K10 Gamepad, press and hold the**HOME button** and **Y button** simultaneously for 3 seconds until the indicator lights start flashing rapidly.
4. The Switch will detect the controller. Once paired, the indicator light on the gamepad will remain solid.

4.2.2 PC (Windows)

1. Ensure your PC has Bluetooth enabled.
2. Go to "Settings" > "Devices" > "Bluetooth & other devices" and turn Bluetooth ON.
3. Click "Add Bluetooth or other device" > "Bluetooth".
4. On the Aolion K10 Gamepad, press and hold the**HOME button** and **X button** simultaneously for 3 seconds until the indicator lights start flashing rapidly.
5. Select "Aolion K10" or similar from the list of available devices.
6. Once paired, the indicator light on the gamepad will remain solid.

4.2.3 iOS Devices (iPhone/iPad)

1. On your iOS device, go to "Settings" > "Bluetooth" and turn Bluetooth ON.
2. On the Aolion K10 Gamepad, press and hold the**HOME button** and **A button** simultaneously for 3 seconds until the indicator lights start flashing rapidly.
3. Look for "Xbox Wireless Controller" or "Aolion K10" under "OTHER DEVICES" and tap to connect.
4. Once paired, the indicator light on the gamepad will remain solid.

4.2.4 Android Devices

1. On your Android device, go to "Settings" > "Connected devices" > "Bluetooth" and turn Bluetooth ON.
2. Tap "Pair new device".
3. On the Aolion K10 Gamepad, press and hold the**HOME button** and **B button** simultaneously for 3 seconds until the indicator lights start flashing rapidly.
4. Select "Aolion K10" or similar from the list of available devices.

5. Once paired, the indicator light on the gamepad will remain solid.

5. Operating Instructions

5.1 Button Layout



Image 2: Front view of the Aolion K10 Gamepad, illustrating the general button layout.

- **Left Analog Stick:** Movement, camera control.
- **Right Analog Stick:** Camera control, aiming.
- **D-Pad:** Directional input, menu navigation.
- **A/B/X/Y Buttons:** Action buttons, context-sensitive.
- **L1/R1 (Shoulder Buttons):** Various in-game actions.
- **L2/R2 (Trigger Buttons):** Analog input for acceleration, braking, shooting.
- **HOME Button:** Power on/off, return to system menu.
- **SELECT/MINUS Button:** Access in-game menus, system functions.
- **START/PLUS Button:** Pause, access in-game menus.
- **Capture Button:** Take screenshots or record video clips (platform dependent).
- **M1/M2/M3/M4 (Back Paddles/Extra Pads):** Customizable buttons, refer to advanced settings for programming.

5.2 Special Functions

5.2.1 RGB Lighting Control

The Aolion K10 features customizable RGB lighting. Specific button combinations or settings via the mini display can be used to cycle through lighting modes, adjust brightness, or turn the lighting off. Refer to the on-screen prompts on the mini display for detailed control.

5.2.2 Mini Display Usage

The integrated mini display provides real-time information such as battery status, connection mode, and allows for quick adjustments to controller settings like button mapping for extra pads, vibration intensity, and RGB lighting. Navigate the display using the D-pad and action buttons as indicated on the screen.

5.2.3 Programming Extra Pads (M1-M4)

The extra pads on the back of the controller can be programmed to replicate other button inputs for enhanced gameplay. Typically, this involves entering a programming mode (often by holding a dedicated 'SET' or 'M' button), pressing the pad you wish to program, then pressing the button you want it to mimic, and finally exiting programming mode. Consult the mini display or specific instructions for precise steps.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the controller. For stubborn dirt, slightly dampen the cloth with water. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Avoid fully discharging the battery frequently. If storing for a long period, charge the battery to about 50% to prolong its lifespan.
- **Avoid Drops:** Do not drop or subject the controller to strong impacts, as this can damage internal components.

7. Troubleshooting

Problem	Possible Solution
Controller does not turn on.	• Ensure the controller is charged. Connect it to the charging dock or directly via USB-C cable. • Press and hold the HOME button for a few seconds to power on.
Cannot pair with device.	• Ensure the controller is in the correct pairing mode for your device (refer to Section 4.2). • Make sure Bluetooth is enabled on your device. • Forget previous pairings on your device and try again. • Restart both the controller and your device. • Ensure the controller is fully charged.
Input lag or disconnections.	• Ensure there are no obstructions between the controller and the device. • Move closer to the device. • Reduce interference from other wireless devices. • Ensure the controller is fully charged.
Joysticks drifting or unresponsive.	• The Aolion K10 uses Hall effect joysticks, which are less prone to drift. If issues occur, try recalibrating the joysticks via the controller's settings (if available) or your device's settings. • Ensure the controller's firmware is up to date (check manufacturer's website if applicable).

8. Specifications

Model Number	AK10DOC
Connectivity	Bluetooth Wireless
Compatibility	Nintendo Switch, PC, iOS, Android
Joystick Type	Hall Effect
Trigger Type	Hall Effect
Dimensions	16 x 15 x 12 cm (approximate)
Weight	400 g (approximate)
Battery	Rechargeable Lithium-ion (capacity not specified)
Charging Port	USB-C

9. Warranty and Support

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package or contact your retailer for specific warranty terms and conditions. For technical support, troubleshooting assistance, or inquiries about replacement parts, please contact the point of purchase or visit the official Aolion support website (if available).
Keep your purchase receipt as proof of purchase for warranty claims.

© 2024 Aolion. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DK7MPQ6P

More documents and user manuals: **https://manuals.plus/**