

[Manuals.plus](#) /

› [COWSAR](#) /

› COWSAR Compact 5-Cup Drip Coffee Maker CM3710H User Manual

COWSAR CM3710H

COWSAR Compact 5-Cup Drip Coffee Maker

MODEL: CM3710H - USER MANUAL

1. Product Overview

The COWSAR Compact 5-Cup Drip Coffee Maker (Model CM3710H) is designed for convenience and efficiency, brewing up to 5 cups of coffee. It features a programmable timer, a 30-second auto-pause function for serving during brewing, and a 2-hour keep-warm function with automatic shut-off. The coffee maker includes a food-grade glass carafe and a reusable filter basket for ease of use and maintenance. Its compact design makes it suitable for various spaces.

Elevate Your Coffee Experience at Home



**Programmable
Timer**



**5-Cup
Capacity**



**Bold Brew
Mode**



**Drip-Free
Design**



**2-Hour Keep
Warm Function**



**Washable
Filter**

COWSAR 5-Cup Drip Coffee Maker highlighting key features like programmable timer, 5-cup capacity, bold brew mode, drip-free design, 2-hour keep warm, and washable filter.

2. Important Safety Instructions

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the brewing cycles.

3. What's in the Box

Upon unboxing your COWSAR Coffee Maker, ensure all components are present and in good condition:

- COWSAR 5-Cup Drip Coffee Maker Unit
- Glass Carafe
- Reusable Filter Basket
- Coffee Spoon
- Instruction Manual



Exploded view of the COWSAR coffee maker showing its components: coffee spoon, reusable coffee filter, detachable funnel, detachable water tank, carafe, and warming plate, with dimensions.

4. Components

Familiarize yourself with the parts of your coffee maker:

1. **Coffee Spoon:** For measuring coffee grounds.
2. **Reusable Coffee Filter:** Eliminates the need for paper filters.
3. **Detachable Funnel:** Holds the filter basket.
4. **Detachable Water Tank (25.36oz):** Transparent tank for water level visibility.
5. **Carafe:** Food-grade glass carafe with drip-free design.
6. **Warming Plate:** Keeps coffee warm for up to 2 hours.
7. **Control Panel:** Features PROG, HOUR, MIN, and ON/OFF buttons.

5. Setup

1. **Initial Cleaning:** Before first use, wash the carafe, reusable filter, and detachable funnel in warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the coffee maker with a damp cloth.
2. **Placement:** Place the coffee maker on a flat, stable surface.
3. **Add Water:** Open the top lid and fill the detachable water tank with fresh, cold water up to the desired level (Max 5 cups). Close the lid securely.
4. **Add Coffee Grounds:** Place the reusable filter basket into the detachable funnel. Add your desired amount of ground coffee into the filter. For optimal taste, use approximately one scoop (provided) per cup.
5. **Position Carafe:** Place the empty glass carafe on the warming plate.



Three steps showing how to prepare the coffee maker: adding ground coffee to the filter basket, adding water to the water tank, and pressing the ON button to brew.

6. Operating Instructions

6.1. Brewing Coffee

1. Ensure the coffee maker is properly set up with water and coffee grounds.
2. Press the 'ON/OFF' button to start the brewing process. The indicator light will illuminate.
3. Coffee will begin to drip into the carafe.
4. Once brewing is complete, the coffee maker will automatically switch to the 'Keep Warm' function.

6.2. Timing and Reservation Function

This coffee machine features a programmable timer to set your desired brew time.

1. With the coffee maker plugged in and the carafe in place, press the 'PROG' button.

2. Use the 'HOUR' and 'MIN' buttons to set the desired brewing time.
3. Press 'PROG' again to confirm the setting. The timer indicator will light up.
4. The coffee maker will automatically start brewing at the programmed time.

COWSAR Professional Coffee Makers



Image illustrating the programmable timer function of the COWSAR coffee maker, showing a person sleeping at 11:00 PM and coffee ready at 7:00 AM.

6.3. 30-Second Grab-and-Go Auto Pause

The coffee maker allows you to pour a cup of coffee during the brewing process without mess. When the carafe is removed, the brewing process automatically pauses for 30 seconds. Replace the carafe within 30 seconds to resume brewing.



Image showing a hand pouring coffee from the carafe while the coffee maker is brewing, demonstrating the 30-second auto-pause feature.

6.4. 2-Hour Keep Warm Function & Auto Power Off

After brewing, the warming plate will keep your coffee hot for up to 2 hours. For safety and energy saving, the coffee maker will automatically power off after 2 hours of keeping warm.

2-Hour Keep Warm Function

Keeps Coffee Hot for 2 Hours with Automatic Shut-Off and Dry Boil Protection



COWSAR coffee maker with the warming plate glowing, indicating the 2-hour keep warm function is active.

7. Maintenance

7.1. Cleaning

- Always unplug the coffee maker before cleaning.
- Wash the carafe, reusable filter, and detachable funnel in warm, soapy water. These parts are not dishwasher safe.
- Wipe the exterior of the coffee maker with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- Empty the drip tray regularly.

7.2. Descaling

Over time, mineral deposits can build up in your coffee maker, affecting its performance. The coffee maker has a descaling reminder function. When the 'DESCALE' indicator lights up, it's time to descale the unit.

1. Fill the water tank with a mixture of white vinegar and water (1:2 ratio).
2. Place the empty carafe on the warming plate.
3. Press the 'DESCALE' button to start the descaling cycle.

4. After the cycle is complete, run 2-3 cycles with fresh, cold water to rinse thoroughly.

8. Troubleshooting

If you encounter any issues with your COWSAR coffee maker, please refer to the following common problems and solutions:

- **Coffee not brewing:** Ensure the unit is plugged in, the water tank is filled, and the carafe is correctly placed. Check if the 'ON/OFF' button has been pressed.
- **Weak coffee:** Increase the amount of coffee grounds or try a finer grind. Ensure the reusable filter is clean.
- **Overflowing filter basket:** Do not overfill the filter basket. Ensure the carafe is properly placed on the warming plate.
- **Water not heating:** Check if the unit is powered on. If the issue persists, contact customer support.
- **'ADD WATER' indicator:** Refill the water tank with fresh, cold water.

For issues not covered here, please contact COWSAR customer support.

9. Specifications

Feature	Detail
Brand	COWSAR
Capacity	5 Cups
Color	Black
Product Dimensions	9.45"D x 6.3"W x 10.08"H
Special Features	Auto Shut-Off, Portable, Programmable, Timer, 2H Keep Warm, Pause & Brew
Coffee Maker Type	Drip Coffee Machine
Operation Mode	Fully Automatic
Coffee Input Type	Ground
Power Source	AC adapter
Filter Type	Reusable
Item Weight	2.22 Pounds
Material	Plastic
Dishwasher Safe	No
Model Name	Drip Coffee Maker-CM3710H

10. Official Product Videos

Wake Up to Fresh Coffee - 5-Cup Coffee Maker with Timer & Auto Shut-Off

Your browser does not support the video tag.

This video demonstrates the features of the COWSAR 5-Cup Coffee Maker, including its timer function and auto shut-off, allowing users to wake up to freshly brewed coffee.

Small and compact

Your browser does not support the video tag.

This video highlights the compact size of the COWSAR coffee maker, showcasing its suitability for small spaces like dorms or offices.

11. Warranty & Support

COWSAR provides a **1-Year After-Sales Service** for this coffee machine. If you encounter any problems with your product, please contact customer service for assistance.

Customer Service Contact:

- Phone: 818-468-1528 or 661-435-8826 (8:30 AM - 5:30 PM P.S.T.)

Proof of purchase is required for warranty service.