

- Manuals.plus /
- › VINGLI /
- › VINGLI Fireplace TV Stand (Model DS0XMXJ) Instruction Manual

VINGLI DS0XMXJ

VINGLI Fireplace TV Stand (Model DS0XMXJ) Instruction Manual

Farmhouse Entertainment Center with Electric Fireplace and Adjustable Shelves

1. SETUP INSTRUCTIONS

1.1 Unpacking

Carefully unpack all components from the packaging. It is recommended to lay out all parts on a soft, clean surface to prevent scratches. Verify that all parts listed in the included parts list are present before beginning assembly. The item may be delivered in two separate packages, which might arrive at different times.

18 INCH Fireplace With Remote Control



(burn with or without heater)



The item will be delivered in **2** packages, and each may arrive at a different time.



Authentic
flame effect



0.5-6
Hours Timer



62°F-82°F



Seven Mesmerizing
Flame Colors



Overheating
protection



CSA Listed

Figure 1: Fireplace unit and packaging information. Note that the TV stand and fireplace may arrive in separate packages.

1.2 Assembly

This TV stand is designed for quick and straightforward assembly. Follow the detailed instructions provided in the separate assembly guide included with your product. Ensure all connections are secure before placing any items on the stand.

- Identify all components and hardware using the provided parts list.
- Assemble the main frame of the TV stand according to the step-by-step diagrams.
- Install the adjustable shelves as desired (refer to section 2.2 for options).
- Carefully insert the electric fireplace unit into the designated central compartment. Ensure it fits securely and is flush with the stand's frame.
- Confirm all screws and fasteners are tightened to ensure stability.



Figure 2: Fully assembled VINGLI Fireplace TV Stand with an electric fireplace and storage shelves.

2. OPERATING INSTRUCTIONS

2.1 Electric Fireplace Operation

The integrated electric fireplace provides both aesthetic flame effects and heating functionality. It can be operated using the control panel on the unit or the included remote control.

- **Power On/Off:** Press the power button on the unit or remote to turn the fireplace on or off.
- **Flame Colors:** Cycle through seven captivating flame colors to match your ambiance.
- **Temperature Control:** Adjust the heater temperature between 62°F and 82°F.
- **Timer Function:** Set the operational timer for 0.5 to 6 hours.
- **Safety Features:** The fireplace includes overheating protection and is CSA certified for safety.

18 INCH Fireplace With Remote Control



(burn with or without heater)



The item will be delivered in **2** packages, and each may arrive at a different time.



Authentic
flame effect



0.5-6
Hours Timer



62°F-82°F



Seven Mesmerizing
Flame Colors



Overheating
protection



CSA Listed

Figure 3: Detailed view of the electric fireplace controls and flame effects.

2.2 Storage and Adjustable Shelves

The TV stand features ample storage space with adjustable shelves to accommodate various media devices, accessories, and decorative items.

- The side compartments include adjustable shelves that can be moved up or down to create customized storage heights.
- Shelves can also be removed entirely for larger items or an open storage concept.
- The overall design includes unique criss-cross embellishments for a farmhouse aesthetic.

Personalized Storage Options

Flexible storage to meet your specific needs



Figure 4: Examples of personalized storage configurations with adjustable and removable shelves.

3. CARE AND MAINTENANCE

To ensure the longevity and appearance of your VINGLI Fireplace TV Stand, follow these care guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Promptly clean any spills to prevent staining.
- **Fireplace Unit:** Refer to the separate fireplace manual for specific cleaning and maintenance instructions for the electric insert. Ensure the unit is unplugged before cleaning.
- **Stability:** Periodically check all fasteners and tighten them if necessary to maintain structural integrity.

Meticulously Crafted Details



Refined and Elegant Surface
Waterproof and Scratch-resistant

Durable and Sturdy Base
Maximum weight capacity 420 LBS

Ample Storage Capacity
Flexible storage to meet your specific needs

Criss-Cross Embellishment
Graceful intersecting design

Figure 5: Close-up views highlighting the refined surface and durable construction of the TV stand.

4. TROUBLESHOOTING

This section addresses common issues you might encounter with your VINGLI Fireplace TV Stand.

Issue	Possible Cause	Solution
Fireplace unit does not fit correctly into the opening.	Incorrect orientation or obstruction.	Ensure the fireplace unit is oriented correctly according to the assembly instructions. Check for any packaging materials or debris obstructing the opening. If the issue persists, contact customer support.
Missing parts during assembly.	Packaging error or parts delivered separately.	Verify all packages have been received. Cross-reference the parts list with the contents. If parts are still missing, contact VINGLI customer support immediately for assistance.

Issue	Possible Cause	Solution
Fireplace does not power on.	Power supply issue or unit not plugged in.	Ensure the fireplace is securely plugged into a functional power outlet. Check the power switch on the unit. Refer to the separate fireplace manual for specific electrical troubleshooting.
Stand feels unstable after assembly.	Loose fasteners.	Re-check and tighten all screws and connections according to the assembly instructions. Ensure the stand is placed on a level surface.

5. PRODUCT SPECIFICATIONS

Detailed specifications for the VINGLI Fireplace TV Stand (Model DS0XMXJ):

Feature	Detail
Brand	VINGLI
Model Name	Fireplace TV Stand
Model Number	DS0XMXJ
Material	Engineered Wood, Metal
Style	Modern Farmhouse
Color	Natural Oak
Product Dimensions (W x D x H)	58.66 x 15.75 x 23.62 inches
Item Weight	75.6 Pounds
Maximum TV Size Supported	Up to 70 inches
Maximum Load Capacity	420 lbs
Fireplace Features	7 Flame Colors, 62°F-82°F Temperature Range, 0.5-6 Hour Timer, Overheating Protection, CSA Certified
Included Components	Fireplace, TV Stand, Instruction Manual



Figure 6: Visual representation of TV size compatibility up to 70 inches.

6. WARRANTY AND CUSTOMER SUPPORT

VINGLI is committed to providing quality products and excellent customer service.

- **Warranty:** This product comes with a 1-year quality service warranty.
- **Customer Support:** For any inquiries, concerns, or assistance with assembly or product issues, please contact VINGLI customer service. Refer to your purchase documentation for specific contact details or visit the official VINGLI website.



Refined and Elegant Surface



Adjustable and Removable Shelves



Robust Support Legs



Criss-Cross Embellishment



We Stand Behind Our Products

VINGLI values your shopping experience. Reach out for a resolution to any issues.



1-year
Quality Service



24/7 Professional
Quality Service

Figure 7: VINGLI's commitment to customer satisfaction and support.

© 2024 VINGLI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DK95RCBT>

More documents and user manuals: <https://manuals.plus/>