



[Manuals.plus](#) /

› [LINSY HOME](#) /

› LINSY HOME TV Stand Model B0F2SSR4VV Instruction Manual

LINSY HOME B0F2SSR4VV

LINSY HOME TV Stand Instruction Manual

Model: B0F2SSR4VV

INTRODUCTION

Thank you for choosing the LINSY HOME TV Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new entertainment center. Please read these instructions thoroughly before beginning assembly and retain them for future reference.



Image: The LINSY HOME TV Stand, white, with a television placed on its top surface. The stand features glass-front cabinets and open shelving, decorated with various household items, showcasing its storage and display capabilities.

Safety Information

Warning: This product requires assembly. Always use proper lifting techniques when handling heavy items to prevent injury. Do not exceed the weight limit of the product. Keep away from children and pets.

- Ensure all parts are present and undamaged before assembly.
- Assemble on a soft, clean surface to prevent scratches.
- Do not overtighten screws, as this may damage the material.
- Periodically check all connections to ensure they remain tight.
- Place the TV stand on a level surface to prevent tipping.
- The maximum weight capacity for this unit is 360 lbs. Do not exceed this limit.

Package Contents

Please verify that all the following components are included in your package:

- Wood Panels (Top, Bottom, Side, Back, Shelves)
- Glass Doors with Hinges
- Door Handles and Screws
- Assembly Hardware (screws, dowels, cam locks, etc.)
- LED Light Strip
- LED Remote Control
- Instruction Manual

ASSEMBLY INSTRUCTIONS

This TV stand requires assembly. Detailed, step-by-step instructions are included in your package. For optimal efficiency and safety, it is recommended that two people assemble this product.

1. **Preparation:** Clear a spacious area for assembly. Lay out all components and hardware.
2. **Follow the Manual:** Refer to the separate, detailed assembly manual provided with your product for specific steps and diagrams.
3. **Hardware:** Use the correct hardware for each step as indicated in the manual.
4. **Door Installation:** Pay close attention to door hinge alignment during installation to ensure smooth opening and closing.
5. **LED Strip:** Install the LED light strip as directed in the assembly guide.

If you encounter any difficulties during assembly, please refer to the troubleshooting section or contact customer support.

PRODUCT FEATURES

LED Lighting System

The integrated LED lighting system offers 6 vibrant colors and 22 dynamic flashing modes. Control the lighting easily via the included remote or a compatible app, allowing you to adjust the ambiance to suit various moods or occasions.



Image: A remote control is held in hand, demonstrating its use to change the color of the LED lights installed within the shelves of the TV stand, which are currently glowing green.

Storage and Design

Measuring 68 inches in length, this TV stand is designed to accommodate televisions up to 75 inches. It features a central storage cabinet with stylish glass doors and two open shelves on each side, providing ample space for media devices, game consoles, and decorative items.

AMPLE STORAGE SPACE



Image: The LINSY HOME TV Stand with its glass doors open, showcasing the interior storage compartments and adjustable shelves, filled with books, baskets, and other media accessories.

Construction and Durability

Constructed from high-quality engineered wood, the entertainment center features a 3.15-inch thick base and reinforced bottom slats. This design ensures stability and durability, supporting a weight capacity of up to 360 lbs and minimizing wobbling.

Premium Desktop



Wear-resistant



Easy to Clean



Smooth Texture




Image: A close-up view of the TV stand's top surface, demonstrating its premium desktop features: wear-resistant, easy to clean, and smooth texture, with a small water spill indicating its water-resistant properties.

SETUP AND PLACEMENT

Once assembled, carefully place the TV stand in your desired location. Ensure the floor is level and stable. The stand is designed for freestanding installation.

- **Location:** Choose a location that is dry, level, and away from direct sunlight or heat sources.
- **Cable Management:** Utilize the pre-drilled holes in the back panel for organized cable routing to keep wires tidy and out of sight.
- **TV Placement:** Center your television on the top surface. Ensure the TV base fits securely within the dimensions of the stand.

Product Size



Weight Capacity
Max: 360 lbs




Image: A detailed diagram illustrating the dimensions of the LINSY HOME TV Stand (68" W x 15.7" D x 23.6" H) and its capacity to hold TVs up to 75 inches, with a maximum weight capacity of 360 lbs.

OPERATING INSTRUCTIONS

LED Light Operation

The LED lights are controlled by the included remote control or a compatible smartphone application.

- **Power On/Off:** Press the 'On' or 'Off' button on the remote to activate or deactivate the lights.
- **Color Selection:** Use the color buttons (R, G, B, W, Y, C, P, O) to select a static color.
- **Dynamic Modes:** Press 'MODE+' or 'MODE-' to cycle through the 22 dynamic flashing modes.
- **Brightness Adjustment:** Use the sun icons (brighter/dimmer) to adjust the light intensity.
- **Speed Adjustment:** In dynamic modes, use 'SPEED+' or 'SPEED-' to change the speed of the effects.
- **App Control:** Refer to the LED light strip's specific instructions for pairing with a smartphone app, if applicable.

MAINTENANCE

Proper care will extend the life and appearance of your TV stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Clean spills immediately to prevent staining or damage to the engineered wood.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Hardware Check:** Periodically inspect all screws and connections and tighten if necessary.
- **LED Lights:** If LED lights malfunction, check connections. If issues persist, contact customer support.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Doors are misaligned or rub	Hinges not adjusted correctly or panels not perfectly aligned during assembly.	Adjust the door hinges. Most hinges allow for minor adjustments using a screwdriver to align the doors properly. Refer to the assembly manual for hinge adjustment details.
LED lights do not turn on or function incorrectly	Loose connection, remote battery low, or LED strip malfunction.	Check all power connections to the LED strip. Replace the remote control battery. Ensure the remote is pointed directly at the receiver. If issues persist, contact customer support.
LED colors appear inaccurate (e.g., yellow looks green, white looks blue)	Color calibration or limitations of the LED technology.	Some LED strips may have slight variations in color representation. Try adjusting brightness levels, as this can sometimes affect perceived color. This may be a characteristic of the product.
Missing pre-drilled holes for back panel or other components	Manufacturing inconsistency.	If you possess the appropriate tools and expertise, you may carefully drill pilot holes. Otherwise, contact customer support for assistance or replacement parts.
Stand wobbles after assembly	Uneven floor or loose connections.	Ensure the stand is on a level surface. Check and tighten all assembly hardware.

SPECIFICATIONS

Feature	Detail
Brand	LINSY HOME
Model Number	B0F2SSR4VV
Color	White
Product Dimensions	15.7"D x 68"W x 23.6"H
Recommended TV Size	Up to 75 inches
Weight Limit	360 Pounds
Material	Engineered Wood
Special Feature	LED Lights (6 colors, 22 modes)

Feature	Detail
Mounting Type	Floor Mount (Freestanding)
Door Style	Glass Front
Number of Shelves	2 (adjustable)
Item Weight	97 Pounds
Assembly Required	Yes

WARRANTY AND SUPPORT

For warranty information, missing parts, or any product-related inquiries, please contact LINSY HOME customer service directly. Refer to the contact details provided in your product packaging or on the official LINSY HOME website.