Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sluban 00870

Sluban City Fishing Boat Building Set (Model 00870) Instruction Manual

Your guide to assembling and enjoying your Sluban City Fishing Boat with Shark Toys.

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Sluban City Fishing Boat Building Set, Model 00870. This set includes 592 pieces, allowing you to construct a detailed fishing boat complete with three minifigures and shark toys. It is designed for builders aged 6 years and up.

The Sluban City Fishing Boat is an intricate model featuring a fully equipped control room, functional propeller, fishing rods, and barrels. Once assembled, it serves as both an engaging toy and an impressive display piece.



Image 1.1: The fully assembled Sluban City Fishing Boat with accompanying shark toy.

2. Setup and Assembly

Follow the step-by-step instructions provided in the included instruction booklet to assemble your Sluban City Fishing Boat. Ensure all 592 pieces are accounted for before beginning assembly. The building process is designed to be straightforward and enjoyable.

2.1 Key Assembly Features

- **Detailed Hull Construction:** Begin by assembling the base and hull of the fishing boat.
- **Functional Elements:** Integrate the propeller mechanism and ensure it can rotate freely.
- **Control Room:** Construct the cockpit area, which includes a steering wheel and dashboard details.
- **Deck Accessories:** Attach fishing rods, barrels, and other deck equipment.
- **Minifigure Placement:** Position the three included minifigures (captain, fisherman, crew member) in their designated areas.




Image 2.1: The removable cockpit section, revealing interior details.




Image 2.2: Interior view of the boat's cabin, featuring a clock and sleeping area.



Image 2.3: Barrels on the deck, designed for storing fish.



Image 2.4: The barrels can be easily removed from the deck.

3. Operating the Building Set

Once assembled, the Sluban City Fishing Boat offers various interactive features for play and display:

- **Minifigure Interaction:** Place the captain in the control room, and the fishermen on deck. The minifigures are designed to fit securely into the building blocks.
- **Movable Parts:** The boat features a functional propeller at the stern. The fishing rods can be positioned to simulate fishing.
- **Accessory Play:** Utilize the included shark toys for imaginative play scenarios. The barrels can be used for storing fish pieces.
- **Display:** The completed model is suitable for display on a shelf or desk, showcasing its detailed craftsmanship.



Image 3.1: The three minifigures: Captain, Fisherman, and Crew Member.




Image 3.2: Detailed view of the fishing equipment and storage on the boat.

Your browser does not support the video tag.

Video 3.1: A short demonstration of the Sluban City Fishing Boat building set, highlighting its features and minifigures.

4. Maintenance

To ensure the longevity and cleanliness of your Sluban City Fishing Boat Building Set, follow these simple maintenance guidelines:

- **Cleaning:** Dust the model regularly with a soft, dry cloth. For deeper cleaning, gently wipe with a damp cloth and mild soap, then rinse with clean water and air dry completely. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the building set in a cool, dry place away from direct sunlight to prevent discoloration or warping of plastic components. Keep small pieces in a sealed container to prevent loss.
- **Handling:** Handle the assembled model with care to avoid accidental disassembly or damage to delicate parts.

5. Troubleshooting

If you encounter any issues during assembly or with your Sluban City Fishing Boat Building Set, please refer to the following common solutions:

- **Missing or Damaged Parts:** If any parts are missing or damaged upon opening the package, please contact Sluban customer support immediately. Refer to the "Customer Support" section for contact information.
- **Difficulty Assembling:** Double-check the instruction manual for the specific step you are on. Ensure you are using the correct pieces and that they are oriented correctly. Building blocks require firm but gentle pressure to connect.
- **Loose Connections:** If pieces are not holding together firmly, ensure they are fully pressed into place. Sometimes, a slight twist can help secure interlocking blocks.

6. Specifications

Key specifications for the Sluban City Fishing Boat Building Set, Model 00870:

Feature	Detail
Brand	Sluban
Model Name	City Fishing Boat
Model Number	00870
Number of Pieces	592
Material Type	Plastic
Recommended Age	6 years and up
Item Dimensions (L x W x H)	1.97 x 3.94 x 5.91 inches (assembled model)
Item Weight	0.6 kg
Included Components	Building blocks, 3 minifigures, shark toys, instruction manual
Additional Features	Working Propeller, Interactive Control Room, Shark Toys



Image 6.1: Approximate dimensions of the assembled fishing boat.

7. Warranty and Customer Support

Sluban is committed to your satisfaction. This product is covered by a standard return policy, allowing for refunds or replacements within 30 days of purchase, subject to retailer terms.

For any inquiries regarding missing or damaged parts, or for assistance with assembly, please contact our customer support team. We will promptly send you replacement parts to ensure your building set is complete and ready for enjoyment.

Customer Support Contact: Please refer to the contact information provided on the product packaging or the official Sluban website for the most up-to-date support channels.
You can also visit the Sluban Store on Amazon for more information and products.

© 2023 Sluban. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DKBPXPXW

More documents and user manuals: **https://manuals.plus/**