

8223656334423887

Sporty Hanging Ear Bluetooth Earphones User Manual

Model: 8223656334423887 | Brand: Generic

1. INTRODUCTION

Thank you for choosing the Sporty Hanging Ear Bluetooth Earphones. These earphones are designed for comfort and performance, featuring Bluetooth 5.4 for stable connections and IPX5 waterproofing, making them ideal for sports and daily use. Additionally, they incorporate advanced features for real-time language translation, enhancing communication in diverse environments. Please read this manual carefully to ensure proper use and maintenance of your device.

2. PACKAGE CONTENTS

- 1 × Sporty Hanging Ear Bluetooth Earphones (Left and Right)
- 1 × Charging Case
- 1 × Type-C Charging Cable
- 1 × User Manual

3. SPECIFICATIONS

Color	Black (Also available in White, Beige)
Bluetooth Version	5.4
Receiving Distance	Up to 15m
Earphone Battery Capacity	60 mAh (each earphone)
Charging Case Battery Capacity	300 mAh
Charging Interface	Type-C
Charging Time	Approximately 1 hour
Battery Life (Earphones)	More than 8 hours
Waterproof Rating	IPX5

4. SETUP

4.1 Charging the Earphones and Case

Before first use, fully charge the earphones and the charging case. Place the earphones into the charging case and connect the Type-C cable to the charging port on the case. Connect the other end to a USB power source.



Image: The earphones securely placed within their charging case, indicating the charging process. The image also highlights the IPX5 waterproof capability with water splashes.

4.2 Bluetooth Pairing

1. Ensure the earphones are charged.
2. Open the charging case. The earphones will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.

4. Search for available Bluetooth devices and select "Sporty Earphones" (or similar name) from the list.
5. Once connected, a voice prompt will confirm successful pairing.

5D panoramic audio matrix

Full-dimensional perception of high-pitched sound waves

The ultra-high frequency transient response hardware unit is used to achieve high-resolution sound quality and bring a sensory experience that breaks through the senses, just like being at the performance site.




Image: A visual representation of the Bluetooth 5.3 chip (note: product uses 5.4) emphasizing stable and continuous connection for reliable audio performance.

5. OPERATING INSTRUCTIONS

5.1 Wearing the Earphones

These earphones feature a hanging ear design for a secure and comfortable fit, especially during physical activity. Gently place the earbud into your ear canal and loop the hanging part over the top of your ear.



Image: A person demonstrating the ergonomic fit of the hanging ear earphones, alongside smaller images showing usage during running and working on a laptop.

5.2 Basic Earphone Controls

The earphones are equipped with touch controls for easy management of audio and calls. Specific touch gestures may vary, but common functions include:

- **Single Tap:** Play/Pause music, Answer/End call.
- **Double Tap (Left/Right):** Previous/Next track.
- **Long Press:** Activate voice assistant, Reject call.

5.3 Advanced Translation Features

These earphones offer real-time two-way translation capabilities, supporting 144 languages and 8 offline modes. To utilize these features, you may need to download a dedicated translation application on your smartphone and connect the earphones via Bluetooth.

- **Real-Time Translation:** Speak into the earphone's microphone, and the translated audio will play through the other earphone or your connected device.
- **Offline Modes:** For major languages like Chinese, English, Japanese, Korean, Russian, German, French, and Spanish, translation can occur without an internet connection.
- **Versatile Modes:** Includes Free Chat, Offline Translation, Audio Transcription, and Image Translation (via the companion app).

Natural and Instant Translation Traducción natural e instantánea



Image: Two earphones displayed with various language greetings around them, illustrating the natural and instant translation

capabilities.

5.4 Sound Quality

Experience high-quality audio with crystal-clear sound for both music and conversations. The earphones are designed to provide a full-dimensional perception of high-pitched sound waves, delivering a rich sensory experience.

Bluetooth 5.3 chip

Stable and continuous connection, more stable

Using the innovative Bluetooth 5.3 chip, music calls tend to have zero delay, power consumption is lower and more power-saving, calls are more stable, the sound is clearer, and performance is stable and greatly improved in all aspects.



Image: A diagram illustrating the "5D panoramic audio matrix" concept, showing sound waves emanating from an earbud around a human head, indicating immersive sound.




Image: An exploded view of an earbud, showcasing its internal components such as the speaker, diaphragm, and other acoustic elements, highlighting the sound technology.

6. MAINTENANCE

6.1 Cleaning

Regularly clean the earphones and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents. For earwax buildup, gently clean the earbud mesh with a small, soft brush.

6.2 Waterproof Care (IPX5)

The earphones are IPX5 waterproof, meaning they are resistant to splashes and sweat. They are not designed for submersion. Do not expose them to running water or wear them while swimming. Ensure the charging port is dry before charging.



Image: The charging case and earphones partially submerged in water, visually representing their IPX5 waterproof rating and durability against splashes.

6.3 Storage

When not in use, store the earphones in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

7. TROUBLESHOOTING

7.1 Earphones Not Pairing

- Ensure earphones are charged.
- Turn off and on Bluetooth on your device.
- Forget the device in your Bluetooth settings and try pairing again.
- Restart your device.

7.2 No Sound

- Check volume levels on both earphones and your connected device.
- Ensure earphones are properly connected to your device.
- Try playing different audio sources.

7.3 Charging Issues

- Ensure the charging cable is securely connected.
- Try a different USB power adapter or port.
- Clean the charging contacts on the earphones and inside the case.

8. WARRANTY INFORMATION

This product comes with a standard manufacturer's warranty. Please refer to the product packaging or retailer's website for specific warranty terms and conditions. Keep your proof of purchase for warranty claims.

9. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Sporty Hanging Ear Bluetooth Earphones, please contact the retailer or manufacturer directly. Contact information can typically be found on the product packaging or the brand's official website.