

Logitech M750 L

Logitech Signature Plus M750 L Wireless Mouse User Manual

Model: M750 L (P/N: 910-007508)

INTRODUCTION

The Logitech Signature Plus M750 L Wireless Mouse is designed to enhance your productivity and comfort. Featuring SmartWheel scrolling for precision or speed, a contoured shape for large hands, and multi-device connectivity, this mouse offers a seamless user experience. Its SilentTouch technology ensures quiet operation, making it ideal for any environment.



Figure 1: Logitech Signature Plus M750 L Wireless Mouse (Graphite)

WHAT'S IN THE Box

- Logitech Signature Plus M750 L Wireless Mouse
- Logi Bolt USB Receiver
- 1 AA Battery (pre-installed or included separately)
- User Documentation

In the box



Figure 2: Included components: mouse, AA battery, and Logi Bolt USB receiver.

SETUP

1. Battery Installation

The Logitech Signature Plus M750 L mouse operates on a single AA battery, which is typically included. If the battery is not pre-installed, locate the battery compartment on the underside of the mouse, open it, and insert the AA battery, ensuring correct polarity (+/-). Close the compartment securely.

2. Connectivity Options

Your mouse offers two primary connection methods: Logi Bolt USB Receiver or Bluetooth Low Energy Wireless

Technology.

Using the Logi Bolt USB Receiver:

1. Locate the Logi Bolt USB receiver. It may be stored inside the mouse's battery compartment or included separately in the packaging.
2. Plug the Logi Bolt USB receiver into an available USB-A port on your computer.
3. Turn on your mouse. The mouse should automatically connect to the receiver.

Using Bluetooth Low Energy:

1. Ensure Bluetooth is enabled on your computer or device.
2. Turn on your mouse.
3. Press and hold the Easy-Switch button (usually on the underside or side of the mouse) until the LED indicator starts blinking rapidly, indicating pairing mode.
4. On your device, go to Bluetooth settings and select "Logitech M750 L" from the list of available devices to pair.
5. Follow any on-screen prompts to complete the pairing process.

Connect via Bluetooth or Logi Bolt USB receiver



Figure 3: Connect via Bluetooth or Logi Bolt USB receiver.

OPERATING INSTRUCTIONS

SmartWheel Scrolling

The SmartWheel automatically switches between line-by-line precision scrolling and super-fast free-spinning scrolling. This allows for precise navigation in documents and rapid movement through long web pages. Simply flick the wheel to engage the desired mode.



Figure 4: Precision and speed scrolling with SmartWheel.

Silent Clicks

The Signature Plus M750 L features SilentTouch technology, reducing click noise by over 90% compared to traditional Logitech mice. This provides a quieter working environment without compromising click feel.

90% less clicking noise



Figure 5: Enjoy 90% less clicking noise with SilentTouch technology.

Customizable Side Buttons

The side buttons on your mouse can be customized to perform your favorite shortcuts, such as back/forward navigation or copy/paste functions. To customize these buttons, download and install the Logitech Options+ software, available for Windows and macOS.

Download Logitech Options+ from: [Logitech Official Website](https://www.logitech.com/en-us/Products/Software/Logitech-Options-Software)

Customize buttons to your favorite shortcuts




Figure 6: Customize buttons to your favorite shortcuts using Logitech Options+.

Easy-Switch Multi-Device Functionality

The Easy-Switch feature allows you to pair and switch between up to three different Bluetooth devices seamlessly. This is ideal for users who work across multiple computers or tablets.

Additionally, with Logitech Flow enabled (requires Logitech Options+), you can effortlessly transfer text, images, and files between Windows and macOS operating systems by simply moving your cursor from one screen to another.

Ergonomic Design

The Signature Plus M750 L is designed for large hands, featuring a contoured shape, soft thumb area, and rubber side grips to provide long hours of comfort and reduce hand fatigue.



Comfort shape and feel
with rubber side grips

Figure 7: Comfort shape and feel with rubber side grips.

MAINTENANCE

Cleaning Your Mouse

To maintain optimal performance and hygiene, regularly clean your mouse. Use a soft, lint-free cloth lightly dampened with water or a mild, non-abrasive cleaner. Avoid harsh chemicals or abrasive materials that could damage the surface.

Battery Replacement

The Logitech Signature Plus M750 L mouse boasts an impressive battery life of up to 24 months on a single AA battery. When the battery level is low, the LED indicator on the mouse may change color or blink. To replace the battery:

1. Turn off the mouse.
2. Locate and open the battery compartment cover on the underside of the mouse.
3. Remove the old AA battery.

4. Insert a new AA battery, ensuring the correct positive (+) and negative (-) orientation.
5. Close the battery compartment cover securely.
6. Turn on the mouse.

TROUBLESHOOTING

Issue	Possible Solution
Mouse not responding	<p>Ensure the mouse is turned on.</p> <p>Check battery level and replace if necessary.</p> <p>For Logi Bolt: Ensure the USB receiver is securely plugged into a working USB port. Try a different USB port.</p> <p>For Bluetooth: Ensure Bluetooth is enabled on your device and the mouse is paired. Try re-pairing the mouse.</p> <p>Move the mouse closer to the receiver/device to reduce interference.</p>
Intermittent connection	<p>Reduce wireless interference by moving other wireless devices away.</p> <p>Ensure the mouse is within the effective range (up to 10 meters).</p> <p>Update your computer's Bluetooth drivers or Logi Bolt software.</p>
SmartWheel not switching modes	<p>Ensure the SmartWheel is clean and free of debris.</p> <p>Restart your computer and mouse.</p> <p>Check Logitech Options+ settings for any conflicting configurations.</p>
Side buttons not working	<p>Ensure Logitech Options+ software is installed and running.</p> <p>Verify button assignments within Logitech Options+.</p> <p>Restart the Logitech Options+ application.</p>

SPECIFICATIONS

Feature	Detail
Model Number	910-007508
Connectivity	Logi Bolt USB Receiver, Bluetooth Low Energy Wireless Technology
Wireless Range	Up to 10 meters (33 feet)
Sensor Technology	Optical Tracking
Battery Type	1 x AA battery (included)
Battery Life	Up to 24 months (may vary based on user and computing conditions)
Buttons	6 (Left/Right-click, Back/Forward, Middle button, Scroll-wheel with SmartWheel)
Dimensions (H x W x D)	118.19 mm x 65.63 mm x 41.52 mm (4.65 in x 2.58 in x 1.64 in)

Feature	Detail
Weight (with battery)	111.2 g (3.93 oz)
Color	Graphite
System Requirements	Windows 10, 11 or later; macOS 10.10 or later; Linux 4; ChromeOS 4; iPadOS 13.4 or later; Android 8.0 or later

Dimensions

118.19 mm
(4.65 in)



65.63 mm
(2.58 in)



41.52 mm
(1.64 in)

Weight (with receiver and battery): 117 g (4.13 oz)

Figure 8: Mouse dimensions.



Figure 9: Key features overview.

WARRANTY AND SUPPORT

For detailed warranty information and technical support, please visit the official Logitech support website. You can find FAQs, troubleshooting guides, driver downloads, and contact information for customer service.




Logitech Support: <https://support.logi.com/>

Product registration is recommended to receive updates and support.

© 2025 Logitech. All rights reserved.

Logitech, Logi, and their respective logos are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries.

Related Documents - M750 L

	<p>Logitech Signature M650 Getting Started Guide</p> <p>A comprehensive guide to setting up and using the Logitech Signature M650 wireless mouse, including pairing, software installation, button customization, and battery information.</p>
	<p>Logitech Signature M750/M750L Mouse: Setup, Features, and Usage Guide</p> <p>Comprehensive guide to setting up and using the Logitech Signature M750 and M750L mice, covering Bluetooth and Logi Bolt pairing, SmartWheel functionality, gesture controls, Logitech Flow, and battery information.</p>
	<p>Logitech LIFT Vertical Ergonomic Mouse User Guide and Setup</p> <p>Comprehensive guide to setting up, connecting, and using the Logitech LIFT Vertical Ergonomic Mouse. Learn about its features like SmartWheel, Easy-Switch, and Logitech Flow.</p>
	<p>Logitech MX Master 3S Getting Started Guide</p> <p>A comprehensive guide to setting up and using the Logitech MX Master 3S wireless mouse, covering detailed setup, pairing with multiple computers, button customization, gesture controls, and battery management.</p>
	<p>Logitech POP Keys and POP Mouse Setup and Customization Guide</p> <p>A comprehensive guide to setting up, pairing, and customizing your Logitech POP Keys keyboard and POP Mouse, including multi-device setup and emoji key customization.</p>
 <p>User Manual of Product 1: Logitech Lift Vertical Ergonomic Mouse, Wireless, Bluetooth or Logi Bolt, Left-handed, Right-handed, Compatible with Windows/macOS/iPadOS, Laptop, PC - Graphite</p> <p>User Manual of Product 2: Logitech Lift Vertical Ergonomic Mouse, Left-handed, Wireless, Bluetooth, Logi Bolt, Graphite, Gunmetal, Graphite, Left-handed, Right-handed, Compatible with Windows/macOS/iPadOS, Laptop, PC - Graphite</p>	<p>Logitech Lift Vertical Ergonomic Mouse: User Manual and Features</p> <p>A comprehensive user manual for the Logitech Lift Vertical Ergonomic Mouse. Learn about its ergonomic design, connectivity options (Bluetooth, Logi Bolt), SmartWheel functionality, Logitech Options+ software, and how to set it up for Windows, macOS, and iPadOS. Covers both standard and left-handed variants.</p>