

[Manuals.plus](#) /

› [Portronics](#) /

› Portronics Talk Five 3W Wearable Bluetooth Speaker User Manual

Portronics Talk Five (POR-2713)

Portronics Talk Five 3W Wearable Bluetooth Speaker User Manual

WELCOME

Thank you for choosing the Portronics Talk Five 3W Wearable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your device. Please read it carefully to ensure optimal performance and longevity of your speaker.

PRODUCT OVERVIEW

Package Contents

- 1 x Portronics Talk Five Bluetooth Speaker
- 1 x USB Type-C Charging Cable
- 1 x User Documentation (this manual)

Key Features

- **3W Audio Output:** Delivers clear and robust sound.
- **Wearable Design:** Features a versatile spring clip for secure attachment to various surfaces.
- **Bluetooth 5.3 Connectivity:** Ensures fast pairing, extended range, and stable wireless connection.
- **Integrated Microphone:** Allows for hands-free calling.
- **IPX5 Water & Dust Resistance:** Protects against splashes, sweat, and dust, suitable for outdoor use.
- **Intuitive Button Controls:** Large, tactile buttons for easy operation of playback, volume, and calls.
- **Up to 10 Hours Playtime:** Extended battery life for continuous audio enjoyment.
- **Type-C Fast Charging:** Convenient and quick recharging.
- **Lightweight:** Weighs approximately 83g for ultra-portability.

Product Diagram




This image displays the Portronics Talk Five speaker held in a hand, showcasing its compact, rectangular design with a black grille and a red speaker mesh visible underneath. The spring clip is visible at the top.

SETUP INSTRUCTIONS

1. Charging the Speaker

1. Locate the USB Type-C charging port on the side of the speaker.
2. Open the protective cover of the Type-C port.
3. Connect the provided USB Type-C cable to the speaker and the other end to a compatible USB power adapter (not included) or a computer's USB port.
4. The LED indicator will illuminate during charging and turn off once fully charged.
5. A full charge typically takes approximately 1.5-2 hours.



This image provides a detailed view of the USB Type-C charging port on the Portronics Talk Five speaker, with the protective flap open, indicating its fast charging capability.

2. Powering On/Off

1. **To Power On:** Press and hold the Power button (usually marked with 'O' or a power symbol) for approximately 3 seconds until you hear an audible prompt and the LED indicator lights up.
2. **To Power Off:** Press and hold the Power button for approximately 3 seconds until you hear an audible prompt and the LED indicator turns off.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode. The LED indicator will typically flash rapidly (e.g., blue) to indicate it's ready to pair.
2. On your smartphone or Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for available devices. You should see "Talk Five" in the list.
4. Select "Talk Five" to connect. Once successfully paired, you will hear a confirmation sound, and the LED indicator

will typically stop flashing and remain solid (e.g., blue).

5. If prompted for a password, enter "0000".
6. The speaker will automatically attempt to reconnect to the last paired device when powered on.



This image illustrates the Bluetooth pairing process, showing a smartphone screen with the Bluetooth settings menu open, and 'Talk Five' successfully connected under 'MY DEVICES'.

OPERATING INSTRUCTIONS

Basic Controls

The Portronics Talk Five speaker features intuitive buttons for easy control:

- **Power Button (O):**
 - Press and hold for 3 seconds to Power On/Off.
 - Short press to Play/Pause music.

- Short press to Answer/End a phone call.
- Press and hold for 2 seconds to Reject an incoming call.
- Double press to Redial the last number.

- **Volume Up Button (+):**

- Short press to increase volume.
- Double press to skip to the next track.

- **Volume Down Button (-):**

- Short press to decrease volume.
- Double press to skip to the previous track.

Easy Button Control



Spring Clip Does not Bounce



This image provides a clear view of the large, tactile control buttons on the side of the Portronics Talk Five speaker, including the volume up (+), power/play/pause (O), and volume down (-) buttons, designed for easy operation.

Wearing the Speaker

The versatile spring clip allows you to attach the Talk Five speaker to various items:

- **Clothing:** Clip it to your shirt collar, pocket, or waistband.
- **Bags:** Attach it to backpack straps or bag handles.
- **Other Surfaces:** Secure it to thin branches, tent poles, or other suitable objects.

Ensure the clip is firmly attached to prevent the speaker from falling during activity.



This image shows the Portronics Talk Five speaker clipped securely to a person's shirt collar, demonstrating its wearable design and how it can be used hands-free.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The speaker is IPX5 water-resistant, meaning it can withstand splashes and light rain. Do not submerge the speaker in water. Ensure the Type-C charging port cover is securely closed to maintain water resistance.

- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use for extended periods.

IPX5 Water Resistant



 Sweatproof

 Splashproof

 Rainproof

This image depicts the Portronics Talk Five speaker with water splashing around it, visually confirming its IPX5 water-resistant rating, making it suitable for use in various outdoor conditions.

TROUBLESHOOTING

If you encounter any issues with your Portronics Talk Five speaker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker using the provided USB Type-C cable.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; Bluetooth disabled on device; device too far.	Ensure speaker is powered on and LED is flashing rapidly. Enable Bluetooth on your device. Move device closer to the speaker (within 10 meters). Forget "Talk Five" from your device's Bluetooth list and try pairing again.
No sound or low volume.	Volume too low on speaker or connected device; speaker not connected.	Increase volume on both the speaker and your connected device. Ensure the speaker is successfully paired and connected.
Sound distortion.	Volume too high; low battery; interference.	Reduce volume. Charge the speaker. Move away from sources of interference (e.g., Wi-Fi routers, other Bluetooth devices).
Call quality issues.	Microphone obstructed; poor network signal.	Ensure the microphone is not covered. Check your phone's network signal.

SPECIFICATIONS

Feature	Detail
Model Name	Talk Five
Model Number	POR-2713
Speaker Type	Portable Speaker
Audio Output Power	3 Watts
Connectivity Technology	Bluetooth 5.3
Bluetooth Range	Up to 10 meters (33 feet)
Water Resistance Rating	IPX5
Playtime	Up to 10 Hours (at 80% volume)
Charging Port	USB Type-C
Battery Type	Lithium Polymer
Charging Time	Approx. 1.5 - 2 hours
Material	ABS Plastic
Dimensions (L x W x H)	119D x 40W x 83H Millimeters
Weight	110 Grams
Included Components	1N Bluetooth Speaker, 1N Charging Cable, 1N Documentation

WARRANTY AND SUPPORT

Portronics products are designed for reliability and performance. This product is covered by a standard manufacturer's warranty against defects in materials and workmanship from the date of purchase.

For warranty claims, technical support, or any inquiries, please contact Portronics customer service:

- **Email:** help@portronics.com
- **Phone:** +91 9555-245-245
- **Manufacturer Address:** Portronics Digital Pvt Ltd, First Floor Property No D 8 Upper Basement Sector 8 Noida Uttar Pradesh 201301, India.

Please retain your proof of purchase for warranty validation.