

[Manuals.plus](#) /

> [WLIVE](#) /

> WLIVE Rattan 5-Drawer Dresser User Manual

WLIVE ASNG119

WLIVE Rattan 5-Drawer Dresser

USER MANUAL

Model: ASNG119

1. Introduction

Thank you for choosing the WLIVE Rattan 5-Drawer Dresser. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure safe and efficient use of your new furniture. Please read it thoroughly before beginning assembly or use.





Figure 1.1: WLIVE Rattan 5-Drawer Dresser, Light Oak

2. Key Features

- **Boho Design:** Features light wood with a natural wood texture and warm color, complemented by rattan-textured drawer fronts and smooth gold metal handles.
- **Spacious Storage:** Equipped with 5 large, deep drawers to maximize storage for various items, helping to keep your room organized.
- **Stable Structure:** Designed with a middle support plate for enhanced stability and load capacity.
- **Smooth Operation:** Drawers utilize smooth metal slides, allowing them to open fully without tipping.
- **Durable Construction:** Crafted from durable engineered wood for long-term use and scratch resistance.
- **Safety Features:** Includes an anti-tipping device to prevent accidental tipping, ensuring safety for family members and pets.



Figure 2.1: Detailed view of handles, rattan material, smooth gliding system, and sturdy base supports.

THE DRESSER CAN HOLD



Toys
15+



Snacks
50+



Clothes
25+



Stationery
40+



Diaper
30+



Socks
50+



Figure 2.2: Example storage capacity for toys, snacks, clothes, stationery, diapers, and socks.

3. Setup and Assembly

Assembly of the WLIVE Rattan 5-Drawer Dresser is required. The package includes detailed installation instructions, and all parts and accessories are coded for easy identification. Precise holes are pre-drilled to facilitate accurate and faster assembly.

3.1. Before You Begin

- Verify all parts and hardware are present against the packing list.
- Clear a spacious, clean area for assembly.
- Have necessary tools ready (e.g., screwdriver, hammer if required).

3.2. Assembly Tips

- Follow the step-by-step instructions provided in the separate assembly guide.
- Do not overtighten screws to avoid damaging the wood.
- For best results, assemble with two people.



Figure 3.1: Product dimensions (15.75"D x 30.94"W x 50.24"H) and weight capacities (top: 88 lbs, drawers: 30 lbs each).

4. Operating Instructions

The WLIVE Rattan 5-Drawer Dresser is designed for easy and functional use.

4.1. Drawer Usage

- Gently pull the gold metal handles to open drawers.
- The smooth metal slides ensure effortless opening and closing.
- Avoid forcing drawers open or closed.

4.2. Weight Capacity

To ensure longevity and safety, adhere to the following weight limits:

- **Wood Tabletop:** Maximum 88 lbs (40 kg).
- **Each Wood Drawer:** Maximum 30 lbs (13.6 kg).

Do not exceed these limits to prevent damage to the dresser or potential injury.

5. Maintenance

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Clean spills immediately to prevent staining or damage to the wood finish.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or warping.
- **Humidity:** Maintain a stable room temperature and humidity level to prevent wood expansion or contraction.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure stability.

6. Safety Information

Your safety is paramount. This dresser is equipped with an anti-tipping device to prevent accidents.

6.1. Anti-Tipping Device Installation

It is crucial to install the included anti-tipping device. Follow the specific instructions in your assembly manual to securely attach the dresser to a wall. This prevents the dresser from tipping over, especially in households with children or pets.

ANTI-TIP LOCK DETAILS






Figure 6.1: Always secure the dresser to the wall using the anti-tipping device to prevent hazards.

6.2. General Safety Precautions

- Do not allow children to climb on or play with the dresser.
- Do not place heavy items on top of the dresser that exceed the specified weight limit.
- Ensure drawers are closed when not in use to maintain stability.

7. Troubleshooting

If you encounter any issues with your dresser, please refer to the following common solutions:

Problem	Possible Cause	Solution
Dresser feels wobbly or unstable.	Loose fasteners; uneven floor; anti-tipping device not installed.	Tighten all screws. Ensure the dresser is on a level surface. Install the anti-tipping device as per instructions.
Drawers do not slide smoothly.	Misaligned slides; debris in tracks; overloaded drawer.	Check that drawer slides are correctly aligned and free of obstructions. Reduce drawer load if it exceeds capacity.
Missing parts during assembly.	Packaging error.	Contact WLIVE customer support with your product model and a list of missing parts.

If problems persist, please contact customer support for further assistance.

8. Specifications

Attribute	Detail
Brand	WLIVE
Model Name	ASNG119/QX (ASNG119)
Product Dimensions	15.75"D x 30.94"W x 50.24"H
Color	Light Oak
Mounting Type	Floor Mount
Room Type	Bedroom, Living Room, Closet, Hallway
Special Feature	Safety Stop (Anti-tipping device)
Assembly Required	Yes
Item Weight	79.4 Pounds
Number of Drawers	5
Country of Origin	China

9. Warranty and Support

9.1. Return Policy

This product is eligible for 30-day easy returns. Please refer to the retailer's return policy for detailed terms and conditions.

9.2. Customer Support

If you encounter any problems, have questions, or require assistance with your WLIVE Rattan 5-Drawer Dresser, please contact WLIVE customer support. Contact information can typically be found on the retailer's website or within your purchase documentation.

© 2025 WLIVE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question