

manuals.plus /

› [vidaXL](#) /

› [vidaXL Kitchen Cabinet Sonoma Grey 57x41.5x131.5 cm Engineered Wood Instruction Manual](#)

vidaXL 860126

vidaXL Kitchen Cabinet Instruction Manual

Model: 860126 | Brand: vidaXL | Color: Sonoma Grey

1. INTRODUCTION

Thank you for choosing the vidaXL Kitchen Cabinet. This cabinet is designed to provide practical storage for your kitchen essentials, featuring a durable engineered wood construction and a modern Sonoma Grey finish. Please read this manual carefully before assembly and use to ensure safe and correct operation.



Image 1.1: The vidaXL Kitchen Cabinet in a kitchen environment.

2. SAFETY INFORMATION

WARNING: To prevent tipping, this product **must** be used with the provided wall attachment device. Failure to do so can result in serious injury.

- Always ensure all parts are securely fastened before use.
- Do not overload shelves. Refer to the 'Specifications' section for maximum weight capacity.
- Keep small parts and packaging materials away from children during assembly.
- Screws and wall plugs for the interior of your specific wall are not included. It is crucial to select and use appropriate screws and wall plugs for your wall type. If you are uncertain, consult a qualified professional.
- Read and follow each step of the assembly instructions carefully.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Engineered wood panels (various sizes)
- Assembly hardware (screws, dowels, hinges, handles)
- Wall attachment device
- Assembly instructions manual (this document)

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly typically requires two adults. Ensure you have adequate space and the necessary tools (e.g., screwdriver, hammer) before starting.

1. **Unpack and Identify Parts:** Carefully unpack all components. Lay them out on a clean, soft surface to prevent scratches. Refer to the parts list in the separate assembly diagram (usually included in the packaging) to identify each panel and piece of hardware. Pay close attention to the size and type of wooden dowels, as incorrect placement can damage the panels.
2. **Assemble the Base:** Follow the step-by-step diagrams to construct the base frame of the cabinet. Ensure all connections are tight.
3. **Attach Side Panels and Shelves:** Secure the side panels to the base. Insert fixed shelves as indicated in the diagrams.
4. **Install Back Panel:** Attach the back panel using the provided small nails or screws. Ensure it is aligned correctly to square the unit.
5. **Assemble Doors:** Attach hinges to the cabinet doors. Then, mount the doors to the main cabinet structure. Adjust hinges as needed for proper door alignment.
6. **Install Handles:** Attach the handles to the doors.
7. **Wall Attachment:** This is a critical safety step. Position the cabinet in its desired location. Using the provided wall attachment device, mark the drilling points on the wall. Drill appropriate holes and secure the cabinet to the wall using suitable screws and wall plugs (not included). Ensure the cabinet is stable and cannot tip over.




Image 4.1: Dimensional diagram of the cabinet.



Image 4.2: Detail of a cabinet hinge.

5. OPERATING INSTRUCTIONS

This kitchen cabinet is designed for storing various kitchen items such as bowls, plates, pots, pans, and small appliances. The lower cabinet with doors provides enclosed storage, while the open shelves offer easy access and display space.

- Distribute weight evenly across shelves to maintain stability.
- Do not exceed the maximum weight capacity of 60 kg for the entire unit.
- Ensure doors close properly to keep contents clean and organized.

6. MAINTENANCE

The engineered wood surface of this cabinet is designed for easy care.

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or moisture damage.
- **Inspection:** Periodically check all screws and fittings to ensure they remain tight. Retighten if necessary.

7. TROUBLESHOOTING

If you encounter any issues with your cabinet, refer to the following common solutions:

- **Wobbly Cabinet:** Ensure all screws are tightened. Verify that the back panel is correctly installed and that the cabinet is securely attached to the wall using the anti-tipping device. Uneven floors can also cause wobbling; consider using furniture pads or shims.
- **Doors Not Aligning:** Adjust the hinges. Most hinges allow for minor adjustments in height, depth, and side-to-side movement. Refer to the hinge manufacturer's instructions or a general guide for hinge adjustment.
- **Difficulty During Assembly:** Double-check the assembly diagrams. Ensure you are using the correct hardware for each step. If a part seems difficult to fit, do not force it, as this may cause damage. Re-examine the instructions.

8. SPECIFICATIONS

Feature	Detail
Brand	vidaXL
Model Number	860126
Color	Sonoma Grey
Material	Engineered Wood
Overall Dimensions (W x D x H)	57 x 41.5 x 131.5 cm (22.4 x 16.3 x 51.8 inches)
Lower Cabinet Dimensions (W x D x H)	54 x 38 x 60 cm (21.3 x 15 x 23.6 inches)
Shelf Dimensions (W x D x H)	54 x 38 x 22/36.5 cm (21.3 x 15 x 8.7/14.4 inches)
Maximum Weight Capacity	60 kg (132 lbs)
Item Weight	27.65 kg (60.96 lbs)
Assembly Required	Yes

9. WARRANTY AND SUPPORT

vidaXL products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official vidaXL website.

If you require assistance with assembly, have questions about product functionality, or need to report missing/damaged parts, please contact vidaXL customer support. Contact details can typically be found on the vidaXL website or on your purchase documentation.

When contacting support, please have your model number (860126) and purchase details readily available.