

## Donner DDP-95

# Donner DDP-95 Digital Piano User Manual

Model: DDP-95

## 1. Introduction

Thank you for choosing the Donner DDP-95 Digital Piano. This instrument is designed to provide an authentic piano playing experience with modern digital features, suitable for beginners and experienced players alike. This manual provides essential information for the safe and effective use of your digital piano.

### 1.1 SAFETY INFORMATION

- **Power Supply:** Use only the specified power adapter. Ensure the voltage matches your local power supply.
- **Placement:** Place the piano on a stable, level surface. Avoid direct sunlight, heat sources, and excessive humidity.
- **Cleaning:** Use a soft, dry cloth for cleaning. Do not use liquid cleaners or solvents.
- **Water and Moisture:** Keep the instrument away from water or any liquids. Do not operate with wet hands.
- **Ventilation:** Ensure proper ventilation around the instrument to prevent overheating.
- **Servicing:** Do not attempt to repair the instrument yourself. Refer all servicing to qualified personnel.

## 2. Product Overview

The Donner DDP-95 features an 88-key weighted keyboard, a 4.3-inch LCD display, and a wide array of tones, rhythms, and teaching modes to enhance your musical journey.

### 2.1 MAIN COMPONENTS

- Digital Piano Unit (Keyboard and Stand)
- 3-Pedal System (Soft, Sostenuto, Sustain)
- Music Rest
- Power Adapter
- User Manual



Figure 2.1: The Donner DDP-95 Digital Piano, showcasing its full size, integrated stand, and three-pedal unit.

# Enrich Playing Performance

**610**

Tones

**600**

Rhythms

**110**

Demo Songs

**128**

Polyphony



Figure 2.2: Top-down view of the DDP-95 control panel, highlighting the LCD display and various function buttons for wireless connection, split, dual tones, MP3, transpose, chord, drum kit, and metronome.

## 3. Setup

### 3.1 ASSEMBLY

The DDP-95 typically comes with the keyboard and stand as separate components. Follow the included assembly guide for detailed instructions on attaching the keyboard to the stand and securing the pedal unit. Ensure all screws

are tightened securely before use.

## **3.2 CONNECTING POWER**

1. Connect the DC power adapter to the DC 15V input jack on the rear of the piano.
2. Plug the adapter into a standard electrical outlet.

## **3.3 CONNECTING PEDALS**

Connect the pedal unit cable to the 'PEDAL' jack on the rear of the piano. The DDP-95 features a 3-pedal system for Soft, Sostenuto, and Sustain functions.



# Connection Guide

① DC power jack

③ Headphone jack

⑤ Connects to computers, smartphones, tablets

② Sustain Pedal Jack

④ Audio input output jack



Figure 3.1: The three-pedal system, including Soft, Sostenuto, and Sustain pedals, designed for an authentic playing experience.

## 3.4 AUDIO CONNECTIONS



# Ultra-large Blue Light LCD Display

Multiple functions are displayed in real time



Figure 3.2: Rear panel connections, including (1) DC power jack, (2) Sustain Pedal Jack, (3) Headphone jack, (4) Audio input/output jacks, and (5) USB-MIDI port for connecting to computers, smartphones, and tablets.

- **Headphones:** Connect standard 6.35mm stereo headphones to the 'HEADPHONE' jack for private practice.
- **Audio In/Out:** Use the 'AUDIO IN' and 'AUDIO OUT' 6.35mm jacks to connect to external audio devices like amplifiers, mixers, or other instruments.

## 3.5 USB-MIDI AND BLUETOOTH CONNECTIVITY

- **USB-MIDI:** Connect the piano to a computer, smartphone, or tablet using a USB-MIDI cable for MIDI data

transfer with compatible software.

- **Bluetooth:** The DDP-95 supports wireless Bluetooth connection for MIDI-compatible applications. Refer to your device's Bluetooth settings and the application's instructions for pairing.

## 4. Operating Instructions

---

### 4.1 BASIC OPERATION

- **Power On/Off:** Press the 'POWER' button to turn the piano on or off.
- **Volume Control:** Use the 'VOLUME' knob or buttons to adjust the overall sound level.
- **Tone Selection:** The DDP-95 offers 610 tones. Use the 'TONE' buttons and the LCD display to browse and select different instrument sounds.
- **Rhythm Selection:** Choose from 600 rhythms (including 128 accompaniment styles) using the 'RHYTHM' buttons.
- **Demo Songs:** Play through 100 built-in demo songs for inspiration or practice.
- **Metronome:** Activate the metronome function to assist with timing and rhythm practice.



# 88 Key Fully Weighted Keyboard

88 key fully weighted keyboard with 16 level touch sensitivity, help beginner develop better touch feel.



Figure 4.1: Overview of the DDP-95's extensive sound library, including 610 tones, 600 rhythms, 110 demo songs, and 128-note polyphony.

## 4.2 LCD DISPLAY

The 4.3-inch blue light LCD display provides visual feedback on various settings and functions. It can show notes in staff notation, indicate key positions, and offer intuitive prompts.



# Designed for Beginner

A variety of  
beginner-friendly  
features to help beginners  
learn piano faster.



Up to 5000  
Notes



3 teaching  
modes



Headphone  
jack

Figure 4.2: The 4.3-inch blue light LCD display, showing real-time information and musical notation.



Figure 4.3: Detailed breakdown of the LCD display elements: (1) Tone/Demo/Rhythm Name, (2) Number of Bars, (3) Tempo, (4) Rhythmic Volume, (5) Indication of Active Keys, (6) Currently Used Function Icon, (7) Piano Score.

## 4.3 KEYBOARD FEATURES

- **88-Key Fully Weighted Keyboard:** Provides an authentic piano feel with hammer action.
- **16-Level Touch Sensitivity:** Adjusts the volume and timbre based on how hard or soft you play the keys, allowing for expressive dynamics.



## Compact and Elegant



Figure 4.4: Visual representation of the 16-level touch sensitivity, demonstrating how key weight influences sound effects from light to heavy.

### 4.4 TEACHING MODES

The DDP-95 includes three teaching modes to assist learners:

- **Single Key:** Practice individual notes.
- **Follow Along:** The piano waits for you to play the correct note before proceeding.
- **Ensemble:** Practice with an accompaniment, playing your part along with the built-in music.





Figure 4.5: Illustration of the three teaching modes: Single Key, Follow Along, and Ensemble, designed to guide learners progressively.

## 4.5 RECORDING AND PLAYBACK

The piano allows you to record your performances, with a capacity of up to 5000 bytes. This feature is useful for reviewing your playing, identifying areas for improvement, and capturing musical ideas.

- Press the 'RECORD' button to start recording.
- Press 'PLAY' to listen to your recorded performance.

## 4.6 ADDITIONAL FUNCTIONS

- **Split Keyboard:** Divides the keyboard into two sections, allowing two different tones to be played simultaneously or for two people to play together.
- **Dual Tones:** Layers two different tones to create a richer, more complex sound.
- **Transpose:** Shifts the pitch of the entire keyboard up or down in semitone steps.
- **Chord Function:** Provides automatic chord accompaniment based on the keys played.
- **Drum Kit:** Access various drum sounds for rhythm creation.

# 5. Maintenance

## 5.1 CLEANING

To maintain the appearance and functionality of your DDP-95 Digital Piano:

- Wipe the surface with a soft, dry, lint-free cloth.
- For stubborn dirt, slightly dampen the cloth with water, then wipe dry immediately.
- Avoid abrasive cleaners, waxes, or solvents as they can damage the finish.

## 5.2 STORAGE

When not in use for extended periods, store the piano in a cool, dry place, away from extreme temperatures and humidity. Cover the keyboard with a dust cover to protect the keys and internal components.

## 6. Troubleshooting

If you encounter issues with your Donner DDP-95, refer to the following common problems and solutions:

| Problem                    | Possible Cause  | Solution   |
|----------------------------|---|--|
| No sound                   | Volume too low; headphones connected; power issue.          | Increase volume; disconnect headphones; check power connection.              |
| Keys not responding        | Function mode active (e.g., teaching mode); internal error. | Exit special modes; power cycle the instrument.                              |
| Bluetooth connection fails | Device not in pairing mode; interference; distance.         | Ensure device is discoverable; reduce distance; restart both devices.        |
| Distorted sound            | Volume too high; faulty cable; external speaker issue.      | Lower volume; check/replace cables; test with different speakers/headphones. |

If the problem persists after trying these solutions, please contact Donner customer support.

## 7. Specifications

| Feature            | Detail  |
|--------------------|---|
| Model Name         | DDP-95  |
| Number of Keys     | 88  |
| Keyboard Type      | Fully Weighted, Hammer Action   |
| Touch Sensitivity  | 16 Levels   |
| Tones              | 610   |
| Rhythms            | 600 (128 Accompaniment Styles)  |
| Demo Songs         | 100   |
| Polyphony          | 128-note  |
| Display            | 4.3" Blue Light LCD   |
| Recording Capacity | Up to 5000 bytes  |
| Connectivity       | Bluetooth, USB-MIDI, 6.35mm Headphone Jack, 6.35mm Audio In/Out Jacks |
| Pedals             | Soft, Sostenuto, Sustain (3-Pedal System)                             |
| Power Source       | DC 15V Power Supply   |
| Item Weight        | 65.9 pounds (approx. 29.9 kg)   |

| Feature            | Detail  |
|--------------------|---|
| Package Dimensions | 53.94 x 16.14 x 11.81 inches (approx. 137 x 41 x 30 cm) |

## 8. Warranty and Support







### 8.1 WARRANTY INFORMATION

Donner products are manufactured to high-quality standards. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Donner website. Keep your proof of purchase for warranty claims.







### 8.2 CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to report an issue, please contact Donner customer support through their official website or the contact information provided in your product packaging. Provide your model number (DDP-95) and purchase details when seeking support.

#### Related Documents - DDP-95

|  |   |
|--|---|
| <br><br> | <a href="#">Donner DDP-100S Digital Piano User Manual</a><br>Comprehensive user manual for the Donner DDP-100S Digital Piano, detailing setup, product parameters, features, assembly, voice and rhythm lists, demo songs, and important safety information.  |
| <br><br> | <a href="#">Donner DDP-400 Digital Piano User Manual</a><br>This user manual provides comprehensive instructions for the Donner DDP-400 Digital Piano. It covers setup, assembly, features, operation, troubleshooting, and technical specifications for this 88-key weighted keyboard instrument.  |
| <br><br> | <a href="#">Donner OURA Piano S300 User Manual: Setup, Operation, and Maintenance</a><br>Explore the Donner OURA Piano S300 digital piano with this comprehensive user manual. Learn about its 88-key graded hammer keyboard, Bluetooth/MIDI features, setup, safe operation, and maintenance. Ideal for musicians seeking detailed guidance on their Donner digital piano. |



|  |  |
|--|--|
| <br><br> | <a href="#">Donner DDP-200 88 Keys Digital Piano User Manual</a><br>Comprehensive user manual for the Donner DDP-200 88 Keys Digital Piano, covering assembly, panel instructions, connections, functions, maintenance, security, and troubleshooting. |
| <br><br> | <a href="#">Donner DDP-80 Plus Digital Piano User Manual</a><br>Comprehensive user manual for the Donner DDP-80 Plus digital piano, providing essential information on setup, features, and connectivity.  |
| <br><br> | <a href="#">Donner DDP-400 Digital Piano User Manual</a><br>Comprehensive user manual for the Donner DDP-400 Digital Piano, covering assembly, operation, features, and troubleshooting.   |

Documents - Donner – DDP-95



[\[pdf\]](#) User Manual  
DDP 95 Manual Download Donner Music US manual Update v 1726197001 cdn shopify s files 1 0518  
1898 7676 |||  
...  
lang: score:26 filesize: 7.29 M page\_count: 52 document date: 2024-09-13



# USER MANUAL

DDP-95

DIGITAL PIANO

Thank You for Choosing DONNER!  
Please Read This Manual Carefully Before Use.

[\[pdf\]](#) User Manual

DDP 95 20240923 sic MANUAL Donner Press the Metronome button to activate metronome function The LCD Appuyez sur le bouton « Métronome » pour activer métronome l'écran LCD manual storage donnermusic official user 202409 |||

...

lang: **score:20** filesize: 51 M page\_count: 52 document date: 2024-09-23