

MeowWhimsy Neo-B

MeowWhimsy XXL Self-Cleaning Cat Litter Box Tray

Instruction Manual - Model: Neo-B

[Introduction](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty &](#)

[Support](#)

1. INTRODUCTION

Thank you for choosing the MeowWhimsy XXL Self-Cleaning Cat Litter Box Tray. This product is designed to revolutionize your cat care routine by providing a spacious and hygienic environment for your feline companion. This tray is an essential component of a larger electric self-cleaning litter box system, designed for seamless integration and effortless maintenance.

Key features of this product include:

- **Convenient Control:** Designed to integrate with electric litter box systems featuring app control for easy management and monitoring.
- **Self-Cleaning Compatibility:** Works with automated XXL self-cleaning systems for effortless maintenance.
- **Spacious Design:** Generously sized litter tray provides ample space for your feline companion.
- **Hassle-Free:** Eliminates the need for manual scooping and cleaning when used with a compatible system.
- **Durable Construction:** Sturdy build ensures long-lasting performance.

2. SETUP

This MeowWhimsy litter box tray is designed as a replacement or supplementary component for a compatible MeowWhimsy electric self-cleaning litter box system. Please refer to the main system's instruction manual for complete assembly and initial setup procedures.

2.1 Tray Installation

1. Ensure your main self-cleaning litter box unit is unplugged and turned off.
2. Carefully remove the existing litter tray from the main unit, if applicable.
3. Align the MeowWhimsy XXL Self-Cleaning Cat Litter Box Tray with the designated slot in your main unit.
4. Gently slide the tray into place until it is securely seated. Ensure there are no gaps and the tray is level.
5. Add your preferred clumping cat litter to the tray, ensuring it does not exceed the 'MAX' fill line indicated on

the tray.



Figure 2.1: MeowWhimsy XXL Self-Cleaning Cat Litter Box Replacement Tray. This image displays the MeowWhimsy XXL Self-Cleaning Cat Litter Box Replacement Tray, designed for use with compatible self-cleaning litter box systems. It features a spacious interior and a durable, washable liner.

2.2 App Control Integration (If applicable to your main unit)

If your main self-cleaning litter box unit features app control, ensure the tray is correctly installed before powering on the unit and connecting it to the mobile application. The app will allow you to monitor the system's status and control cleaning cycles.

3. OPERATION

The MeowWhimsy XXL Self-Cleaning Cat Litter Box Tray functions as the waste collection and sifting component

of your automated litter box system. Once installed and the main unit is powered on, the system will automatically detect waste and initiate cleaning cycles.

3.1 Automatic Cleaning Cycles

The main unit's mechanism will periodically sift the litter within the tray, separating clumps and solid waste from clean litter. The waste is then deposited into a sealed waste compartment (part of the main unit, not this tray). This process ensures a fresh and odor-free environment for your cat.

3.2 App Monitoring and Control

Through the dedicated mobile application (for compatible main units), you can:

- Monitor the litter level and waste compartment status.
- Initiate manual cleaning cycles.
- Receive notifications regarding system status or maintenance alerts.

For detailed instructions on using the app, please refer to the main self-cleaning litter box system's user manual.

4. MAINTENANCE

Regular cleaning of the MeowWhimsy XXL Self-Cleaning Cat Litter Box Tray is crucial for hygiene and optimal performance. The tray features a removable and washable design for easy maintenance.

4.1 Tray Cleaning

1. Unplug the main self-cleaning litter box unit from the power outlet.
2. Carefully remove the litter tray from the main unit.
3. Dispose of any remaining litter and waste in an appropriate manner.
4. The tray's inner lining is designed with 5 layers for durability and easy cleaning. You can rinse the tray with water and a mild, pet-safe detergent.
5. Ensure the tray is thoroughly dried before re-installing it into the main unit and adding fresh litter. Do not use abrasive cleaners or harsh chemicals.

Removable and Washable

5 layers

Performance test

More than 100 models

Carefully selected fabrics


Tested Over 10,000 Times

Friction and anti adhesion test of cat litter roller

Prevent scratching and biting



Anti infiltration



Micro antibacterial




Figure 4.1: Removable and Washable Tray Layers. This diagram highlights the advanced features of the MeowWhimsy litter box tray, including its removable and washable 5-layer design. It emphasizes durability, anti-infiltration properties, and micro-antibacterial qualities, ensuring a hygienic environment for your pet.

4.2 Litter Replacement

Regularly check the litter level and replenish as needed. Always use high-quality clumping cat litter for optimal performance of the self-cleaning mechanism. Replace all litter periodically as recommended by your veterinarian or based on your cat's usage.

5. TROUBLESHOOTING

This section addresses common issues related to the MeowWhimsy XXL Self-Cleaning Cat Litter Box Tray. For issues related to the main self-cleaning unit's motor, sensors, or app connectivity, please refer to the main unit's instruction manual.

5.1 Litter Not Sifting Properly

- **Check Litter Type:** Ensure you are using clumping cat litter. Non-clumping litter will not be effectively sifted.
- **Litter Level:** Verify that the litter level is between the 'MIN' and 'MAX' lines on the tray. Too much or too little litter can impede sifting.
- **Tray Obstruction:** Remove the tray and inspect for any large debris or foreign objects that might be blocking the sifting mechanism.
- **Tray Seating:** Ensure the tray is correctly and securely seated within the main unit. A misaligned tray can prevent proper operation.

5.2 Odor Persistence

- **Regular Cleaning:** Even with self-cleaning, periodic manual cleaning of the tray and main unit is necessary. Refer to Section 4.1.
- **Litter Quality/Freshness:** Ensure you are using fresh, high-quality litter. Replace all litter regularly.
- **Waste Compartment:** Check the waste compartment of the main unit. If it's full or not sealed properly, odors can escape.

6. SPECIFICATIONS

Model Name	Litter tray
Item Model Number	Neo-B
Brand	MeowWhimsy
ASIN	B0DKFFT11K
Color	Gray
Size	XXL
Material	Polyester
Style	Tray
Included Components	Litter tray pan
Item Dimensions (LxWxH)	19.69 x 15.75 x 17.72 inches
Product Dimensions (L x W x H)	15.5"L x 13.5"W x 2.36"H
Item Weight	9.9 pounds (4.5 Kilograms)
With Lid	Yes
Specific Uses for Product	Litter tray
Manufacturer	MeowWhimsy

7. WARRANTY & SUPPORT

7.1 Product Warranty

The MeowWhimsy XXL Self-Cleaning Cat Litter Box Tray comes with a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by

misuse, accident, unauthorized modification, or improper maintenance.
Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your MeowWhimsy product, please contact MeowWhimsy customer support. You can typically find contact information on the MeowWhimsy official website or through the retailer where you purchased the product.

When contacting support, please have your product model number (Neo-B) and purchase details ready.