

LOFREE Zero ARTZ

LOFREE Zero ARTZ 75% Mechanical Keyboard User Manual

Model: Zero ARTZ

[Introduction](#) [Package Contents](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

The LOFREE Zero ARTZ is a 75% mechanical keyboard designed for versatile use across multiple operating systems. It features a unique terrazzo-inspired design, hot-swappable linear switches, and multiple connection options for enhanced productivity and user experience.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- LOFREE Zero ARTZ Mechanical Keyboard
- Marble Palm Rest
- USB-C to USB-A Cable
- Cleaning Brush
- User Manual (this document)
- Warranty Card



Image: Included accessories with the keyboard.

3. SETUP

3.1. Power On/Off & Connection Mode Selection

Locate the switches on the back edge of the keyboard:

1. **Power Switch:** Slide the switch to turn the keyboard ON or OFF.
2. **OS Switch:** Select between "Win/And" (Windows/Android) or "Mac/iOS" (Mac/iOS) to optimize key

functions for your operating system.

3. **Connection Mode Switch:** Choose your preferred connection method:

- **WLS (Wireless/Bluetooth):** For Bluetooth connection.
- **CAB (Cable):** For wired USB-C connection.
- **OFF:** Turns off the keyboard.



Image: Close-up of the USB-C port, OS switch, and connection mode switch.

3.2. Connecting via Bluetooth (WLS Mode)

1. Ensure the keyboard is ON and the Connection Mode Switch is set to "WLS".
2. On your device (computer, tablet, smartphone), enable Bluetooth.
3. Search for available Bluetooth devices and select "LOFREE Zero ARTZ" (or similar name).
4. Follow any on-screen prompts to complete the pairing process.

3.3. Connecting via USB-C Cable (CAB Mode)


1. Connect one end of the provided USB-C cable to the keyboard's USB-C port.
2. Connect the other end (USB-A) to an available USB port on your computer.
3. Ensure the Connection Mode Switch is set to "CAB". The keyboard will automatically connect.

4. OPERATING INSTRUCTIONS

4.1. Backlighting Effects

The keyboard features customizable backlighting:

- **Change Light Effect:** Press **Fn + Up Arrow** to cycle through 7 distinct lighting effects.
- **Adjust Brightness:** Press **Fn + Left Arrow** or **Fn + Right Arrow** to adjust between 4 brightness levels.
- **Adjust Blink Frequency:** Press **Fn + Down Arrow** to change between 4 blink frequencies for dynamic effects.



7 Distinct
lighting effects



4 Brightness
levels



4 Blink
frequencies

Image: The keyboard displaying its various backlighting options.

4.2. Marble Palm Rest

The included Marble Palm Rest provides ergonomic support and features a natural marble texture. It is equipped with non-slip mats for stability during use.

Equipped with
Non-slip mats




Image: The marble palm rest showing its non-slip mats.



Image: Close-up of the marble palm rest highlighting its natural texture.

4.3. Hot-swappable Switches

The LOFREE Zero ARTZ keyboard features hot-swappable switches, allowing users to easily change switches without soldering. This enables customization of typing feel and sound.

Your browser does not support the video tag.

Video: Demonstrates the hot-swappable feature of the keyboard, showing how switches can be easily removed and replaced.

Your browser does not support the video tag.

Video: A short preview showcasing the hot-swappable switches and customizable keycaps.

5. MAINTENANCE

To keep your keyboard in optimal condition:

- Use the provided cleaning brush to remove dust and debris from between the keycaps regularly.
- For deeper cleaning, carefully remove keycaps using a keycap puller (not included) and clean the switches and plate.
- Avoid exposing the keyboard to liquids or extreme temperatures.

6. TROUBLESHOOTING

- **Keyboard not responding:**
 - Ensure the keyboard is powered ON.
 - Check the connection mode (WLS/CAB) and ensure it matches your connection type.
 - For Bluetooth, try re-pairing the device.
 - For wired, try a different USB port or cable.
- **Backlight not working:**
 - Ensure the keyboard is charged.
 - Try adjusting brightness levels using **Fn + Left/Right Arrow**.
- **Keys not registering:**
 - Ensure the OS switch is set correctly for your operating system.
 - If a specific key is not working, it might be a faulty switch. Utilize the hot-swappable feature to replace it.

7. SPECIFICATIONS

Feature	Detail
Brand	LOFREE
Model	Zero ARTZ
Keyboard Type	75% Mechanical
Switch Type	Linear (Hot-swappable)
Connectivity	Bluetooth, Wired (USB-C)
Compatible Devices	Android, Laptop, Mac, PC, Smartphone, Tablet
Operating Systems	MacOS, iOS, Windows, Android
Power Source	Battery Powered
Special Feature	Ergonomic Marble Palm Rest

8. WARRANTY & SUPPORT

Your LOFREE Zero ARTZ Mechanical Keyboard comes with a manufacturer's warranty. Please refer to the included Warranty Card for details regarding coverage, terms, and conditions.

For technical support or customer service, please visit the official LOFREE website or contact their customer support channels as listed on the product packaging or warranty card.

