

[Manuals.plus](#) /

› [LUXOAK](#) /

› LUXOAK 7-Piece Farmhouse Solid Wood Dining Table Set (Model ZYD001) Instruction Manual

## LUXOAK ZYD001

# LUXOAK 7-Piece Farmhouse Solid Wood Dining Table Set (Model ZYD001) Instruction Manual

## 1. SAFETY INFORMATION

**WARNING:** To prevent tip-over, always assemble and use the table as instructed. Do not use liquids or wet cloths to clean the table. Be cautious when moving the table due to its weight of 143 pounds. Keep the table away from children's reach to prevent injury from small parts or sharp edges.

## 2. PRODUCT OVERVIEW

The LUXOAK 7-Piece Farmhouse Solid Wood Dining Table Set, Model ZYD001, is designed to provide a functional and aesthetically pleasing dining solution for your home. This set includes one rectangular dining table and six matching chairs, suitable for seating 4 to 6 individuals comfortably. The design features a farmhouse-inspired aesthetic with a natural wood grain finish on the tabletop and sturdy solid wood construction for durability.

- **Table Dimensions:** 60"L x 36"W x 30"H
- **Chair Dimensions:** 18.3"L x 21.6"W x 36.6"H
- **Materials:** Solid wood legs and MDF tabletop. Chairs feature high-elastic, breathable linen fabric seat cushions.
- **Features:** 3-section splicing desktop, anti-slip foot pads, water-resistant and scratch-proof surface.

# Shipped by 2 Boxes

●●● Package Quantity: 2 ●●●




Image: The complete LUXOAK 7-Piece Farmhouse Solid Wood Dining Table Set, showcasing the rectangular table and six chairs in a dining room setting.

## 3. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the LUXOAK dining table set is estimated to take 30-40 minutes with two people. Please follow these detailed steps carefully. Ensure all parts are present before beginning assembly.

### Table Assembly

#### 1. Step 1: Prepare Table Top Section 1

Insert cam-locks (E) and dowels (K) into the designated holes of table top section 1. Tighten cam-locks until flush with the panel. Do not overtighten.



Image: Diagram showing insertion of cam-locks and dowels into the first table top section.

#### 2. Step 2: Prepare Table Top Sections 2 and 3

Repeat the process from Step 1 for table top sections 2 and 3, inserting dowels (K) and cam-locks (E) as indicated in the manual.



Image: Diagram illustrating the preparation of the remaining table top sections with hardware.

### 3. Step 3: Connect Table Top Sections

Align and connect the prepared table top sections. Secure them using the provided metal plates (J), bolts (A), and flat washers (D). Ensure the connections are tight and flush.



Image: Diagram showing how to join the table top sections using metal plates, bolts, and washers.

### 4. Step 4: Attach Side Rails to Table Legs

Attach the side rails (parts 4 and 5) to the table legs using bolts (B), cam-locks (C), and flat washers (D). Ensure all connections are secure.



Image: Diagram detailing the attachment of side rails to the table legs with bolts, cam-locks, and washers.

### 5. Step 5: Attach Middle Rails to Table Legs

Attach the middle rails (parts 6 and 7) to the table legs using bolts (B), cam-locks (C), and flat washers (D). Verify all connections are firm.



Image: Diagram showing the process of attaching middle rails to the table legs.

### 6. Step 6: Prepare Table Legs

Insert dowels (G) into the top ends of the table legs (part 8). These dowels will connect to the table frame.



Image: Diagram illustrating the insertion of dowels into the table legs.

### 7. Step 7: Connect Crossbars to Side Rails

Insert dowels (K) into the crossbars (part 3) and connect them to the side rails (parts 6 and 7) to form the table frame.



Image: Diagram showing how to connect the crossbars to the side rails using dowels.

### 8. Step 8: Attach Table Legs to Frame

Carefully attach the prepared table legs (part 8) to the assembled table frame. Ensure the dowels align with the corresponding holes.



Image: Diagram showing the attachment of the table legs to the main frame structure.

### 9. Step 9: Secure Table Legs to Frame

Secure the table legs to the frame using washers (H) and nuts (I). Tighten with the provided wrench (S) until firm.



Image: Diagram illustrating the use of washers, nuts, and a wrench to secure the table legs.

### 10. Step 10: Attach Table Frame to Table Top

Carefully place the assembled table frame onto the underside of the table top. Ensure all cam-locks (F) align with the entry holes. Insert and turn the female cam-locks clockwise with a screwdriver until you feel a click, indicating the joint is secure.

Video: Official assembly video demonstrating the attachment of the table frame to the table top. This video shows the process of securing the table frame to the tabletop using cam-locks, ensuring a stable connection.

## Chair Assembly (Repeat for all 6 chairs)

### 11. Step 11: Attach Seat to Backrest

Attach the chair seat (part 10) to the backrest (part 9) using bolts (O), washers (P), and nuts (Q). Tighten with the provided wrench (R).



Image: Diagram showing the initial assembly of the chair seat and backrest components.

12. **Step 12: Attach Front Legs**

Attach the front legs to the chair seat using bolts (M), washers (P), and nuts (Q). Ensure they are firmly attached.



Image: Diagram illustrating the attachment of the front legs to the chair seat.

13. **Step 13: Attach Back Legs**

Attach the back legs to the chair seat using bolts (N), washers (P), and nuts (Q). Verify all connections are secure and stable.



Image: Diagram showing the final step of attaching the back legs to the chair seat.

4. **OPERATING INSTRUCTIONS**

This dining set is designed for everyday use and can comfortably accommodate 4 to 6 people. The chairs feature an ergonomic design with curved backrests and high-elastic, linen fabric seat cushions for a comfortable seating experience. The table's spacious surface is ideal for family meals, gatherings, or other activities.



Image: The LUXOAK dining table set arranged with place settings, demonstrating its use for meals.

## Space Saving

When not in use, the dining chairs can be neatly stored under the dining table to save space, making it suitable for various room sizes.

# EASILY SAVE SPACE



Before Organize



After Organize



Image: Illustration showing how the dining chairs can be tucked under the table to optimize space.

## 5. MAINTENANCE

To ensure the longevity and appearance of your LUXOAK dining set, follow these maintenance guidelines:

- **Cleaning:** The table surface is water-resistant and scratch-proof. Wipe clean with a dry or slightly damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Promptly clean up any spills to prevent staining, especially on the chair cushions.
- **Protection:** Use placemats or coasters to protect the table surface from hot dishes, spills, and scratches.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood and fabric.
- **Humidity:** Maintain a consistent humidity level in your room to prevent wood from warping or cracking.

- **Tighten Fasteners:** Periodically check and tighten all bolts and screws to ensure the stability and safety of the table and chairs.



# The Spacious Dinner Table



- **3-section Splicing Desktop**



- **The Anti-slip Foot Pads**



- **Easy to Clean**

Image: Close-up view of the table surface demonstrating its water-resistant properties.

## 6. TROUBLESHOOTING

If you encounter any issues with your LUXOAK dining table set, please refer to the following common solutions:

- **Wobbly Table/Chairs:** Check all assembly bolts and screws. Tighten any loose fasteners using the appropriate tools. Ensure the table and chairs are on a level surface.
- **Surface Scratches/Damage:** For minor scratches, wood repair kits or markers can be used. For significant damage, contact customer support for advice.
- **Missing Parts:** If any parts were missing upon delivery, please contact LUXOAK customer support immediately with your purchase details.
- **Color Variation:** Note that product color might appear different under varying lighting conditions. This is a natural characteristic and not a defect.

## 7. SPECIFICATIONS

| Feature                      | Detail                                               |
|------------------------------|------------------------------------------------------|
| Brand                        | LUXOAK                                               |
| Model Number                 | ZYD001                                               |
| Set Name                     | LUXOAK 7-Piece Farmhouse Solid Wood Dining Table Set |
| Table Dimensions (L x W x H) | 60" x 36" x 30"                                      |
| Chair Dimensions (L x W x H) | 18.3" x 21.6" x 36.6"                                |
| Material                     | Wood (Solid wood legs, MDF tabletop)                 |
| Color                        | Rustic Cream                                         |
| Item Weight                  | 87 Pounds (Table)                                    |
| Assembly Required            | Yes (Estimated 30-40 minutes for two people)         |
| Seating Capacity             | 4-6 Persons                                          |

## 8. WARRANTY AND SUPPORT

For any questions, concerns, or assistance with your LUXOAK 7-Piece Farmhouse Solid Wood Dining Table Set, please contact LUXOAK customer support. Refer to your purchase documentation for specific warranty details and contact information.