

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [LLIVEKIT](#) /

› [LLIVEKIT Airfryer XXL Mini Oven 26L 1700W User Manual](#)

LLIVEKIT AO46

LLIVEKIT Airfryer XXL Mini Oven 26L 1700W User Manual

Model: AO46

1. INTRODUCTION

Thank you for purchasing the LLIVEKIT Airfryer XXL Mini Oven. This appliance is designed to provide a convenient and healthy cooking experience, allowing you to prepare a variety of meals with less oil. Please read this manual thoroughly before operation to ensure safe and efficient use.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury.

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.

- The appliance features an overheat protection system for safe cooking.

3. PRODUCT OVERVIEW

The LLIVEKIT Airfryer XXL Mini Oven (Model AO46) is a versatile 26-liter appliance with 1700W power, designed for various cooking methods including air frying, baking, grilling, roasting, and dehydrating. It features a digital LED touch screen for easy control and a double-walled glass door for safe viewing.



Figure 3.1: LLIVEKIT Airfryer XXL Mini Oven in operation, showing fries, steaks, and pizza.

3.1 Components and Accessories

Your LLIVEKIT Airfryer XXL Mini Oven comes with 7 professional and easy-to-clean accessories to enhance your cooking experience.

7

Accesorios Prácticos

Para Mayor Versatilidad



Figure 3.2: Included accessories for the LLIVEKIT Airfryer XXL Mini Oven.

- **Non-stick Baking Pan:** Made of cold-rolled steel, suitable for baking and collecting drips.
- **SUS430 Stainless Steel Frying Basket:** Ideal for air frying items like fries and vegetables.
- **Coated Cooking Rack:** For grilling steaks, chicken wings, and other items.
- **Rotisserie Spit Set:** For roasting whole chickens or other large cuts.
- **Crumb Tray:** Collects food residues for easy cleaning.
- **Tongs for Baking Pans:** For safely handling hot baking pans.
- **Food Tongs:** For safely handling hot food items.

All accessories are heat-resistant, durable, and designed for easy cleaning, with many being dishwasher-safe (avoid steel wool).

4. SETUP AND FIRST USE

4.1 Unpacking

1. Carefully remove the appliance and all accessories from the packaging.
2. Remove any protective films or stickers from the appliance.

3. Inspect the appliance for any damage. Do not use if damaged.

4.2 Cleaning Before First Use

1. Wipe the exterior of the oven with a damp cloth.
2. Wash all accessories (baking pan, frying basket, cooking rack, rotisserie spit, crumb tray, tongs) with warm soapy water. Rinse thoroughly and dry completely.
3. Ensure the interior of the oven is clean and dry before plugging it in.

4.3 Placement

- Place the oven on a stable, flat, and heat-resistant surface.
- Ensure there is adequate ventilation around the appliance (at least 10 cm clearance on all sides).
- Do not place the oven near flammable materials or heat sources.

4.4 Initial Burn-Off

It is recommended to run the oven empty for about 15 minutes before first use to burn off any manufacturing residues.

1. Plug the oven into a grounded 220V-240V AC outlet.
2. Set the temperature to 200°C and the timer to 15 minutes.
3. Operate the oven without any food inside. A slight odor or smoke may be present; this is normal.
4. After 15 minutes, turn off the oven and allow it to cool completely.
5. Wipe the interior with a damp cloth once cooled.

5. OPERATING INSTRUCTIONS

5.1 Control Panel

The LLIVEKIT Airfryer XXL Mini Oven features an intuitive digital LED touch screen for easy operation.

12 Funciones Preseleccionadas - Disfrute del placer de cocinar con una sola presión



Figure 5.1: Digital LED touch screen control panel with various preset functions.

- **Power Button:** Turns the oven on/off.
- **Temperature Control:** Adjusts temperature from 60°C to 230°C.
- **Time Control:** Adjusts cooking time up to 90 minutes.
- **Preset Functions:** Icons for 12 common dishes (e.g., fries, chicken wings, pizza, roasted chicken, dried fruit, pastries, bread, shrimp, fish, cookies, steak).
- **Light Button:** Turns the interior oven light on/off.
- **Fan/Convection Button:** Activates or deactivates the convection fan for even cooking.
- **Rotisserie Button:** Activates the rotisserie function (if using the rotisserie spit).

5.2 General Operation

1. **Prepare Food:** Place your food on the appropriate accessory (baking pan, frying basket, or cooking rack).
2. **Insert Accessory:** Slide the accessory into the desired rack position inside the oven. Ensure the crumb tray is at the bottom.
3. **Power On:** Plug in the oven and press the Power button.
4. **Select Function:**

- **Using Presets:** Select one of the 12 preset icons. The oven will automatically set the recommended time and temperature.
- **Manual Setting:** Use the Temperature and Time control buttons to set your desired cooking parameters.

5. **Start Cooking:** Press the Start/Pause button to begin cooking. The interior light can be turned on to monitor progress.
6. **Adjust During Cooking:** You can adjust the time and temperature during cooking if needed.
7. **Finish Cooking:** The oven will beep when the cooking cycle is complete. Carefully remove the food using oven mitts and the provided tongs.
8. **Power Off:** Press the Power button to turn off the oven and unplug it from the wall outlet.

5.3 Specific Functions

- **Air Frying:** Use the frying basket for items like fries, chicken wings, and vegetables. The 360° hot air circulation ensures crispy results.
- **Roasting (Rotisserie):** For whole chickens or larger cuts, use the rotisserie spit. Ensure the food is securely fastened and clears all heating elements. Activate the Rotisserie button on the control panel.
- **Dehydrating:** Use a low temperature (e.g., 60°C) and a longer time for drying fruits or making jerky.
- **Preheating:** The oven supports a preheating function. For optimal results, allow the oven to reach the set temperature before adding food.
- **Keep Warm:** After cooking, the oven can maintain a warm temperature to keep your food ready until serving.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your LLIVEKIT Airfryer XXL Mini Oven.

1. **Unplug and Cool:** Always unplug the oven from the power outlet and allow it to cool completely before cleaning.
2. **Crumb Tray:** Remove the crumb tray and empty any food residues. Wash it with warm soapy water or place it in the dishwasher.
3. **Accessories:** All removable accessories (baking pan, frying basket, cooking rack, rotisserie spit, tongs) are dishwasher-safe. For stubborn food, soak them in warm soapy water before cleaning. Avoid using abrasive cleaners or steel wool, as this can damage the non-stick coating and stainless steel.
4. **Interior:** Wipe the interior walls and heating elements with a damp cloth and mild detergent. For baked-on food, a non-abrasive sponge can be used. Ensure the interior is dry before next use.
5. **Exterior:** Wipe the exterior surface with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
6. **Door:** Clean the double-walled glass door with a glass cleaner or damp cloth.

Note: Never immerse the main unit of the oven in water or any other liquid.

7. TROUBLESHOOTING

If you encounter any issues with your LLIVEKIT Airfryer XXL Mini Oven, please refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Oven does not turn on.	Not plugged in; power outlet malfunction; power button not pressed.	Ensure the oven is securely plugged into a working outlet. Press the Power button. Check circuit breaker.
Food is not cooking evenly.	Overcrowding; incorrect temperature/time; fan not active.	Do not overcrowd the oven. Ensure food is in a single layer. Adjust temperature/time. Activate the convection fan. Flip or rotate food halfway through cooking.
White smoke coming from the oven.	Excess oil/grease on heating elements or crumb tray; initial burn-off.	This is normal during initial use. For subsequent uses, ensure accessories and interior are clean. Remove excess fat from food.
Oven is too noisy.	Fan operation; loose accessory.	The convection fan produces some noise (below 65 dB), which is normal. Ensure all accessories are properly seated.
Digital display not working.	Power issue; internal malfunction.	Unplug the oven for a few minutes, then plug it back in. If the issue persists, contact customer support.

If the problem persists after trying these solutions, please contact LLIVEKIT customer support.

8. SPECIFICATIONS

Brand	LLIVEKIT
Model Number	AO46
Color	Silver
Product Dimensions (L x W x H)	42 x 38.2 x 40 cm
Item Weight	9 Kilograms
Capacity	26 Liters
Power	1700 Watts
Voltage	220-240 Volts (AC)
Material	Stainless Steel
Special Features	Automatic shut-off, Temperature control, Programmable, Stain resistant
Recommended Uses	Bake, Stew, Dehydrate, Grill, Roast
Certifications	CE/GS/UKCA, VDE plug standard

9. WARRANTY AND SUPPORT

LLIVEKIT products are manufactured to high-quality standards. For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official LLIVEKIT website.

For technical assistance or inquiries, please contact LLIVEKIT customer service.

Related Documents - AO46

	<p>LLIVEKIT Air Fryer Oven User Manual</p> <p>Comprehensive user manual for the LLIVEKIT Air Fryer Oven (Model: AFS26E), detailing operation, features, safety precautions, and maintenance for optimal use.</p>
	<p>LLIVEKIT AFS26A User Manual</p> <p>Comprehensive user manual for the LLIVEKIT AFS26A Air Fryer Oven. Learn about safety precautions, appliance components, operation guides, cooking presets, troubleshooting, and maintenance.</p>
	<p>LLIVEKIT User Manual: Important Safeguards and Safety Instructions</p> <p>Comprehensive safety guidelines and important safeguards for LLIVEKIT kitchen appliances, including mini air fryers and electric ovens. Ensure safe operation and prevent hazards with this user manual.</p>
	<p>LLIVEKIT GLA-532 Air Fryer User Manual</p> <p>User manual for the LLIVEKIT GLA-532 7L air fryer. This guide provides comprehensive instructions for operating the 1800W hot air fryer, including setup, safety precautions, maintenance, troubleshooting, and proper disposal. Learn to use the digital touchscreen and various presets for healthy, oil-free, and low-fat cooking.</p>
	<p>LLIVEKIT 30 L Heißluftofen Bedienungsanleitung</p> <p>Entdecken Sie die Vielseitigkeit des LLIVEKIT 30 L Heißluftofens. Dieses Handbuch bietet detaillierte Anleitungen zur Bedienung, Wartung und Fehlerbehebung für Ihr Gerät. Erfahren Sie, wie Sie verschiedene Kochfunktionen wie Air Fry, Grillen, Backen und mehr nutzen können, um köstliche Mahlzeiten zuzubereiten.</p>
	<p>LLIVEKIT AF-D5508ATB Air Fryer User Manual</p> <p>Comprehensive user manual for the LLIVEKIT AF-D5508ATB Air Fryer, detailing operation, safety, specifications, troubleshooting, and maintenance for this 9L dual-zone hot air fryer.</p>