Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi F6CLF264E

De'Longhi F6CLF264E Built-in Combined Refrigerator User Manual

Model: F6CLF264E

1. Safety Information

Please read these instructions carefully before installing and using the appliance. Keep this manual for future reference.

- **Electrical Safety:** Ensure the appliance is connected to a properly grounded electrical outlet. Do not use extension cords or multiple adapters. Disconnect the appliance from the power supply before cleaning or maintenance.
- **Ventilation:** Ensure adequate ventilation around the appliance as specified in the installation section to prevent overheating.
- **Children:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- **Flammable Materials:** Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- **Maintenance:** Any repairs should only be carried out by qualified service personnel.

2. Product Overview

The De'Longhi F6CLF264E is a built-in combined refrigerator designed for seamless integration into your kitchen cabinetry. It features a total net capacity of 248 liters, with a ventilated refrigerator compartment and a static freezer compartment.



Image: De'Longhi F6CLF264E Built-in Combined Refrigerator. This image shows the exterior of the combined refrigerator, designed for built-in installation.

Key Features:

- **Type:** Combined Refrigerator
- **Installation:** Built-in
- **Total Net Capacity:** 248 Liters
- **Refrigerator Cooling:** Ventilated
- **Freezer Cooling:** Static
- **Energy Class:** E
- **Special Feature:** 0-degree zone
- **Door Reversibility:** Yes

3. Setup

3.1 Unpacking

1. Carefully remove all packaging materials, including protective films and tapes.
2. Check the appliance for any transport damage. Report any damage to your retailer immediately.
3. Keep packaging materials out of reach of children.

3.2 Placement and Ventilation

- Install the appliance in a dry, well-ventilated room, away from direct sunlight and heat sources (e.g., ovens, radiators).
- Ensure sufficient air circulation around the appliance. Refer to the installation diagram for specific clearance requirements within the cabinetry.
- Level the appliance using the adjustable feet to ensure stability and proper door closure.

3.3 Electrical Connection

- Before connecting, ensure the voltage and frequency indicated on the rating plate match your household power supply.
- The appliance must be properly grounded. The plug should be inserted into an outlet with an earth contact.
- Do not switch on the appliance immediately after installation. Allow it to stand for at least 2-4 hours before plugging it in to allow the refrigerant to settle.

3.4 Door Reversal

The doors of this appliance are reversible. If you need to change the hinge side, please refer to the detailed instructions provided in the separate installation guide or contact qualified service personnel.

4. Operating Instructions

4.1 Initial Start-up

After connecting the appliance to the power supply, the internal light will illuminate, and the cooling system will start. Allow the appliance to run for several hours before placing food inside to ensure it reaches the optimal temperature.

4.2 Temperature Control

The appliance features electronic temperature control with a display. Use the control panel to adjust the desired temperature for the refrigerator and freezer compartments. Refer to the specific control panel diagram in the full manual for detailed button functions.

- **Refrigerator Temperature:** Typically adjustable between 2°C and 8°C.
- **Freezer Temperature:** Typically adjustable between -16°C and -24°C.

4.3 Cooling Features

- **Ventilated Refrigerator:** Ensures even temperature distribution and faster cooling.
- **Static Freezer:** Provides consistent freezing conditions.
- **Fast Cooling/Freezing:** Use this function to rapidly cool or freeze newly added food items. Deactivate the function once the food has reached the desired temperature.

4.4 Storage Recommendations

- **0-Degree Zone:** Ideal for storing fresh meat, fish, and dairy products at a temperature close to 0°C to extend their freshness.
- **Refrigerator Shelves:** Adjustable glass shelves allow for flexible storage of various food items.
- **Drawers:** Use the dedicated drawer for fruits and vegetables to maintain optimal humidity.

5. Maintenance and Cleaning

Regular maintenance ensures optimal performance and extends the lifespan of your appliance.

5.1 Cleaning the Interior

1. Before cleaning, unplug the appliance from the power outlet.
2. Remove all food items and removable parts (shelves, drawers).

3. Clean the interior with a solution of lukewarm water and a mild, neutral detergent. Avoid abrasive cleaners or solvents.
4. Rinse thoroughly with clean water and dry with a soft cloth.
5. Clean the door seals regularly to ensure a tight seal.

5.2 Cleaning the Exterior

Wipe the exterior surfaces with a soft cloth dampened with water and a mild detergent. Dry thoroughly. Do not use abrasive cleaners or harsh chemicals.

5.3 Manual Defrosting

Both the refrigerator and freezer compartments require manual defrosting when a layer of ice approximately 3-5 mm thick has formed.

1. Unplug the appliance.
2. Remove all food items and store them in a cool place.
3. Leave the doors open to allow the ice to melt naturally. Place towels at the bottom to absorb water. Do not use sharp objects or heating devices to speed up defrosting.
4. Once defrosted, clean and dry the interior thoroughly before plugging the appliance back in and returning food.

5.4 Power Outage

In case of a power outage, the appliance has an autonomy of approximately 1 hour without power. Keep the doors closed to maintain the internal temperature for as long as possible.

6. Troubleshooting

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Appliance does not operate.	No power supply; plug not inserted correctly; fuse blown.	Check power connection; check household fuse.
Temperature is not cold enough.	Door not closed properly; door opened too frequently; large amount of warm food added; temperature setting too high; poor ventilation.	Ensure door is closed; avoid frequent opening; allow food to cool before placing in fridge; adjust temperature setting; ensure proper ventilation.
Excessive ice build-up in freezer.	Door not closed properly; door opened too frequently; high humidity.	Ensure door is closed; avoid frequent opening; perform manual defrost.
Unusual noises.	Appliance not level; contact with wall or other objects; normal operating sounds (refrigerant flow, compressor).	Level the appliance; ensure clearance; these sounds are normal.
Door alarm sounds.	Door left open for too long.	Close the door.

7. Specifications

Technical specifications for the De'Longhi F6CLF264E refrigerator:

Feature	Specification
Model Number	F6CLF264E
Type	Combined Refrigerator
Installation Type	Built-in (Integrated)
Total Net Capacity	248 Liters
Refrigerator Net Capacity	186 Liters
Freezer Net Capacity	62 Liters
Energy Efficiency Class	E
Annual Energy Consumption	216 kWh
Noise Level	38 dBA (Class C)
Refrigerator Defrost System	Manual
Freezer Defrost System	Manual
Autonomy (without power)	1 hour
Number of Doors	2
Dimensions (H x W x D)	1770 mm x 560 mm x 550 mm
Weight	55 Kg
Climate Class	ST
Special Feature	0-degree zone

8. Warranty and Support

This De'Longhi appliance comes with a manufacturer's warranty. For detailed information regarding warranty terms and conditions, please refer to the warranty card included with your product or visit the official De'Longhi website.

For technical assistance, spare parts, or to schedule a service appointment, please contact De'Longhi customer support. Contact details can typically be found on the official brand website or in the documentation provided with your appliance.

When contacting support, please have your appliance model number (F6CLF264E) and serial number ready.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DKJN3ZD3

More documents and user manuals: **https://manuals.plus/**