

[Manuals.plus](#) /

› [Best Choice Products](#) /

› Best Choice Products 6ft Lighted 2D Christmas Tree Outdoor Decoration Manual

Best Choice Products SKY8076

Best Choice Products 6ft Lighted 2D Christmas Tree Outdoor Decoration

Model: SKY8076

INTRODUCTION

Thank you for choosing the Best Choice Products 6ft Lighted 2D Christmas Tree Outdoor Decoration. This manual provides essential information for the safe assembly, operation, and maintenance of your product. Please read all instructions carefully before use and retain this manual for future reference.

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, visit www.P65Warnings.ca.gov.



Image: The 6ft Lighted 2D Christmas Tree Outdoor Decoration, featuring a green tree with white snow accents, red and white ornaments, a star topper, and three gift boxes at the base, illuminated at night in a snowy outdoor setting.

PACKAGE CONTENTS


Please ensure all components are present before beginning assembly:

- 6ft 2D Lighted Christmas Tree (with integrated LED lights)
- 3 Lighted Gift Boxes
- Ground Stakes (11 pieces)
- Durable Connectors
- Steel Wingnuts
- Storage Bag
- Assembly Guide (this manual)

SETUP INSTRUCTIONS

Follow these steps for proper assembly and placement of your Christmas tree decoration:

1. **Unpack Components:** Carefully remove all parts from the packaging. Inspect for any damage.
2. **Assemble the Tree:** The 2-dimensional design allows for straightforward assembly. Connect the tree sections using the provided durable connectors and steel wingnuts. Ensure all connections are secure.
3. **Position Gift Boxes:** Place the three lighted gift boxes at the base of the tree as desired.
4. **Secure to Ground:** For outdoor use, utilize the 11 ground stakes to firmly anchor the tree and gift boxes into the ground. This prevents movement due to wind or other elements.



2-Dimensional Design
lightweight for easy setup
and stores flat




Image: An illustration demonstrating the 2-dimensional design of the Christmas tree and gift boxes, highlighting their lightweight structure for easy setup and flat storage.

Durable Construction



Image: A person's hands using a hammer to insert a ground stake into the snowy ground next to a lighted gift box, demonstrating the durable construction and securing method.

OPERATING INSTRUCTIONS

The Best Choice Products 6ft Lighted 2D Christmas Tree features integrated LED lights for immediate illumination.

1. **Power Connection:** Once assembled and secured, plug the power cord into a standard outdoor-rated electrical outlet.
2. **Light Functions:** The tree and gift boxes are pre-lit with 170 LED lights. The tree's foliage features steady lights, while the snow accents and star topper include twinkling lights. No additional controls are typically required for basic operation.

170 LED Lights

Twinkling lights in
snow and star



Image: A close-up view of the 6ft Lighted 2D Christmas Tree, showcasing the 170 LED lights, with steady lights on the green foliage and twinkling lights on the white snow and star topper.

Product Video

Video: This video demonstrates the illuminated 2D Lighted Outdoor Christmas Tree in various settings, showcasing its design and light effects.

MAINTENANCE

Proper care ensures the longevity of your decoration:

- **Cleaning:** Gently wipe the surface with a soft, dry cloth to remove dust or debris. Do not use harsh chemicals or abrasive cleaners.
- **Weather Resistance:** The decoration is designed with a vibrant metal frame and sturdy connectors to withstand outdoor elements. However, during extreme weather conditions (e.g., heavy storms, blizzards), it is recommended to temporarily store the decoration indoors to prevent potential damage.
- **Storage:** After the holiday season, disassemble the tree by reversing the setup steps. The 2-dimensional design

allows the pieces to stack flat. Store all components, including the tree sections, gift boxes, stakes, and connectors, in the provided storage bag in a cool, dry place.



Easy Storage

Storage Bag Included

Image: An individual dressed as an elf placing the folded Christmas tree decoration into a red storage bag labeled 'bcp', demonstrating the ease of storage.

TROUBLESHOOTING

If you encounter any issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lights not illuminating	Power cord not properly plugged in; faulty outlet; loose connection.	Ensure the power cord is securely plugged into a working outlet. Check for any loose connections in the wiring. Test the outlet with another device.

Problem	Possible Cause	Solution
Decoration unstable or leaning	Insufficient ground stakes; loose connectors.	Ensure all 11 ground stakes are fully inserted into the ground. Tighten all steel wingnuts and connectors between tree sections.
Some lights are out	Individual LED bulb failure.	LED lights are generally long-lasting. If a few individual bulbs fail, the rest of the string should remain lit. Replacement bulbs are typically not user-serviceable for integrated LED designs.

SPECIFICATIONS

Key product details:

Feature	Detail
Brand	Best Choice Products
Model Number	SKY8076
Product Dimensions	12"(L) x 30"(W) x 72"(H)
Large Present Dimensions	10"(W) x 12.5"(H)
Small Present Dimensions	8"(W) x 9.5"(H)
Color	Red/White
Material	Metal
Item Weight	8.5 Pounds
Number of LED Lights	170
Light Color	White
Recommended Use	Outdoor
UPC	842957146468



30in

21in



10in

12.5in



8in

9.5in



6ft

30in

Image: A visual representation of the dimensions for the 6ft Lighted 2D Christmas Tree, including its height and width, and the dimensions of the accompanying large and small gift boxes, along with the storage bag.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or visit the official Best Choice Products website. Keep your purchase receipt for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DKL7B8BT>

More documents and user manuals: **<https://manuals.plus/>**