

[Manuals.plus](#) /

› [ATMPC](#) /

› ATMPC T10 Android 14 Tablet User Manual

ATMPC T10

ATMPC T10 Android 14 Tablet User Manual

Model: T10

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your ATMPC T10 Android 14 Tablet. Please read this guide thoroughly to ensure optimal performance and longevity of your device.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your product package:

- ATMPC T10 Android Tablet
- Bluetooth Keyboard
- Wireless Mouse
- Stylus
- Protective Case
- USB-C Data Cable
- User Manual




Image: The ATMPc T10 tablet displayed with its accompanying accessories, including a keyboard, mouse, stylus, protective case, and charging cable.

3. PRODUCT OVERVIEW

The ATMPc T10 is a 10.1-inch Android 14 tablet designed for versatility and performance. It features an Octa-Core processor, 12GB RAM (4GB physical + 8GB virtual), and 128GB internal storage, expandable up to 1TB via a microSD card. The tablet supports Wi-Fi 6 and Bluetooth 5.4 for robust connectivity. It is equipped with a 6000mAh battery, dual HD cameras (2MP front, 5MP rear), and a 1280x800 IPS display.




Image: An infographic highlighting key specifications of the ATMPc T10 tablet, including its Android 14 operating system, 10.1-inch FHD display, 12GB RAM, 128GB ROM, Octa-Core processor, 6000mAh battery, Wi-Fi 6, and dual cameras.

4. SETUP

4.1 Charging the Tablet

Before first use, fully charge the tablet using the provided USB-C data cable and a compatible power adapter (not included). The 6000mAh battery provides extended usage time.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the screen illuminates.
- **To Power Off:** Press and hold the Power button, then select 'Power off' from the options on the screen.
- **To Restart:** Press and hold the Power button, then select 'Restart' from the options.

4.3 Initial Setup

Upon first power-on, follow the on-screen prompts to:

- Select your language.
- Connect to a Wi-Fi network.
- Sign in with your Google account or create a new one.
- Set up security features (PIN, pattern, password).

4.4 Connecting Accessories

The ATMPC T10 tablet comes with a Bluetooth keyboard, wireless mouse, and stylus for enhanced productivity.

4.4.1 Bluetooth Keyboard Connection

1. Ensure the keyboard is charged.
2. Flip the power switch on the keyboard to the 'ON' position.
3. Press the 'Connect' button on the keyboard to enter pairing mode.
4. On your tablet, go to **Settings > Connected devices > Pair new device**.
5. Select 'BT Keyboard' from the list of available devices and tap 'Pair'.
6. Confirm the connection.



Image: A visual guide demonstrating the six steps to connect the Bluetooth keyboard to the ATMPC T10 tablet, from powering on the keyboard to confirming the pairing on the tablet's screen.

4.4.2 Wireless Mouse Connection

1. Ensure the mouse has working batteries.
2. Flip the power switch on the mouse to the 'ON' position.
3. On your tablet, go to **Settings > Connected devices > Pair new device**.
4. Select 'BT Mouse' from the list of available devices and tap 'Pair'.
5. Confirm the connection.

Powerful, Ample, Efficient




Image: A visual guide demonstrating the steps to connect the wireless mouse to the ATMP C T10 tablet, from powering on the mouse to confirming the pairing on the tablet's screen.

4.4.3 Stylus Usage

The stylus does not require pairing. Simply use it to interact with the tablet screen for drawing, writing, or precise navigation.

5. OPERATING THE TABLET

5.1 Navigation

The ATMP C T10 uses a multi-touch IPS display. Navigate by tapping, swiping, pinching, and spreading fingers on the screen. The Android 14 operating system provides an intuitive user interface.

5.2 Wi-Fi Connection

The tablet supports dual-band Wi-Fi 6 (2.4G/5G) for fast and stable internet connectivity. To connect:

1. Go to **Settings > Network & internet > Internet**.
2. Turn on Wi-Fi.
3. Select your desired network from the list and enter the password if prompted.

5.3 Bluetooth Connection

Bluetooth 5.4 allows connection to various devices like headphones, speakers, and other peripherals. To connect:

1. Go to **Settings > Connected devices > Connection preferences > Bluetooth**.
2. Turn on Bluetooth.
3. Select 'Pair new device' and choose your device from the list.

5.4 Storage Management

The tablet comes with 128GB of internal storage. You can expand this by inserting a microSD card (up to 1TB) into the designated slot. To manage storage, go to **Settings > Storage**.

5.5 Split Screen Functionality

Android 14 supports split-screen mode, allowing you to use two applications simultaneously. This enhances multitasking

for activities like comparing documents or watching a video while browsing.

Immerse Audio Stereo Sound



Dual-band WiFi 6



Long Lasting Battery



Capture Wonderful Moments



Image: The ATMPC T10 tablet displaying two applications side-by-side in split-screen mode, with the Bluetooth keyboard connected, illustrating enhanced productivity.

5.6 Camera Usage

The tablet features a 2MP front camera and a 5MP rear camera. Open the Camera application to capture photos and videos. Adjust settings within the app for different modes and effects.

5.7 Audio

The ATMPC T10 provides immersive stereo sound. It also includes a 3.5mm audio jack for connecting wired headphones or external speakers.



Image: A person wearing headphones while using the ATMPc T10 tablet, highlighting the tablet's audio capabilities and the presence of a 3.5mm audio jack.

6. MAINTENANCE

6.1 Cleaning

- Use a soft, lint-free cloth to clean the screen and tablet body.
- Avoid using harsh chemicals, abrasive cleaners, or aerosol sprays.
- For stubborn smudges, lightly dampen the cloth with water or a screen-specific cleaning solution.

6.2 Battery Care

- Avoid fully discharging the battery frequently.
- Do not expose the tablet to extreme temperatures (hot or cold).
- Use only the provided or certified charging cables.

6.3 Software Updates

Periodically check for system updates to ensure your tablet has the latest features and security patches. Go to **Settings > System > System update**.

7. TROUBLESHOOTING

If you encounter issues with your ATMPc T10 tablet, refer to the following common solutions:

- **Tablet not powering on:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
- **Wi-Fi connectivity issues:** Restart your Wi-Fi router and the tablet. Ensure you are within range of the Wi-Fi signal and have entered the correct password.
- **Bluetooth accessory not pairing:** Ensure the accessory is in pairing mode and fully charged. Restart the tablet and try pairing again.
- **Slow performance:** Close unused applications. Clear cache from apps in **Settings > Apps**. Consider freeing up storage space.
- **Screen unresponsive:** Force restart the tablet by holding the power button for approximately 10-15 seconds.

If problems persist, contact customer support for further assistance.

8. SPECIFICATIONS

Feature	Specification
Model	T10
Operating System	Android 14
Screen Size	10.1 Inches
Screen Resolution	1280 x 800 pixels (IPS)
Processor	Octa-Core
RAM	12GB (4GB + 8GB Expand)
Internal Storage	128GB ROM
Expandable Storage	Up to 1TB via MicroSD card
Wireless Connectivity	Wi-Fi 6 (802.11 ac, 2.4G/5G)
Bluetooth	Bluetooth 5.4
Front Camera	2MP
Rear Camera	5MP
Battery Capacity	6000mAh Lithium Polymer
Average Battery Life	6 Hours (video playback)
Dimensions (LxWxH)	9.6 x 6.4 x 0.37 inches
Item Weight	2.88 pounds
Color	Silver Gray

9. WARRANTY AND SUPPORT

Your ATMPC T10 tablet is covered by a manufacturer's warranty and dedicated customer support.

- **Warranty:** 1 Year Manufacturer Warranty.
- **Returns:** 30 Days Free Return policy.
- **Customer Service:** 24/7 Online Service.
- **Response Time:** Replies within 24 hours.
- **Email Support:** atmpcservice@163.com



Image: A graphic detailing ATMP's hassle-free protection, including a 1-year manufacturer warranty, 30-day free returns, 24/7 online service, and email support with a 24-hour response time.

© 2024 ATMP. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DKP3YM2C>

More documents and user manuals: <https://manuals.plus/>