

Samsung VG-TM1240AN/ZA

Samsung Universal IR Remote Control User Manual

Model: VG-TM1240AN/ZA

1. INTRODUCTION

This manual provides comprehensive instructions for the Samsung Universal IR Remote Control, model VG-TM1240AN/ZA. This remote is designed to operate compatible Samsung televisions using traditional infrared (IR) signals. It offers a user-friendly interface for controlling various TV functions.





Image: Front view of the Samsung Universal IR Remote Control, showing all buttons and the Samsung logo at the bottom.

2. WHAT'S IN THE BOX

Verify that all items are present in the package:

- Samsung Universal IR Remote Control (Model VG-TM1240AN/ZA)
- AAA Batteries (x2)
- User Manual (this document)








Image: The remote control displayed with its dimensions and a list of included items: IR Remote, Batteries (2x AAA included), Manual, Warranty.

3. SETUP

The Samsung Universal IR Remote Control is designed for immediate use with compatible Samsung TVs. No complex pairing or setup procedures are required.

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Replace the battery cover by sliding it upwards until it clicks into place.

Once batteries are installed, the remote is ready for operation. Point the remote directly at your Samsung TV.





Image: Back view of the remote control, highlighting the battery compartment cover.

Wide compatibility

Compatible with all Samsung TV models from 2012 and after.




Image: The remote control resting on a light-colored surface, accompanied by text indicating "Quick and easy" setup, emphasizing that no pairing is needed.

4. OPERATING INSTRUCTIONS

The remote control features a standard layout for intuitive operation of your Samsung TV. Ensure a clear line of sight between the remote's IR emitter and the TV's IR receiver.

4.1 Button Functions Overview



Image: Close-up front view of the remote control, clearly displaying all buttons and their labels.

- **Power ()**: Turns the TV on or off.
- **Source**: Selects the input source (HDMI, AV, etc.).
- **Number Pad (0-9)**: Directly enters channel numbers.
- **Pre-CH**: Returns to the previous channel.
- **Volume (+/-)**: Adjusts the volume level.
- **Mute**: Mutes or unmutes the TV audio.
- **Channel (CH Up/Down)**: Changes channels sequentially.
- **CH List**: Displays the channel list.
- **Sleep**: Sets a sleep timer for the TV.
- **Settings**: Accesses the TV's settings menu.
- **Home (△)**: Navigates to the Smart Hub or main menu.
- **Guide**: Displays the electronic program guide.
- **Info (i)**: Shows information about the current program.
- **Navigation Pad (Up/Down/Left/Right/Enter)**: Navigates through menus and selects options.
- **Return**: Goes back to the previous screen or menu.
- **Exit**: Exits the current menu or application.
- **Color Buttons (A, B, C, D)**: Functionality varies by TV model and application.
- **E-Manual**: Accesses the TV's electronic manual.
- **P. Size**: Adjusts picture size/aspect ratio.
- **CC/VD**: Activates Closed Captions or Video Description.
- **Media Control Buttons (Play, Pause, Stop, Fast Forward, Rewind)**: Controls media playback.

5. COMPATIBILITY

This Samsung Universal IR Remote Control is compatible with all Samsung TV models manufactured from 2012 onwards. It utilizes standard infrared signals, ensuring broad compatibility without the need for complex programming or code entry.

Model: Samsung Universal IR Remote



What's in the box:

- IR Remote
- Batteries (2x AAA included)
- Manual
- Warranty

Dimensions:

(INCHES W x H x D):

- Remote Size: 1.77 x 6.89 x 0.89
- Compatibility: 2012 – present, all current Samsung TVs

Features and specifications subject to change.

Image: The remote control positioned on a table next to a plant, with text emphasizing "Wide compatibility" for Samsung TV models from 2012 and after.

6. MAINTENANCE

6.1 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using abrasive cleaners, solvents, or alcohol, as these can damage the remote's surface and internal components.

6.2 Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both AAA batteries simultaneously with new ones. Do not mix old and new batteries, or different types of batteries, as this can lead to leakage or malfunction.

6.3 Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, remove the batteries to prevent potential leakage and damage.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries. Obstruction between remote and TV. Remote out of range.	<ul style="list-style-type: none">• Replace batteries with new AAA batteries, ensuring correct polarity.• Remove any objects blocking the line of sight to the TV's IR receiver.• Move closer to the TV.
Specific buttons not working.	Button malfunction or TV not supporting the function.	<ul style="list-style-type: none">• Ensure your TV model supports the specific function (e.g., "Sleep" button functionality can vary).• Clean the remote surface around the button.
Remote works intermittently.	Low battery power. Interference.	<ul style="list-style-type: none">• Replace batteries.• Ensure no strong light sources (like direct sunlight) are interfering with the IR signal.

8. SPECIFICATIONS

Feature	Detail
Model Number	VG-TM1240AN/ZA
Brand	Samsung
Connectivity Technology	Infrared (IR)
Compatible Devices	Samsung Televisions (2012 models and newer)
Power Source	2 x AAA Batteries (included)
Product Dimensions (L x W x H)	6.89 x 1.77 x 0.89 inches (17.5 x 4.5 x 2.26 cm)
Item Weight	2.82 ounces (80 grams)
Color	Black
Special Features	Ergonomic, Lightweight

Quick and easy

Simply insert batteries — no pairing or setup needed.*



* This remote may control any device that uses an IR signal.

Image: Side profile of the remote control, illustrating its ergonomic design.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official Samsung website or contact Samsung customer service directly. Keep your purchase receipt as proof of purchase.

Samsung Customer Service: www.samsung.com/us/support/