

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Xtrike Me](#) /
- › [Xtrike Me KB-229 EN USB Wired Keyboard User Manual](#)

Xtrike Me KB-229 EN

Xtrike Me KB-229 EN USB Wired Keyboard User Manual

INTRODUCTION

The Xtrike Me KB-229 EN wired keyboard is a reliable and efficient input device designed for comfortable and precise typing. It features a standard layout with 104 keys, providing a comprehensive range of functions for everyday computing tasks. Engineered for durability, this keyboard offers an impressive operating life of up to 10 million keystrokes. Its USB 2.0 connectivity and a 1.4-meter cable ensure a stable and hassle-free connection to your computer. With a modern and elegant design, it integrates seamlessly into various workspace setups. Weighing 690 grams, it offers a solid feel while remaining portable. This keyboard is an ideal choice for users seeking a dependable wired keyboard with a classic design and robust construction, suitable for both professional work and leisure activities.



Image: The Xtrike Me KB-229 EN USB Wired Keyboard, showcasing its full layout and design.

PACKAGE CONTENTS

Please verify that all items are present in the package before proceeding with the setup.

- Xtrike Me KB-229 EN USB Wired Keyboard
- Integrated USB Cable



Image: The Xtrike Me KB-229 EN USB Wired Keyboard as it appears in its retail packaging.

SETUP INSTRUCTIONS

1. **Unpack the Keyboard:** Carefully remove the Xtrike Me KB-229 EN keyboard from its packaging.
2. **Connect to Computer:** Locate an available USB port on your computer. Insert the USB connector of the keyboard firmly into the USB port.
3. **Driver Installation:** The keyboard is plug-and-play. Your operating system (Windows, macOS, Linux) should automatically detect and install the necessary drivers. This process may take a few moments.
4. **Verify Functionality:** Once the drivers are installed, open a text editor or any application that accepts text input and test the keyboard by typing. Ensure all keys respond correctly.
5. **Positioning:** Place the keyboard on a stable, flat surface in a comfortable position for typing.

OPERATING INSTRUCTIONS

Basic Typing

The Xtrike Me KB-229 EN features a standard 104-key layout. Simply press the desired keys to input characters, numbers, and symbols into your computer.

Special Features: Multi-color Backlight

This keyboard includes a multi-color backlight feature. Specific key combinations or dedicated keys (if present, typically indicated by a sun or lightbulb icon) can be used to toggle the backlight on/off or adjust its brightness and color modes. Refer to the keyboard's key legends for any specific backlight control keys.



Image: Close-up view of the Xtrike Me KB-229 EN keyboard keys, highlighting the multi-color backlight feature.

MAINTENANCE

- **Cleaning:** To clean the keyboard, disconnect it from your computer. Use a soft, damp cloth to wipe the surface. For dust and debris between keys, use compressed air. Avoid using harsh chemicals or abrasive materials.
- **Spills:** In case of liquid spills, immediately disconnect the keyboard from the computer. Invert the keyboard to drain excess liquid and allow it to dry completely for at least 24-48 hours before reconnecting.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------------------------|---|--|
| Keyboard not responding | Loose USB connection, faulty USB port, driver issue. | Ensure the USB cable is securely plugged into both the keyboard and the computer. Try connecting the keyboard to a different USB port on your computer. Restart your computer. Check Device Manager (Windows) or System Information (macOS) to see if the keyboard is recognized. Reinstall drivers if necessary. |
| Specific keys not working | Debris under the key, physical damage, software conflict. | Disconnect the keyboard and use compressed air to clear any debris from under the affected keys. Test the keyboard on another computer to rule out software issues. If the issue persists, the key may be physically damaged. |

| Problem | Possible Cause | Solution |
|-------------------------------------|---|--|
| Backlight not working or flickering | Backlight control setting, power issue, hardware malfunction. | <p>Ensure the backlight is enabled using the designated control keys (if any).</p> <p>Try reconnecting the keyboard to a different USB port.</p> <p>Restart your computer.</p> |

SPECIFICATIONS

| Feature | Detail |
|-------------------------|-------------------------|
| Brand | Xtrike Me |
| Model Number | XT-KB-229-EN |
| Product Dimensions | 44.8 x 16.6 x 2.6 cm |
| Item Weight | 690 grams |
| Number of Keys | 104 |
| Key Life | 10 million clicks |
| Connectivity Technology | USB 2.0 (Wired) |
| Cable Length | 1.4 meters |
| Compatible Devices | Devices with a USB port |
| Keyboard Type | Membrane Keyboard |
| Special Feature | Multi-color backlight |
| Material | Plastic |
| Color | Black |

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact the manufacturer directly. Keep your proof of purchase for warranty claims.

