

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Chapolino](#) /

› [Chapolino Peak i-Size Child Car Seat User Manual](#)

Chapolino STKPK02403MA

Chapolino Peak i-Size Child Car Seat User Manual

Model: STKPK02403MA

1. INTRODUCTION

Thank you for choosing the Chapolino Peak i-Size Child Car Seat. This manual provides essential information for the safe and correct installation, operation, and maintenance of your car seat. Please read this manual thoroughly before first use and keep it for future reference.



Figure 1.1: The Chipolino Peak i-Size Child Car Seat, showcasing its ergonomic design and soft beige padding. This image provides a general overview of the product.

2. SAFETY INFORMATION

Your child's safety is paramount. Always adhere to the following safety guidelines:

- Ensure the car seat is correctly installed according to the instructions before every journey.
- Never leave your child unattended in the car seat.
- Always secure your child with the 5-point harness, ensuring it is snug and not twisted.
- The car seat is suitable for children with a height of 40 to 150 cm (from birth to approximately 12 years, max. 36 kg).
- For children 40 to 105 cm (0 to 18 kg), use the car seat in **rearward-facing** position.

- For children 100 to 150 cm, use the car seat in a**forward-facing** position with the vehicle's seat belt.
- Do not use the car seat on passenger seats equipped with an active front airbag when installed rearward-facing.
- Regularly check all parts for wear and tear. Discontinue use if any damage is found.

3. PRODUCT FEATURES

The Chipolino Peak i-Size Car Seat is designed with advanced features for comfort and safety:

- **i-Size Compliance:** Meets the latest European safety standard ECE R129.
- **Isofix System:** Provides a secure and rigid connection to the vehicle's chassis.
- **Top Tether:** An additional anchor point for enhanced stability and reduced forward movement in a collision.
- **Side Protection System (SPS):** Integrated side impact protection for increased safety.
- **360° Rotatable Seat:** Allows easy access for placing and removing your child, and effortless switching between rearward and forward-facing positions.
- **Rebound Bar:** Reduces rebound and seat rotation when the Top Tether is installed.
- **Adjustable 5-Point Harness:** Length-adjustable with soft shoulder pads for a secure and comfortable fit.
- **Multi-Position Backrest:** Adjustable to 3 positions for optimal comfort.
- **Height-Adjustable Headrest:** Grows with your child, ensuring proper head and neck support.
- **Soft Padding & 3D Cushion:** Provides comfort and reduces pressure on the child's waist and back.
- **Removable and Washable Padding:** For easy cleaning and hygiene.

4. SETUP AND INSTALLATION

Proper installation is crucial for safety. Follow these steps carefully:

4.1 Isofix and Top Tether Installation (40-105 cm, Rearward-Facing)

1. Locate the Isofix anchor points in your vehicle.
2. Extend the Isofix connectors from the car seat base.
3. Push the Isofix connectors firmly onto the vehicle's anchor points until you hear a click and the indicators turn green.
4. Locate the Top Tether anchor point in your vehicle (usually behind the rear seat or in the trunk).
5. Attach the Top Tether strap hook to the anchor point and tighten the strap until the indicator turns green.
6. Ensure the car seat is firmly secured and does not move excessively.



Figure 4.1: Side view illustrating the extended Isofix connectors and the Top Tether strap, ready for installation in the vehicle. The SPS label is also visible.



Figure 4.2: Rear view of the car seat, highlighting the i-Size certification label and the structure for Isofix attachment, ensuring proper and secure installation.

4.2 Vehicle Seat Belt Installation (100-150 cm, Forward-Facing)

1. Place the car seat on the vehicle's seat in a forward-facing position.
2. Guide the vehicle's 3-point seat belt through the designated belt guides on the car seat.
3. Ensure the lap belt is low across your child's hips and the shoulder belt rests across the center of their shoulder and chest.
4. Buckle the vehicle's seat belt and pull it tight to remove any slack.

5. OPERATING THE CAR SEAT

5.1 360° Rotation

To rotate the seat, locate the rotation lever on the base (refer to Figure 5.1). Press the lever and turn the seat to the desired position (rearward-facing or forward-facing). Ensure it locks securely into place before driving.



Figure 5.1: This image demonstrates the 360-degree rotation capability of the car seat, allowing for easy transitions between rearward and forward-facing positions.

5.2 Harness Adjustment

The 5-point harness can be adjusted in length. Press the harness release button (usually located at the front of the seat) and pull the shoulder straps to loosen. To tighten, pull the adjustment strap until the harness is snug against your child's body. Ensure the shoulder pads are positioned correctly.

5.3 Headrest and Backrest Adjustment

The headrest can be adjusted in height to accommodate your growing child. Locate the headrest adjustment lever (usually at the top of the headrest) and pull it up or down to the desired height. The backrest can be reclined to 3 positions for comfort. Refer to the labels on the side of the seat for visual guidance (Figure 5.2).



Figure 5.2: The car seat shown in a reclined position, demonstrating the adjustable backrest feature for enhanced child comfort during travel.

6. MAINTENANCE AND CLEANING

To ensure the longevity and hygiene of your car seat:

- **Padding:** The soft padding and 3D cushion are removable and washable. Please refer to the care label on the fabric for specific washing instructions (e.g., hand wash or machine wash on a gentle cycle with mild detergent). Do not tumble dry.
- **Plastic Parts:** Wipe plastic parts with a damp cloth and mild soap. Do not use abrasive cleaners or solvents.
- **Harness:** Clean the harness straps with a damp cloth. Do not immerse the buckle in water.
- **Storage:** When not in use, store the car seat in a clean, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter any issues with your Chipolino Peak i-Size Car Seat, please refer to the following common solutions:

- **Car Seat Feels Loose After Installation:** Double-check that the Isofix connectors are fully engaged (green indicators visible) and the Top Tether is tightened correctly. For belt installation, ensure the vehicle belt is

pulled taut and routed through all designated guides.

- Harness Difficult to Adjust:** Ensure the harness release button is fully pressed when loosening. Check for any twists in the straps. If the harness is stiff, ensure it is clean and free of debris.
- Seat Rotation is Stiff:** Ensure the rotation lever is fully engaged. Check for any obstructions around the base of the seat.
- Child Not Comfortable:** Adjust the headrest height and backrest recline position to suit your child's size and comfort. Ensure the padding is correctly installed.

If the problem persists, please contact Chipolino customer support or your retailer for further assistance.

8. SPECIFICATIONS

Feature	Detail
Model Number	STKPK02403MA
Recommended Age	Birth to approx. 12 years
Height Range	40 - 150 cm
Maximum Supported Weight	36 kg
Product Dimensions (L x W x H)	60 x 52 x 60 cm
Item Weight	13.5 kg
Main Material	Fabric (100% Polyester)
Color	Beige
Special Features	i-Size, Isofix, SPS, 360° Rotation, Rebound Bar

9. WARRANTY AND SUPPORT

For information regarding the warranty period and terms for your Chipolino Peak i-Size Child Car Seat, please refer to the documentation provided at the time of purchase or contact your retailer. Warranty terms may vary by region and retailer.

For technical support, spare parts, or any other inquiries, please contact Chipolino customer service through their official website or the contact information provided by your local distributor. When contacting support, please have your model number (STKPK02403MA) and proof of purchase ready.

Related Documents - STKPK02403MA

