

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [DEERTIME](#) /

› [DEERTIME E15 Android 14 Tablet User Manual](#)

DEERTIME E15

DEERTIME E15 Android 14 Tablet User Manual

Model: E15

1. INTRODUCTION

Welcome to the DEERTIME E15 Android 14 Tablet user manual. This guide provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your new tablet. The DEERTIME E15 is a versatile 2-in-1 tablet PC designed for both productivity and entertainment, featuring a powerful Octa-Core processor, ample memory, and a vibrant 10.1-inch HD display.



Image: The DEERTIME E15 tablet showcasing its sleek design and included accessories.

2. WHAT'S IN THE BOX

Upon opening your DEERTIME E15 Tablet package, please ensure all the following items are present:

- DEERTIME E15 Android 14 Tablet
- Protective Case
- Wireless Keyboard
- Wireless Mouse
- Charger
- USB-C Cable
- Screen Protector (pre-applied or separate)
- User Manual (this document)



Image: All components included in the DEERTIME E15 Tablet package.

3. PRODUCT OVERVIEW

3.1 Key Features

- **Operating System:** Latest Android 14 for enhanced security and user experience.
- **Memory & Storage:** 20GB RAM (6GB physical + 14GB virtual) and 128GB internal storage, expandable up to 1TB via microSD card.
- **Display:** 10.1-inch IPS HD touchscreen with 1280x800 resolution for crisp visuals and Widevine L1 support for high-definition streaming.
- **Processor:** Powerful Octa-Core CPU (1.8GHz) for smooth performance and multitasking.
- **Battery:** 6000mAh long-lasting battery for extended usage.
- **Cameras:** 5MP front camera and 8MP rear camera for photos and video calls.
- **Connectivity:** Wi-Fi 6 (2.4G & 5G) and Bluetooth 5.0 for fast and reliable connections.

3.2 Components and Controls

Familiarize yourself with the tablet's physical components:

- **Front:** 10.1-inch IPS HD Touchscreen, 5MP Front Camera.
- **Rear:** 8MP Rear Camera, DEERTIME branding.
- **Sides:** Power Button, Volume Buttons, USB-C Port, 3.5mm Headset Jack, MicroSD Card Slot.




Image: Side view of the tablet highlighting the camera, ports, and buttons.



Image: Comprehensive overview of the DEERTIME E15 Tablet's features including RAM, ROM, display, and connectivity.

4. SETUP

4.1 Initial Power On and Setup Wizard

1. Press and hold the **Power Button** on the side of the tablet until the DEERTIME logo appears.
2. Follow the on-screen instructions to complete the initial setup wizard. This includes selecting your language, connecting to a Wi-Fi network, and signing in with your Google account.

4.2 Charging the Tablet

Before first use, fully charge the tablet using the provided charger and USB-C cable.

- Connect the USB-C cable to the tablet's USB-C port.
- Plug the charger into a power outlet.
- The battery icon on the screen will indicate charging status.

4.3 Connecting the Keyboard and Mouse

The included keyboard and mouse connect via Bluetooth.

1. Turn on the keyboard and mouse (usually a switch on the device).
2. On your tablet, go to **Settings > Connected devices > Bluetooth**.
3. Ensure Bluetooth is enabled.
4. Select the keyboard and mouse from the list of available devices to pair them. Follow any on-screen prompts for pairing codes.

4.4 Inserting a microSD Card (Optional)

To expand storage, insert a microSD card (up to 1TB) into the dedicated slot.

1. Locate the microSD card slot on the side of the tablet.
2. Gently insert the microSD card with the gold contacts facing down until it clicks into place.
3. The tablet will prompt you to format the card for use.

5. OPERATING INSTRUCTIONS

5.1 Basic Navigation

- **Touch:** Tap an icon or option to select it.
- **Swipe:** Drag your finger across the screen to scroll or navigate between screens.
- **Pinch-to-Zoom:** Use two fingers to zoom in or out on images or web pages.
- **Long Press:** Press and hold an item for more options.

5.2 Installing and Managing Applications

Applications can be downloaded from the Google Play Store.

1. Open the **Play Store** app.
2. Search for your desired application.
3. Tap **Install** to download and install.

To uninstall an app, long-press its icon on the home screen or app drawer, then drag it to the

