



[Manuals.plus](#) /

› [Dghrti](#) /

› Dghrti TAB30 Tablet 10-inch Android 14 User Manual

Dghrti TAB30

Dghrti TAB30 Tablet 10-inch Android 14 User Manual

Model: TAB30

1. INTRODUCTION

Welcome to the Dghrti TAB30 Tablet user manual. This guide provides essential information to help you set up, operate, maintain, and troubleshoot your new tablet. Please read this manual thoroughly before using your device to ensure proper functionality and to maximize your user experience.

Nueva Delgada y Ligera Android 14 Tablet

Android 14 | Octa-Core CPU | 22GB+128GB | 8000mAh



Image 1.1: Front and back view of the Dghrti TAB30 Tablet, highlighting its metallic casing and camera module.

2. WHAT'S IN THE BOX

Upon unboxing your Dghrti TAB30 Tablet, please verify that all the following items are included:

- Dghrti TAB30 Tablet
- Mouse
- Bluetooth Keyboard
- Protective Case
- OTG Converter
- Screen Protector Film
- SD Card Pin Ejector Tool
- Charger



Image 2.1: The Dghrti TAB30 Tablet shown with its complete set of accessories, including the keyboard, mouse, and protective case.

3. PRODUCT OVERVIEW

3.1 Key Features

- **Display:** 10.1-inch Full HD IPS screen (1920x1200 resolution) for vivid colors and sharp images.
- **Performance:** Unisoc T606 Octa-Core CPU (2.0GHz A75 high-performance core, A55 high-efficiency core) for smooth multitasking.
- **Memory:** 22GB RAM (6GB physical + 16GB virtual) and 128GB ROM, expandable up to 1TB via microSD card.
- **Battery:** 8000mAh long-lasting battery for extended usage.
- **Operating System:** Latest Android 14 with enhanced privacy protection and smart notification management.
- **Cameras:** 8MP rear camera and 5MP front camera for video calls and capturing moments.
- **Connectivity:** Dual-band 5G WiFi and Bluetooth 5.0 for stable and fast connections.
- **Security:** Face ID for quick and secure access.
- **Audio:** Dual stereo speakers for an immersive sound experience.
- **Streaming:** Widevine L1 support for high-definition streaming on platforms like Netflix, Amazon Prime Video, and YouTube.

3.2 Components and Ports

Familiarize yourself with the physical components of your tablet:

Potente Octa-Core Procesador




T606 Octa-Core
Unisoc



A75 Alto Rendimiento
A55 Eficiencia Energética



Proceso de 12nm
Bajo Calor y Alta Eficiencia energética



Poder Duradero

La enorme batería de 8000 mAh te permite ver vídeos, jugar, estudiar y trabajar hasta un día entero.



8000 mAh
Batería de alta capacidad



Type-C
Puerto de carga universal

Image 3.1: Illustration of the tablet's internal components, highlighting the T606 Octa-Core processor and the 8000mAh battery capacity.


Tecnología Compatibilidad

Widevine L1 Netflix, experimenta una reproducción de vídeo de alta calidad y una sensación de imagen colorida con una pantalla Full HD de 10,1 pulgadas de resolución



Fácil de Usar

5G WIFI BT 5.0 Protección Ocular



Cuerpo Metálico Nueva Cámara



Image 3.2: Visual representation of key features including Widevine L1 support, 5G WiFi, Bluetooth 5.0, and the tablet's metallic construction.



Image 3.3: Details on the tablet's 8MP rear camera and 5MP front camera, suitable for video calls and photography.

4. SETUP

4.1 Initial Charging

Before first use, fully charge your tablet using the provided charger and USB-C cable. The charging port is typically located on the side or bottom edge of the tablet.

4.2 Power On/Off

- **To Power On:** Press and hold the power button until the Dghrti logo appears.
- **To Power Off:** Press and hold the power button, then select 'Power Off' from the options on the screen.

4.3 Initial Setup Wizard

Follow the on-screen instructions to complete the initial setup, which includes:

- Selecting your language.
- Connecting to a Wi-Fi network.

- Setting up your Google account.
- Configuring screen lock (PIN, pattern, password, or Face ID).

4.4 Inserting a MicroSD Card

To expand storage, locate the SIM/MicroSD card tray on the side of the tablet. Use the provided ejector tool to open the tray, insert the MicroSD card (up to 1TB), and close the tray securely.

4.5 Connecting Accessories

- **Bluetooth Keyboard/Mouse:** Turn on the keyboard/mouse and enable Bluetooth on your tablet (Settings > Connected devices > Bluetooth). Pair the devices by selecting them from the list of available devices.
- **OTG Converter:** Use the OTG converter to connect USB devices like flash drives or external hard drives to your tablet's USB-C port.

5. OPERATING INSTRUCTIONS

5.1 Android 14 Features

Your tablet runs on Android 14, offering enhanced privacy controls, smarter notifications, and more customization options.

Android 14 Reforzar Protección Intimidad



Android 14
A tu medida



Vista Paralela
OExperiencia horizontal optimizada



Privacidad y Seguridad
Gestión de permisos



1TB Memoria Extragrande

Ejecuta Rpeed Para una Mejor Experiencia



22 RAM (6+16)GB



128GB ROM



TF 1TB

Image 5.1: Overview of Android 14's privacy and security enhancements, including permission management and optimized horizontal view.

Android 14 Más sorpresas

Productividad
Trabajar con documentos

Nueva interfaz de usuario
Personaliza tu estilo favorito

Nuevas funciones
Mejor experiencia de usuario

Seguridad del sistema
Protege la información privada




Image 5.2: Visual representation of Android 14's new features, including productivity tools, new UI, and system security.

5.2 Navigation

- **Home Screen:** Swipe up from the bottom to access the app drawer.

- **Notifications:** Swipe down from the top of the screen to view notifications and quick settings.
- **Multitasking:** Swipe up and hold from the bottom to see recent apps.

5.3 Face ID

To set up Face ID, go to Settings > Security > Face Unlock and follow the on-screen instructions. Ensure good lighting for optimal performance.

5.4 Multi-Window and Split-Screen

The tablet supports multi-window and split-screen functions for enhanced productivity. To activate, open a recent app, tap its icon at the top of the preview, and select 'Split screen' or 'Freeform'.




Image 5.3: Examples of the tablet's versatile use, including learning, entertainment, facial unlock, and multi-screen functionality.

5.5 Wi-Fi Screencasting

You can cast your tablet's screen to compatible devices (e.g., smart TVs) using Wi-Fi screencasting. Access this feature from Quick Settings or Settings > Connected devices > Cast.

Pantalla IPS de 10 pulgadas

Más agradable para ver vídeos



Función WIFI screencasting

Transmite la pantalla a otros dispositivos



Image 5.4: The 10-inch IPS display for video viewing and the WiFi screencasting function for transmitting the screen to other devices.

6. MAINTENANCE

6.1 Cleaning Your Tablet

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials that could damage the surface. For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution.

6.2 Software Updates

Regularly check for and install software updates to ensure your tablet has the latest features, security patches, and performance improvements. Go to Settings > System > System update to check for updates.

6.3 Battery Care

- Avoid extreme temperatures, as they can degrade battery life.
- Do not leave the tablet charging for excessively long periods after it's fully charged.
- Use only the original charger or a certified compatible charger.

6.4 Storage Management

Periodically clear unnecessary files, apps, and cache to maintain optimal performance. You can manage storage in Settings > Storage.

7. TROUBLESHOOTING

If you encounter issues with your Dghrti TAB30 Tablet, refer to the following common solutions:

Problem	Possible Solution
Tablet does not power on	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, perform a forced restart by holding the power button for 10-15 seconds.

Problem	Possible Solution
Apps are crashing or freezing	Clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache). If the problem persists, uninstall and reinstall the app. Ensure sufficient free storage space.
Wi-Fi connection issues	Restart your Wi-Fi router and the tablet. Forget the Wi-Fi network (Settings > Network & internet > Internet > [Network Name] > Forget) and reconnect. Ensure you are within range of the Wi-Fi signal.
Slow performance	Close unused apps running in the background. Clear cache and temporary files. Uninstall unnecessary apps. Consider a factory reset as a last resort (back up your data first).
Face ID not working	Ensure your face is well-lit and not obstructed. Clean the front camera lens. Re-register your face in Settings > Security > Face Unlock.

8. SPECIFICATIONS

Detailed technical specifications for the Dghrti TAB30 Tablet:

- **Model Name:** TAB30
- **Operating System:** Android 14
- **Processor:** Unisoc T606 Octa-Core (2 GHz CPU Speed)
- **RAM:** 22 GB (6GB installed + 16GB virtual)
- **Internal Storage:** 128 GB
- **Expandable Storage:** Up to 1 TB via MicroSD card
- **Display:** 10.1-inch LED IPS, 1920x1200 maximum resolution, 1280x800 native resolution, 16:10 aspect ratio
- **Battery:** 8000 mAh Lithium Polymer
- **Rear Camera:** 8 MP
- **Front Camera:** 5 MP
- **Connectivity:** Dual-band Wi-Fi (802.11a/b/g/n/ac), Bluetooth 5.0, USB-C, 3.5mm Audio
- **Special Features:** Face Recognition, Multi-Window, Split-Screen, GPS
- **Dimensions:** 24.21 x 16.1 x 0.79 cm
- **Weight:** 480 g

Aproveche su potencial **Precisión, potencia, perfección: Unisoc T606.**

El Unisoc T606 incorpora un núcleo A75 de alto rendimiento. Junto con el núcleo A55 de alta eficiencia, proporciona una experiencia de tableta más fluida.




Image 8.1: Detailed view of the Unisoc T606 Octa-Core processor, highlighting its A75 and A55 cores and 2.0GHz frequency.

Más espacio de almacenamiento, más opciones



22GB RAM
6GB+16GB Expansión

128GB ROM

UP to 1TB
Micro SD Expansión

Image 8.2: Information on the tablet's 22GB RAM, 128GB ROM, and support for up to 1TB Micro SD expansion.

Batería duradera de 8000mAh

La batería de litio de gran capacidad de 8000mAh y el procesador de bajo consumo te permiten ver vídeos hasta 6 horas. Y el puerto Type-C estándar para una carga cómoda.

8000mAh **Type-C**

8000 mAh

4-5hrs 4-6hrs
7hrs 8hrs
8hrs



Image 8.3: Visual representation of the 8000mAh battery capacity and estimated usage times for various activities.

Proporción áurea visualización cómoda

Pantalla grande de 10 pulgadas de proporción dorada, cómoda para ver vídeos y navegar por Internet. Protege tus ojos y evita la fatiga ocular.

10.1inch **Protección para los ojos**




Image 8.4: The 10.1-inch display, designed for comfortable viewing and reduced eye fatigue.

9. WARRANTY INFORMATION

The Dghrti TAB30 Tablet comes with a limited warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration. Keep your proof of purchase for warranty

claims.

10. SUPPORT INFORMATION

For further assistance, technical support, or service inquiries, please contact Dghrti customer support through the following channels:

- **Online Support:** Visit the official Dghrti website for FAQs and support resources.
- **Email Support:** Refer to your warranty card or product packaging for the customer service email address.

When contacting support, please have your tablet's model number (TAB30) and purchase information ready.