



Manuals.plus /

› YTE PRO /

› YTE PRO Handheld Cordless Vacuum VC-D17B1 Instruction Manual

YTE PRO VC-D17B1

YTE PRO Handheld Cordless Vacuum VC-D17B1 Instruction Manual

Model: VC-D17B1

1. INTRODUCTION

Thank you for choosing the YTE PRO Handheld Cordless Vacuum. This 3-in-1 vacuum is designed for versatile cleaning in your home, car, and for pet hair, offering powerful suction and convenient features. Please read this manual thoroughly before use to ensure proper operation and maintenance.

What's Included:

- YTE PRO Handheld Vacuum Unit
- Multi-surface Brush
- Crevice Nozzle
- Push-in Brush
- Charging Dock
- Power Adapter
- User Manual

Ready When You Need

Two Charging Methods



Figure 1: All components of the YTE PRO Handheld Cordless Vacuum, including the main unit, various nozzles, charging dock, and power adapter.

2. SETUP AND CHARGING

Initial Charge:

Before first use, fully charge the vacuum. The smart display will indicate battery level. A full charge takes approximately 2.5 hours.

Charging Methods:

1. **Direct Plug-in Charging:** Connect the power adapter directly to the charging port on the vacuum unit.

2. **Magnetic Base Charging:** Place the vacuum onto the charging dock. Ensure the dock is connected to the power adapter. The magnetic connection will secure the vacuum and begin charging. The charging dock also provides convenient storage for the vacuum and its accessories.

300ML Big Capacity

Quick & Easy to Clean Up



Figure 2: The YTE PRO vacuum can be charged directly via a cable or by placing it on its magnetic charging base, which also serves as a storage solution.

3. OPERATING INSTRUCTIONS

Power Modes and Smart Display:

The vacuum features two suction power modes: Standard (Eco Mode) and Max Mode. The smart display provides real-time battery status and indicates the current power mode.

- **Standard Mode (Eco Mode):** Provides up to 25 minutes of continuous cleaning. Ideal for lighter debris and extended use.
- **Max Mode:** Delivers 25000 Pa of powerful suction for tougher messes. Provides up to 13 minutes of continuous cleaning.

Double-Layer Filter



Stainless Filter

Efficiently ease off the decreasing of suction power



HEPA Filter

Block tiny dust particles



Figure 3: The vacuum offers two suction levels: Eco Mode (9000 Pa) for general cleaning and Max Mode (25000 Pa) for deep cleaning.

Multi Function



Figure 4: The smart display provides real-time power information, showing battery percentage and estimated remaining runtime for both Eco and High Speed modes.

Using the Accessories:

Attach the desired nozzle firmly to the vacuum's suction inlet.

- **Crevice Nozzle:** Ideal for reaching tight spaces, such as between car seats, in cup holders, or along baseboards.
- **Push-in Brush:** Use for dusting delicate surfaces, cleaning air vents, or dislodging stubborn dirt from upholstery.
- **Multi-surface Brush:** Effective for picking up pet hair and debris from carpets, rugs, and larger upholstered areas.

Multiple Nozzles



Push-in Brush



Multi-surface Brush



Crevice Nozzle

Figure 5: The vacuum comes with multiple nozzles, including a push-in brush, multi-surface brush, and crevice nozzle, for comprehensive cleaning.



Figure 6: The vacuum's versatile attachments allow for cleaning car seats, cup holders, air vents, and floor mats.

4. MAINTENANCE

Emptying the Dustbin:

The 300ml dust collection box provides ample capacity. To empty, simply press the one-touch release button, and the lid will open, allowing you to dispose of debris without direct contact.

Cleaning the HEPA Filter:

The enhanced HEPA filter captures 99.97% of fine dust particles and is reusable. Regularly clean the filter to maintain optimal suction power and extend the vacuum's lifespan.

1. Twist and remove the dustbin from the main unit.
2. Carefully remove the HEPA filter and stainless steel filter from the dustbin.
3. Rinse both filters under running water until clean.
4. Allow filters to air dry completely before reassembling. Do not use the vacuum with wet filters.



Figure 7: The dustbin can be emptied with a single touch. The HEPA and stainless steel filters are easily removable and washable for reuse.

5. TROUBLESHOOTING

If you encounter any issues with your YTE PRO Handheld Cordless Vacuum, please refer to the following common solutions:

- **No Power:** Ensure the vacuum is fully charged. Check if the charging cable and adapter are properly connected.
- **Weak Suction:** Empty the dustbin if it's full. Clean the HEPA filter and ensure it is completely dry before reinstallation. Check for any blockages in the nozzle or suction path.
- **Unusual Noise:** Turn off the vacuum and check for any foreign objects caught in the motor or brush head.
- **Short Battery Life:** Ensure the vacuum is fully charged. Battery life can vary based on the suction mode used (Max Mode consumes more power).

For further assistance, please contact YTE PRO customer support.

6. SPECIFICATIONS

Feature	Detail
Brand	YTE PRO
Model Name	VC-D17B1
Maximum Suction	25000 Pa (Max Mode)
Battery Life	25 minutes (Standard Mode), 13 minutes (Max Mode)
Charging Time	Approx. 2.5 hours
Dustbin Capacity	300 ml
Filter Type	HEPA Filter, Stainless Steel Filter
Weight	1.1 LB (approx. 450g)
Dimensions	2.76"L x 2.76"W x 15.75"H
Included Components	Adapter, Charging Dock, Crevice Tool, Multi-surface Brush, Push-in Brush

7. WARRANTY AND SUPPORT

YTE PRO is committed to providing high-quality products and excellent customer service. Your handheld vacuum comes with a standard warranty (please refer to your purchase documentation for specific terms).

For any questions regarding the use, maintenance, or troubleshooting of your YTE PRO handheld vacuum, our customer team provides 24-hour technical support and consulting services. Please do not hesitate to reach out to us for assistance.

Contact Information: Please refer to the contact details provided in your product packaging or on the official YTE PRO website.