


CHOEZON TPR12BFC1



CHOEZON TPR12BFC1 Hanging Pot Rack Instruction Manual

Model: TPR12BFC1

Safety Information	Components	Setup & Installation	Operating
Instructions	Maintenance	Troubleshooting	Specifications

INTRODUCTION

This manual provides detailed instructions for the assembly, installation, and use of your CHOEZON TPR12BFC1 Hanging Pot Rack. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The CHOEZON TPR12BFC1 is a versatile, industrial-style pot rack designed to maximize kitchen space by providing overhead storage for cookware. It features a rustic brown and black finish, a mesh shelf, and 18 S-shaped hooks for organizing pots, pans, and other kitchen essentials.

SAFETY INFORMATION

- **Read all instructions:** Ensure you understand all assembly and installation steps before proceeding.
- **Proper mounting:** The pot rack must be securely mounted to ceiling joists or appropriate wall studs. Do not mount to drywall or plaster without proper anchors that can support the weight of the rack and its contents.
- **Weight capacity:** Do not exceed the maximum load-bearing capacity of 44 lbs (20 kg). Overloading can cause the rack to fall, resulting in injury or damage.
- **Check wall materials:** The actual load-bearing capacity may vary by wall materials. Choose appropriate screws and anchors based on your specific wall conditions. Consult a professional if unsure.
- **Secure hooks:** Ensure all S-shaped hooks are properly seated and secure before hanging cookware.
- **Regular inspection:** Periodically check all connections, screws, and chains to ensure they remain tight and secure.

- **Keep children away:** During assembly and installation, keep children and pets away from the work area.

PACKAGE CONTENTS

Please verify that all components listed below are present before beginning assembly.

- Pot Rack Frame (Particleboard and Metal Mesh Shelf)
- Metal Chains (4 x 19.7 inches each)
- S-shaped Hooks (18 pieces, including 1 spare)
- Assembly Hardware (screws, expansion screws for diverse walls)
- Instruction Manual




Figure 1: Product Dimensions and Included Components. The diagram illustrates the pot rack frame measuring 35.4 inches in length, 13 inches in width, and 2.4 inches in height. It also shows four 19.7-inch chains and 18 S-shaped hooks.

SETUP & INSTALLATION

Follow these steps for proper assembly and installation of your pot rack.

Tools Required (Not Included):

- Drill

- Drill bits appropriate for chosen screws/anchors
- Pencil
- Measuring Tape
- Level
- Stud Finder (recommended for ceiling/wall mounting)

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all components are present against the "Package Contents" list.
2. **Assemble the Frame:** Attach the metal mesh shelf to the particleboard frame using the provided screws. Ensure all connections are tight.
3. **Attach Chains:** Securely attach the four metal chains to the designated points on the pot rack frame. Ensure the chains are evenly distributed for balanced hanging.

Metal and Wooden Material

A new vintage style embodies the latest trend in modern kitchen storage.



THE DETAILS



Solid Iron Chains



Removable Hooks



Premium Materials

Figure 2: Detailed view of the pot rack components, highlighting the solid iron chains, removable S-hooks, and the rustic wood-look particleboard with metal frame.

Installation (Ceiling/Wall Mounted):

The pot rack can be mounted to the ceiling or a wall. Choose the appropriate mounting location based on your kitchen layout and structural support.

1. Identify Mounting Points:

- For ceiling mounting: Use a stud finder to locate ceiling joists. Mark four points on the ceiling where the chains will attach, ensuring they align with the attachment points on the pot rack. These points should be strong enough to support the rack and its maximum load.
 - For wall mounting: Locate wall studs. Mark points for mounting brackets (not explicitly mentioned as included, but implied by "two types of expansion screws for diverse walls"). Ensure the wall can support the weight.
2. **Drill Pilot Holes:** Drill pilot holes at the marked locations using a drill bit suitable for your chosen screws and wall material. If using expansion screws, follow their specific installation instructions.
 3. **Install Mounting Hardware:** Securely install the appropriate mounting hardware (e.g., ceiling hooks, wall brackets) into the pilot holes. Ensure they are firmly anchored.
 4. **Hang the Pot Rack:** Carefully lift the assembled pot rack and attach the chains to the installed mounting hardware. Use a level to ensure the rack hangs evenly.
 5. **Attach Hooks:** Distribute the S-shaped hooks along the bottom bars of the pot rack as desired.



Wall-Mounted Pot Rack

Maximize space utilization and release more countertop area.

Figure 3: Example of the pot rack installed above a kitchen island, demonstrating its space-saving design and capacity for hanging cookware.



Figure 4: Another installation example, showing the pot rack mounted in front of a kitchen window, providing convenient access to cookware.

Your browser does not support the video tag.

Video 1: Official CHOEZON product video demonstrating the hanging pot rack in use, showcasing its features and installation.

OPERATING INSTRUCTIONS

- Hanging Cookware:** Use the provided S-shaped hooks to hang pots, pans, and other utensils. Ensure items are balanced to prevent the rack from tilting.
- Using the Mesh Shelf:** The top mesh shelf can be used to store lids, smaller pots, or other lightweight kitchen items. Do not place excessively heavy items on the shelf.
- Weight Distribution:** Distribute the weight of your cookware evenly across the rack to maintain stability and prevent strain on the mounting points.
- Adjusting Hooks:** The S-shaped hooks can be easily repositioned along the bottom bars to accommodate different sizes and quantities of cookware.

MAINTENANCE

- Cleaning:** Wipe the pot rack with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- Regular Checks:** Periodically inspect all screws, bolts, and chain connections to ensure they remain tight. Tighten any loose fasteners immediately.
- Weight Limit:** Always adhere to the maximum weight capacity of 44 lbs (20 kg).

TROUBLESHOOTING

Problem	Possible Cause	Solution
Pot rack is wobbly or unstable.	Loose mounting hardware or uneven weight distribution.	Check and tighten all mounting screws and chain connections. Redistribute cookware evenly. Ensure mounting points are in solid joists/studs.
Pot rack sags in the middle.	Overloaded or uneven weight distribution.	Reduce the total weight on the rack. Ensure weight is distributed evenly across the entire length. Do not exceed 44 lbs (20 kg).
Hooks fall off easily.	Hooks are not properly seated or are overloaded.	Ensure hooks are fully engaged on the rack's bars. Avoid hanging excessively heavy items on a single hook.
Difficulty with assembly.	Missing parts or unclear instructions.	Refer to the "Package Contents" section to verify all parts. Review the "Setup & Installation" section carefully. Contact customer support if parts are missing or instructions remain unclear.

SPECIFICATIONS

Feature	Detail
Model Number	TPR12BFC1
Brand	CHOEZON
Material	Engineered Wood, Metal
Color	Rustic Brown and Black

Feature	Detail
Product Dimensions (L x W x H)	35.4" x 13" x 2.4" (90cm x 33cm x 6cm)
Item Weight	7.19 pounds (3.26 kg)
Shelf Type	Wire Rack
Number of Shelves	1
Mounting Type	Ceiling Mount (can also be adapted for wall mount)
Maximum Load Capacity	44 lbs (20 kg)
Included Components	Pot Rack Frame, 4 Metal Chains, 18 S-shaped Hooks, Assembly Hardware
Assembly Required	Yes
Indoor/Outdoor Usage	Indoor

WARRANTY AND SUPPORT

For warranty information or customer support, please contact CHOEZON directly through their official channels or the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

Manufacturer: CHOEZON

Contact: Refer to the contact information provided with your product packaging or visit the official CHOEZON website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DKXJMJVJ>

More documents and user manuals: <https://manuals.plus/>